

# INSTRUCTION MANUAL



## Model HFP01 Soil Heat Flux Plate

Revision: 10/16



Copyright © 2002-2016  
Campbell Scientific, Inc.



# ***Limited Warranty***

---

“Products manufactured by CSI are warranted by CSI to be free from defects in materials and workmanship under normal use and service for twelve months from the date of shipment unless otherwise specified in the corresponding product manual. (Product manuals are available for review online at [www.campbellsci.com](http://www.campbellsci.com).) Products not manufactured by CSI, but that are resold by CSI, are warranted only to the limits extended by the original manufacturer. Batteries, fine-wire thermocouples, desiccant, and other consumables have no warranty. CSI’s obligation under this warranty is limited to repairing or replacing (at CSI’s option) defective Products, which shall be the sole and exclusive remedy under this warranty. The Customer assumes all costs of removing, reinstalling, and shipping defective Products to CSI. CSI will return such Products by surface carrier prepaid within the continental United States of America. To all other locations, CSI will return such Products best way CIP (port of entry) per Incoterms ® 2010. This warranty shall not apply to any Products which have been subjected to modification, misuse, neglect, improper service, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied. The warranty for installation services performed by CSI such as programming to customer specifications, electrical connections to Products manufactured by CSI, and Product specific training, is part of CSI’s product warranty. **CSI EXPRESSLY DISCLAIMS AND EXCLUDES ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. CSI hereby disclaims, to the fullest extent allowed by applicable law, any and all warranties and conditions with respect to the Products, whether express, implied or statutory, other than those expressly provided herein.”**

# Assistance

---

Products may not be returned without prior authorization. The following contact information is for US and international customers residing in countries served by Campbell Scientific, Inc. directly. Affiliate companies handle repairs for customers within their territories. Please visit [www.campbellsci.com](http://www.campbellsci.com) to determine which Campbell Scientific company serves your country.

To obtain a Returned Materials Authorization (RMA), contact CAMPBELL SCIENTIFIC, INC., phone (435) 227-9000. Please write the issued RMA number clearly on the outside of the shipping container. Campbell Scientific's shipping address is:

**CAMPBELL SCIENTIFIC, INC.**

RMA# \_\_\_\_\_  
815 West 1800 North  
Logan, Utah 84321-1784

For all returns, the customer must fill out a "Statement of Product Cleanliness and Decontamination" form and comply with the requirements specified in it. The form is available from our website at [www.campbellsci.com/repair](http://www.campbellsci.com/repair). A completed form must be either emailed to [repair@campbellsci.com](mailto:repair@campbellsci.com) or faxed to (435) 227-9106. Campbell Scientific is unable to process any returns until we receive this form. If the form is not received within three days of product receipt or is incomplete, the product will be returned to the customer at the customer's expense. Campbell Scientific reserves the right to refuse service on products that were exposed to contaminants that may cause health or safety concerns for our employees.

# Safety

---

**DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC. FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.**

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at [www.campbellsci.com](http://www.campbellsci.com) or by telephoning (435) 227-9000 (USA). You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified engineer. If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

## General

- Prior to performing site or installation work, obtain required approvals and permits. Comply with all governing structure-height regulations, such as those of the FAA in the USA.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a **hardhat** and **eye protection**, and take **other appropriate safety precautions** while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

## Utility and Electrical

- **You can be killed** or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in **contact with overhead or underground utility lines**.
- Maintain a distance of at least one-and-one-half times structure height, 20 feet, or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.

## Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

## Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CUSTOMER ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.



# Table of Contents

---

*PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.*

<b>1. Introduction .....</b>	<b>1</b>
<b>2. Precautions .....</b>	<b>1</b>
<b>3. Initial Inspection.....</b>	<b>1</b>
<b>4. Overview .....</b>	<b>1</b>
<b>5. Specifications.....</b>	<b>2</b>
<b>6. Installation.....</b>	<b>3</b>
6.1 Placement in Soil .....	3
6.2 Wiring .....	4
6.3 Programming.....	5
6.4 Soil Heat Flux and Storage .....	5
<b>7. Maintenance .....</b>	<b>6</b>
<b>8. References.....</b>	<b>6</b>

## ***Appendices***

<b>A. General Theory of Heat Flux Sensors.....</b>	<b>A-1</b>
A.1 General Theory .....	A-1
A.2 Extended Theory .....	A-2
<b>B. Example Program.....</b>	<b>B-1</b>

## ***Figures***

6-1. Placement of heat flux plates .....	3
6-2. HFP01 plate to datalogger connections.....	4
A-1. General characteristics of a heat flux sensor .....	A-1
A-2. Deflection error .....	A-2

**Tables**

6-1. Wire Color, Function, and Datalogger Connections ..... 5  
B-1. Wiring for CRBasic Example B-1 ..... B-1

**CRBasic Example**

B-1. Sample CR3000 Program using Differential Measurement  
Instructions ..... B-1



# Model HFP01 Soil Heat Flux Plate

---

## 1. Introduction

The HFP01 outputs a voltage signal that is proportional to the heat flux of the surrounding medium (usually soil). It is typically used for energy-balance or Bowen-ratio flux systems. At least two sensors are required for each site to provide spatial averaging. Sites with heterogeneous media may require additional sensors.

---

**NOTE**

This manual provides information only for CRBasic dataloggers. It is also compatible with most of our retired Edlog dataloggers. For Edlog datalogger support, see an older manual at [www.campbellsci.com/old-manuals](http://www.campbellsci.com/old-manuals).

---

## 2. Precautions

- READ AND UNDERSTAND the *Safety* section at the front of this manual.
- Care should be taken when opening the shipping package to not damage or cut the cable jacket. If damage to the cable is suspected, consult with a Campbell Scientific applications engineer.
- Although the HFP01 is rugged, it should be handled as a precision scientific instrument.

## 3. Initial Inspection

- Upon receipt of the HFP01, inspect the packaging and contents for damage. File damage claims with the shipping company.
- The model number and cable length are printed on a label at the connection end of the cable. Check this information against the shipping documents to ensure the correct product and cable length are received.
- The HFP01 is shipped with a calibration sheet and an instruction manual or a *ResourceDVD*.

## 4. Overview

The HFP01 Soil Heat Flux Plate uses a thermopile to measure temperature gradients across its plate. Operating in a completely passive way, it generates a small output voltage that is proportional to this differential temperature. Assuming that the heat flux is steady, that the thermal conductivity of the body is constant, and that the sensor has negligible influence on the thermal flow pattern, the signal of the HFP01 is directly proportional to the local heat flux.

The HFP01's output is in millivolts. To convert this measured voltage to heat flux, it must be divided by the plate's calibration constant. A unique calibration constant is supplied with each sensor.

To get the soil heat flux at the surface, use at least two HFP01s to measure soil heat flux at a depth of 8 cm; a TCAV Averaging Soil Thermocouple to measure the temporal change in temperature of the soil layer above the HFP01; and a CS616, CS650, or CS655 water content reflectometer to measure soil water content. The temporal change in soil temperature and soil water content are used to compute the soil storage term.

The -L extension in the model name (for example, HFP01-L) indicates a user-specified cable length. This manual refers to the sensor as the HFP01.

The sensor's cable can terminate in:

- Pigtails that connect directly to a Campbell Scientific datalogger (option -PT).
- Connector that attaches to a prewired enclosure (option -PW). Refer to [www.campbellsci.com/prewired-enclosures](http://www.campbellsci.com/prewired-enclosures) for more information.
- Connector that attaches to a CWS900 Wireless Sensor Interface (option -CWS). The CWS900 allows the probe to be used in a wireless sensor network. Refer to [www.campbellsci.com/cws900](http://www.campbellsci.com/cws900) for more information.

---

**NOTE**

A general discussion about the characteristics and principles of operation of heat flux sensors is shown in Appendix A, *General Theory of Heat Flux Sensors (p. A-1)*.

---

## 5. Specifications

**Features:**

- Ideal for energy-balance or Bowen-ratio systems
- Compatible with the CWS900-series interfaces, allowing it to be used in a wireless sensor network
- Compatible with Campbell Scientific CRBasic dataloggers: CR6 series, CR800 series, CR1000, CR3000, CR5000, and CR9000(X)

**Operating Temperature:** -30 to 70 °C

**Plate Thickness:** 5.0 mm (0.20 in)

**Plate Diameter:** 80.0 mm (3.15 in)

**Weight (without cable):** 200 g (7.05 oz)

**Sensor:** Thermopile

**Measurement Range:**  $\pm 2000 \text{ W m}^{-2}$

<b>Sensitivity (nominal):</b>	50 $\mu\text{V W}^{-1} \text{m}^{-2}$
<b>Expected Typical Accuracy (12 hour totals):</b>	Within $-15\%$ to $+5\%$ in most common soils
<b>Nominal Resistance:</b>	2 W
<b>Sensor Thermal Resistance:</b>	$<6.25 \times 10^{-3} \text{ Km}^2\text{W}^{-1}$

## 6. Installation

### 6.1 Placement in Soil

The standard set of sensors for measuring soil heat flux includes two HFP01 Soil Heat Flux Plates, one TCAV Averaging Soil Thermocouple, and one CS616, CS650, or CS655 water content reflectometer. These sensors are installed as shown in FIGURE 6-1.




FIGURE 6-1. Placement of heat flux plates

The location of the heat flux plates and thermocouple should be chosen to be representative of the area under study. If the ground cover is extremely varied, an additional set of sensors is required to provide a valid soil heat flux average.

Use a small shovel to make a vertical slice in the soil. Excavate the soil to one side of the slice. Keep this soil intact so that it can be replaced with minimal disruption.

The sensors are installed in the undisturbed face of the hole. Measure the sensor depths from the top of the hole. With a small knife, make a horizontal cut 8 cm below the surface into the undisturbed face of the hole. Insert the heat flux plate into the horizontal cut.

---

**NOTE** Install the HFP01 in the soil such that the side with the red label is facing the sky and the side with a blue label is facing the soil.

---

**CAUTION** To make quality soil heat flux measurements, the HFP01's plate must be in full contact with the soil.

---

Never run the sensors leads directly to the surface. Rather, bury the sensor leads a short distance back from the hole to minimize thermal conduction on the lead wire. Replace the excavated soil back into its original position after all the sensors are installed.

---

**NOTE** To protect sensor cables from damage caused by rodents, Campbell Scientific recommends burying them inside of flexible electrical tubing.

---

## 6.2 Wiring

Wire functions are shown in FIGURE 6-2. TABLE 6-1 provides the datalogger connections for both single-ended and differential measurements. Typically, the differential measurements are used.




FIGURE 6-2. HFP01 plate to datalogger connections

**TABLE 6-1. Wire Color, Function, and Datalogger Connections**

Wire Color	Wire Function	Datalogger Single-Ended Measurement	Datalogger Differential Measurement
White	Signal	U configured for single-ended analog input <sup>1</sup> , <b>SE</b> (single-ended, analog input)	U configured for differential analog input high <sup>1</sup> , <b>DIFF H</b> (differential high, analog input)
Green	Signal Reference	<b>AG</b> or $\perp$ (analog ground)	U configured for differential analog input low <sup>1</sup> , <b>DIFF L</b> (differential low, analog input)
Clear	Shield	<b>AG</b> or $\perp$ (analog ground)	<b>AG</b> or $\perp$ (analog ground)

<sup>1</sup>U channels are automatically configured by the measurement instruction.

### 6.3 Programming

Programming basics for CRBasic dataloggers are in this section. A complete program example for a CRBasic datalogger can be found in Appendix B, *Example Program (p. B-1)*. Programming basics and programming examples for Edlog dataloggers are provided at [www.campbellsci.com/old-manuals](http://www.campbellsci.com/old-manuals).

The HFP01 is measured using either a single-ended (**VoltSE**) or differential (**VoltDiff**) instruction. The differential measurement is recommended.

Syntax of the **VoltDiff()** instruction is:

**VoltDiff**(Dest, Reps, Range, DiffChan, RevDiff, SettlingTime, Integ/FNotch, Mult, Offset)

Syntax of the **VoltSE()** instruction is:

**VoltSE**(Dest, Reps, Range, SEChan, MeasOff, SettlingTime, Integ/FNotch, Mult, Offset)

For the multiplier, divide 1000 by the nominal calibration sensitivity (1000/sensitivity). The nominal calibration is unique for each HFP01.

Each sensor is accompanied with a calibration certificate and has a label on it with the calibration values. The label is located on the pigtail end of the sensor leads.

### 6.4 Soil Heat Flux and Storage

The soil heat flux at the surface is calculated by adding the measured flux at a fixed depth, *d*, to the energy stored in the layer above the heat flux plates. The specific heat of the soil and the change in soil temperature,  $\Delta T_s$ , over the output interval, *t*, are required to calculate the stored energy.

The heat capacity of the soil is calculated by adding the specific heat of the dry soil to that of the soil water. The values used for specific heat of dry soil and water are on a mass basis. The heat capacity of the moist soil is given by:

$$C_s = \rho_b(C_d + \theta_m C_w) = \rho_b C_d + \theta_v \rho_w C_w \tag{1}$$

$$\theta_m = \frac{\rho_w}{\rho_b} \theta_v \quad (2)$$

where  $C_s$  is the heat capacity of moist soil,  $\rho_b$  is bulk density,  $\rho_w$  is the density of water,  $C_d$  is the heat capacity of a dry mineral soil,  $\theta_m$  is soil water content on a mass basis,  $\theta_v$  is soil water content on a volume basis, and  $C_w$  is the heat capacity of water.

This calculation requires site specific inputs for bulk density, mass basis soil water content or volume basis soil water content, and the specific heat of the dry soil. Bulk density and mass basis soil water content can be found by sampling (Klute, 1986). The volumetric soil water content is measured by the CS616 water content reflectometer. A value of  $840 \text{ J kg}^{-1} \text{ K}^{-1}$  for the heat capacity of dry soil is a reasonable value for most mineral soils (Hanks and Ashcroft, 1980).

The storage term is then given by Eq. (3) and the soil heat flux at the surface is given by Eq. (4).

$$S = \frac{\Delta T_s C_s d}{t} \quad (3)$$

$$G_{sfc} = G_{8cm} + S \quad (4)$$

## 7. Maintenance

### NOTE

---

All factory repairs and calibrations require a returned material authorization (RMA) and completion of the “Declaration of Hazardous Material and Decontamination” form. Refer to the [Assistance](#) page at the beginning of this manual for more information.

---

The HFP01 requires minimal maintenance. Check the sensor leads monthly for rodent damage. Recalibrate the HFP01 for every two years of continuous use.

## 8. References

- Hanks, R. J., and G. L. Ashcroft, 1980: *Applied Soil Physics: Soil Water and Temperature Application*. Springer-Verlag, 159 pp.
- Klute, A., 1986: *Method of Soil Analysis*. No. 9, Part 1, Sections 13 and 21, American Society of Agronomy, Inc., Soil Science Society of America, Inc.

# Appendix A. General Theory of Heat Flux Sensors

This appendix discusses the general theory and characteristics of heat flux sensors similar to the HFP01.

## A.1 General Theory




FIGURE A-1. General characteristics of a heat flux sensor

When heat is flowing through the sensor in the indicated direction, the filling material will act as a thermal resistance. Consequently, the heat flow,  $\phi$ , will follow a temperature gradient across the sensor, flowing from the hot to the cold side. Most heat flux sensors are based on a thermopile—a number of thermocouples connected in series. A single thermocouple will generate an output voltage that is proportional to the temperature difference between the joints (copper-constantan and constantan-copper). Provided that errors are avoided, the temperature difference is proportional to the heat flux—depending only on the thickness and the thermal conductivity of the sensor. Using more thermocouples in series will enhance the output signal. In FIGURE A-1, the joints of a copper-constantan thermopile are alternatively placed on the hot and the cold side of the sensor.

The thermopile is embedded in a filling material, usually plastic.

Each individual sensor has its own sensitivity,  $E_{\text{sen}}$ , usually expressed in Volts output,  $V_{\text{sen}}$ , per Watt per square meter heat flux,  $\phi$ . The flux is calculated:

$$\phi = V_{\text{sen}} / E_{\text{sen}}$$

The sensitivity is determined by the manufacturer, and is found on the calibration certificate that is supplied with each sensor.

When used for measuring soil heat flux, heat flux sensors such as the HFP01 reach a limited level of accuracy. This is because thermal parameters of soil are constantly changing (soil moisture content) and the ambient temperature is not fixed. A realistic estimate of the error range is  $\pm 20\%$  over a thermal conductivity range from 0.1 to 1.7 W/mK (dry sand to water-saturated sand) across the temperature range of  $-30$  to  $70$  °C. The accuracy is better if the soil conditions are closer to the reference conditions (see the sensor specifications) and, in an actual experiment, the expected error range will probably be  $\pm 10\%$ .

The reference conditions for the calibration are a thermal conductivity of 0.8 W/mK and a nominal temperature of 20 °C.

## A.2 Extended Theory

Obviously, the sensor itself can significantly disturb the phenomenon that it is supposed to measure. By adding a sensor to the material under observation, you can add additional, and sometimes differing, thermal resistances.

The deflection error, as shown in FIGURE A-2, represents the effect that, as a result of differing resistances, the flow pattern will change, especially at the edges of the heat flux sensor. The order of magnitude of this error for strongly different thermal conductivity values between the sensor and its environment (for example 0.6 for a typical sensor and 0.03 for an insulating wall) is about 40%.




FIGURE A-2. Deflection error

The heat flux is deflected at the edges of the sensor. As a result, the heat flow at the edges is not representative.

Apart from the sensor thermal resistance, the contact resistance between the sensor and surrounding material require special attention.

The conductivity of air is approximately 0.02 W/mK which is ten times smaller than that of the heat flux sensor. It follows, therefore, that air gaps can form major contact resistances. In all cases, the contact between sensor and surrounding material should be as close and as stable as possible, so that it will not influence the measurements.

Aspects of differing thermal properties between sensor and its environment can also be dealt with during the measurement using a higher accuracy self-calibrating type of heat flux sensor.



# Appendix B. Example Program

The nominal calibration sensitivity is  $67.1 \mu\text{V}/\text{W}^{-2}$  for the HFP01#1 and  $67.0 \mu\text{V}/\text{W}^{-2}$  for the HFP01#2. In CRBasic Example B-1, the nominal calibration sensitivity is  $67.1 \mu\text{V}/\text{W}^{-2}$ .

TABLE B-1. Wiring for CRBasic Example B-1		
Description	Color	CR3000
Sensor Signal #1	White	7H
Sensor Signal Reference #1	Green	7L
Shield #1	Clear	$\perp$
Sensor Signal #2	White	8H
Sensor Signal Reference #2	Green	8L
Shield #2	Clear	$\perp$

## CRBasic Example B-1. Sample CR3000 Program using Differential Measurement Instructions

```
'CR3000 Series Datalogger
'Copyright (c) 2007, Campbell Scientific, Inc. All rights reserved.
'This datalogger program measures two HFP01 Hukseflux soil heat flux sensors
'*** Wiring ***
'7H HFP01 #1 signal (white)
'7L HFP01 #1 signal reference (green)
'gnd HFP01 #1 shield (clear)
'8H HFP01 #2 signal (white)
'8L HFP01 #2 signal reference (green)
'gnd HFP01 #2 shield (clear)
'*** Constants ***
Const HFP01_CAL_1 = 14.90 'Unique multiplier for HFP01 #1. 1000/sensitivity (1000/67.1)
Const HFP01_CAL_2 = 14.92 'Unique multiplier for HFP01 #2. 1000/sensitivity (1000/67.0)
'*** Variables ***
'Energy balance sensors.
Public shf(2)
Dim shf_cal(2) 'Soil heat flux plate calibration coefficients.
Units shf = W/m^2
'*** Final Output Data Tables ***
DataTable (soil_hf, TRUE, -1)
  DataInterval (0, 30, Min, 10)
  Average (2, shf(1), IEEE4, FALSE)
EndTable
```

```
*** Program ***  
  
BeginProg  
  
'Load the HFP01 factory calibration.  
shf_cal(1) = HFP01_CAL_1  
shf_cal(2) = HFP01_CAL_2  
  
Scan (1,Sec,3,0)  
  
  'Measure the HFP01 soil heat flux plates.  
  VoltDiff (shf(1),2,mV50C,7,TRUE,200,250,shf_cal(),0)  
  
  CallTable soil_hf  
  
NextScan  
EndProg
```



## Campbell Scientific Companies

---

**Campbell Scientific, Inc.**

815 West 1800 North  
Logan, Utah 84321  
UNITED STATES

[www.campbellsci.com](http://www.campbellsci.com) • [info@campbellsci.com](mailto:info@campbellsci.com)

**Campbell Scientific Canada Corp.**

14532 – 131 Avenue NW  
Edmonton AB T5L 4X4  
CANADA

[www.campbellsci.ca](http://www.campbellsci.ca) • [dataloggers@campbellsci.ca](mailto:dataloggers@campbellsci.ca)

**Campbell Scientific Africa Pty. Ltd.**

PO Box 2450  
Somerset West 7129  
SOUTH AFRICA

[www.campbellsci.co.za](http://www.campbellsci.co.za) • [cleroux@csafrica.co.za](mailto:cleroux@csafrica.co.za)

**Campbell Scientific Centro Caribe S.A.**

300 N Cementerio, Edificio Breller  
Santo Domingo, Heredia 40305  
COSTA RICA

[www.campbellsci.cc](http://www.campbellsci.cc) • [info@campbellsci.cc](mailto:info@campbellsci.cc)

**Campbell Scientific Southeast Asia Co., Ltd.**

877/22 Nirvana@Work, Rama 9 Road  
Suan Luang Subdistrict, Suan Luang District  
Bangkok 10250  
THAILAND

[www.campbellsci.asia](http://www.campbellsci.asia) • [info@campbellsci.asia](mailto:info@campbellsci.asia)

**Campbell Scientific Ltd.**

Campbell Park  
80 Hathern Road  
Shepshed, Loughborough LE12 9GX  
UNITED KINGDOM

[www.campbellsci.co.uk](http://www.campbellsci.co.uk) • [sales@campbellsci.co.uk](mailto:sales@campbellsci.co.uk)

**Campbell Scientific Australia Pty. Ltd.**

PO Box 8108  
Garbutt Post Shop QLD 4814  
AUSTRALIA

[www.campbellsci.com.au](http://www.campbellsci.com.au) • [info@campbellsci.com.au](mailto:info@campbellsci.com.au)

**Campbell Scientific Ltd.**

3 Avenue de la Division Leclerc  
92160 ANTONY  
FRANCE

[www.campbellsci.fr](http://www.campbellsci.fr) • [info@campbellsci.fr](mailto:info@campbellsci.fr)

**Campbell Scientific (Beijing) Co., Ltd.**

8B16, Floor 8 Tower B, Hanwei Plaza  
7 Guanghua Road  
Chaoyang, Beijing 100004  
P.R. CHINA

[www.campbellsci.com](http://www.campbellsci.com) • [info@campbellsci.com.cn](mailto:info@campbellsci.com.cn)

**Campbell Scientific Ltd.**

Fahrenheitstraße 13  
28359 Bremen  
GERMANY

[www.campbellsci.de](http://www.campbellsci.de) • [info@campbellsci.de](mailto:info@campbellsci.de)

**Campbell Scientific do Brasil Ltda.**

Rua Apinagés, nbr. 2018 – Perdizes  
CEP: 01258-00 – São Paulo – SP  
BRASIL

[www.campbellsci.com.br](http://www.campbellsci.com.br) • [vendas@campbellsci.com.br](mailto:vendas@campbellsci.com.br)

**Campbell Scientific Spain, S. L.**

Avda. Pompeu Fabra 7-9, local 1  
08024 Barcelona  
SPAIN

[www.campbellsci.es](http://www.campbellsci.es) • [info@campbellsci.es](mailto:info@campbellsci.es)

Please visit [www.campbellsci.com](http://www.campbellsci.com) to obtain contact information for your local US or international representative.