

05103AP-10
R.M. YOUNG WIND MONITOR
INSTRUCTION MANUAL

REVISION: 01/07/2004

COPYRIGHT (c) 1984-2004 CAMPBELL SCIENTIFIC, INC.

WARRANTY AND ASSISTANCE

This equipment is warranted by CAMPBELL SCIENTIFIC (CANADA) CORP. ("CSC") to be free from defects in materials and workmanship under normal use and service for **twelve (12) months** from date of shipment unless specified otherwise. ***** **Batteries are not warranted.** ***** CSC's obligation under this warranty is limited to repairing or replacing (at CSC's option) defective products. The customer shall assume all costs of removing, reinstalling, and shipping defective products to CSC. CSC will return such products by surface carrier prepaid. This warranty shall not apply to any CSC products which have been subjected to modification, misuse, neglect, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for a particular purpose. CSC is not liable for special, indirect, incidental, or consequential damages.

Products may not be returned without prior authorization. To obtain a Return Merchandise Authorization (RMA), contact CAMPBELL SCIENTIFIC (CANADA) CORP., at (780) 454-2505. An RMA number will be issued in order to facilitate Repair Personnel in identifying an instrument upon arrival. Please write this number clearly on the outside of the shipping container. Include description of symptoms and all pertinent details.

CAMPBELL SCIENTIFIC (CANADA) CORP. does not accept collect calls.

Non-warranty products returned for repair should be accompanied by a purchase order to cover repair costs.



CAMPBELL SCIENTIFIC
CANADA CORP.

11564 - 149 street - edmonton - alberta - T5M 1W7
tel 780.454.2505 fax 780.454.2655

www.campbellsci.ca

05103AP-10 R.M. YOUNG WIND MONITOR

1. INTRODUCTION

These notes provide information for interfacing Campbell Scientific, Inc.'s CR10, CR10X, CR510, 21X, and CR7 dataloggers to the R.M. Young 05103AP-10 Wind Monitor and 05305-10 Wind Monitor AQ. The 05305-10 Wind Monitor AQ is a high performance version of the 05103-10 Wind Monitor that is designed specifically for air quality measurements. Wiring is identical for both models. R.M. Young's instruction manual is also included, which contains sensor specifications, operating principles, installation and alignment guide, and calibration information. Multiplier and offset values in the Campbell Scientific notes are based on calibration data obtained from the R.M. Young Wind Monitor manual.

2. MOUNTING REQUIREMENTS

The Wind Monitor mounts to a vertical piece of 1" IPS schedule 40 (1.32" O.D.) pipe. (See Figure 2-1.) A band clamp at the base of the sensor is tightened to secure the sensor to the pipe.

Orient the junction box to true south for proper azimuth readings.




FIGURE 2-1. Wind Monitor Mounted to a Vertical Pipe

3. SENSOR TO DATALOGGER WIRING

Wire the Wind Monitor leads to the datalogger (see Figure 3-1). Figure 3-2 depicts the wind monitor's circuit diagram.

NOTE: The black outer jacket of the cable is Santoprene® rubber. This compound was chosen for its resistance to temperature extremes, moisture, and UV degradation. However, this jacket will support combustion in air. It is rated as slow burning when tested according to U.L. 94 H.B. and will pass FMVSS302. Local fire codes may preclude its use inside buildings.

4. PROGRAMMING

4.1 WIND SPEED

Measure the wind speed with Instruction 3 (Pulse Count). Wind vector instruction 69 is used to calculate average wind speed and direction. With the pulse count instruction, specify a configuration code of 21 (low level AC, discarding counts from excessive intervals, result in Hz). With this configuration code, Instruction 3 divides the number of counts during the execution interval by the interval in seconds before applying the multiplier and offset.

The expression for wind speed (U) is:

$$U = MX + B$$

where

M = multiplier

X = number of pulses per second

B = offset

Table 4-1 lists the multipliers to obtain miles/hour or meters/second when configuration code 21 is used. The helicoid propeller has a calibration that passes through zero; use an offset of zero (Gill, 1973; Baynton, 1976).

TABLE 4-1. Wind Speed Multiplier (With Configuration Code 21*)

<u>Model</u>	<u>Miles/hour output</u>	<u>Meters/second output</u>
05103AP-10	0.2192	0.0980
05305-10	0.2290	0.1024

*When configuration code 11 is used, the multiplier above is divided by the execution interval in seconds.

05103AP-10 R.M. YOUNG WIND MONITOR

NOTE: 21Xs without OSX PROMS and CR7s without OS7 PROMS (dataloggers purchased prior to March 1989 and August 1991 respectively, and not updated) do not have the option of outputting frequency in hertz. Program Instruction 3 with configuration code 11 (pulses per execution interval). The multiplier from Table 4-1 is divided by the execution interval in seconds to obtain the multiplier used with code 11. For example, with a 10 second execution interval, the multiplier for meters/second with the 05103AP-10 would be $0.0980/10 = 0.0098$. The offset remains zero.




FIGURE 2-2. Wind Monitor Mounted to Campbell Scientific's 019WM Crossarm Mount

Signal	CR7/21X	CR510/ CR10(X)	CR23X	Grey Cable (P/N 6549)	Black Cable (P/N 9721)
WSPD (REF)	G	G	AG near Pulse Channel	Black of Red & Black	Black
WDIR (REF)	G	AG	AG	Black of Green & Black	White
WDIR (SIG+)	H or L (Analog Channel)	H or L (Analog Channel)	H or L (Analog Channel)	Green	Green
WDIR (EX+)	Excitation	Excitation	Excitation	Black of White & Black	Blue
WSPD (SIG+)	Pulse	Pulse	Pulse	Red	Red
Drain	G	G	AG near Analog Channel	Clear	Clear

FIGURE 3-1. Wind Monitor Connections to Campbell Scientific Dataloggers**4.2 WIND DIRECTION INSTRUCTION CODE**

Measure the wind direction with Instruction 4 (Excite, Delay, and Measure). In general, a delay of 2 (0.02 seconds) is sufficient when lead lengths are less than 100 feet. If the cable is 100 to 1000 feet, use a delay of 20 (0.20 seconds). If you need further assistance with

the delay, contact Campbell Scientific's Technical Support Department. The wind direction potentiometer has a five degree deadband between 355 and 360 degrees; therefore, the multiplier is 355/Excitation Voltage. The offset is zero. The parameters to be used with each datalogger are listed in Table 4-2.

TABLE 4-2. Instruction 4 Parameters for Wind Direction

	CR10	21X	CR7
Measurement Range	2500 mV, slow	5000 mV, slow	5000 mV, fast
Excitation Voltage	2500 mV	5000 mV	5000 mV
Multiplier	0.142 deg/mV	0.071 deg/mV	0.071 deg/mV
Offset	0	0	0

5. MAINTENANCE AND REPAIRS

R.M. Young suggests the anemometer bearings be inspected at least every 24 months. Please refer to the R.M. Young manual for maintenance information.

Contact Campbell Scientific at (780) 454-2505 to obtain repair cost estimates and a Return Merchandise Authorization (RMA) Number.

6. REFERENCES

Gill, G.C., 1973: The Helicoid Anemometer Atmosphere, II, 145-155.

Baynton, H.W., 1976: Errors in Wind Run Estimates from Rotational Anemometers Bul. Am. Met. Soc., vol. 57, No. 9, 1127-1130.

05103AP-10 R.M. YOUNG WIND MONITOR




FIGURE 3-2. Wind Monitor's Circuit Diagram

NOTE: The 05103AP-10 is a modified version of R.M. Young's model 05103 -45. This modification allows the 05103AP-10 to interface directly to Campbell Scientific dataloggers.



MODEL 05103-45 WIND MONITOR-ALPINE MODEL



WIND SPEED SPECIFICATION SUMMARY

Range	0 to 60 m/s (130 mph), gust survival 100 m/s (220 mph)
Sensor	14 cm diameter 4-blade helicoid propeller molded of polypropylene
Pitch	29.4 cm air passage per revolution
Distance Constant	2.7 m (8.9 ft.) for 63% recovery
Threshold Sensitivity	1.1 m/s (2.4 mph)
Transducer	Centrally mounted stationary coil, 2K Ohm nominal DC resistance
Transducer Output	AC sine wave signal induced by rotating magnet on propeller shaft. 80 mV p-p at 100 rpm. 8.0 V p-p at 10,000 rpm.
Output Frequency	3 cycles per propeller revolution (0.0980 m/s per Hz)

WIND DIRECTION (AZIMUTH) SPECIFICATION SUMMARY

Range	360° mechanical, 355° electrical (5° open)
Sensor	Balanced vane, 38 cm (15 in) turning radius.
Damping Ratio	0.3
Delay Distance	1.3 m (4.3 ft) for 50% recovery
Threshold Sensitivity	1.1 m/s (2.5 mph) at 10° displacement
Damped Natural Wavelength	7.4 m (24.3 ft)
Undamped Natural Wavelength	7.2 m (23.6 ft)
Transducer	Precision conductive plastic potentiometer, 10K ohm resistance ($\pm 20\%$), 0.25% linearity, life expectancy 50 million revolutions, rated 1 watt at 40° C, 0 watts at 125° C
Transducer Excitation Requirement	Regulated DC voltage, 15 VDC max
Transducer Output	Analog DC voltage proportional to azimuth angle with regulated excitation voltage applied across potentiometer.

GENERAL

Operating Temperature: -50 to 50°C (-58 to 122°F)

INTRODUCTION

The Wind Monitor-Alpine model measures horizontal wind speed and direction. It is rugged and corrosion resistant, yet accurate and light weight. External housing surfaces are coated with a special ice resistant coating to improve performance in harsh alpine conditions. Both the propeller and vertical shafts use stainless steel precision grade ball bearings.

Propeller rotation produces an AC sine wave signal with frequency proportional to wind speed. This AC signal is induced in a stationary coil by a six pole magnet mounted on the propeller shaft. Three complete sine wave cycles are produced for each propeller revolution.

Vane position is transmitted by a 10K ohm precision conductive plastic potentiometer which requires a regulated excitation voltage. With a constant voltage applied to the potentiometer, the output signal is an analog voltage directly proportional to wind direction angle.

The instrument mounts on standard one inch pipe, outside diameter 34 mm (1.34"). An orientation ring is provided so the instrument can be removed for maintenance and reinstalled without loss of wind direction reference. Both the mounting post assembly and the orientation ring are secured to the mounting pipe by stainless steel band clamps. Electrical connections are made in a junction box at the base. A variety of devices are available for signal conditioning, display, and recording of wind speed and direction.

INITIAL CHECKOUT

When the Wind Monitor is unpacked it should be checked carefully for any signs of shipping damage.

Remove the plastic nut on the propeller shaft. Install the propeller on the shaft so the serial number on the propeller faces forward (into the wind). Engage the propeller into the molded ribs on the propeller shaft hub. The instrument is aligned, balanced and fully calibrated before shipment, however, it should be checked both mechanically and electrically before installation. The vane and propeller should easily rotate 360° without friction. Check vane balance by holding the instrument base so the vane surface is horizontal. It should have near neutral torque without any particular tendency to rotate. A slight imbalance will not degrade performance.

The potentiometer requires a stable DC excitation voltage. Do not exceed 15 volts. When the potentiometer wiper is in the 5° deadband region, the output signal is "floating" and may show varying or unpredictable values. To prevent false readings, signal conditioning electronics should clamp the signal to excitation or reference level when this occurs. **NOTE: Young signal conditioning devices clamp the signal to excitation level.** Avoid a short circuit between the wind direction signal line and either the excitation or reference lines. Although there is a 1K ohm current limiting resistor in series with the wiper for protection, damage to the potentiometer may occur if a short circuit condition exists.

Before installation, connect the instrument to an indicator as shown in the wiring diagram and check for proper wind speed and wind direction values. To check wind speed, temporarily remove the propeller and connect the shaft to an Anemometer Drive. Details appear in the CALIBRATION section of this manual.

INSTALLATION

Proper placement of the instrument is very important. Eddies from trees, buildings, or other structures can greatly influence wind speed and wind direction observations. To get meaningful data for most applications locate the instrument well above or upwind from obstructions. As a general rule, the air flow around a structure is disturbed to twice the height of the structure upwind, six times the

height downwind, and up to twice the height of the structure above ground. For some applications it may not be practical or necessary to meet these requirements.

FAILURE TO PROPERLY GROUND THE WIND MONITOR MAY RESULT IN ERRONEOUS SIGNALS OR TRANSDUCER DAMAGE.

Grounding the Wind Monitor is vitally important. Without proper grounding, static electrical charge can build up during certain atmospheric conditions and discharge through the transducers. This discharge can cause erroneous signals or transducer failure. To direct the discharge away from the transducers, the mounting post assembly is made with a special antistatic plastic. It is very important that the mounting post be connected to a good earth ground. There are two ways this may be accomplished. First, the Wind Monitor may be mounted on a metal pipe which is connected to earth ground. The mounting pipe should not be painted where the Wind Monitor is mounted. Towers or masts set in concrete should be connected to one or more grounding rods. If it is difficult to ground the mounting post in this manner, the following method should be used. Inside the junction box the terminal labeled EARTH GND is internally connected to the antistatic mounting post. This terminal should be connected to an earth ground (Refer to wiring diagram).

Initial installation is most easily done with two people; one to adjust the instrument position and the other to observe the indicating device. After initial installation, the instrument can be removed and returned to its mounting without realigning the vane since the orientation ring preserves the wind direction reference. Install the Wind Monitor following these steps:

1. MOUNT WIND MONITOR
 - a) Place orientation ring on mounting post. Do Not tighten band clamp yet.
 - b) Place Wind Monitor on mounting post. Do Not tighten band clamp yet.
2. CONNECT SENSOR CABLE
 - a) Refer to wiring diagram located at back of manual.
3. ALIGN VANE
 - a) Connect instrument to an indicator.
 - b) Choose a known wind direction reference point on the horizon.
 - c) Sighting down instrument centerline, point nose cone at reference point on horizon.
 - d) While holding vane in position, slowly turn base until indicator shows proper value.
 - e) Tighten mounting post band clamp.
 - f) Engage orientation ring indexing pin in notch at instrument base.
 - g) Tighten orientation ring band clamp.

CALIBRATION

The Wind Monitor is fully calibrated before shipment and should require no adjustments. Recalibration may be necessary after some maintenance operations. Periodic calibration checks are desirable and may be necessary where the instrument is used in programs which require auditing of sensor performance.

Accurate wind direction calibration requires a Model 18112 Vane Angle Bench Stand. Begin by connecting the instrument to a signal conditioning circuit which has some method of indicating wind direction value. This may be a display which shows wind direction values in angular degrees or simply a voltmeter monitoring the output. Orient the base so the junction box faces due south. Visually align the vane with the crossmarkings and observe the indicator output. If the vane position and indicator do not agree within 5°, adjust the potentiometer coupling inside the main housing. Details for making this adjustment appear in the MAINTENANCE, POTENTIOMETER REPLACEMENT, outline, step 7.

It is important to note that, while the sensor mechanically rotates through 360°, the full scale wind direction signal from the signal conditioning occurs at 355°. The signal conditioning electronics must be adjusted accordingly. For example, in a circuit where 0 to 1.000 VDC represents 0° to 360°, the output must be adjusted for 0.986 VDC when the instrument is at 355°. ($355^\circ/360^\circ \times 1.000 \text{ volts} = 0.986 \text{ volts}$)

Wind speed calibration is determined by propeller pitch and the output characteristics of the transducer. Calibration formulas showing wind speed vs. propeller rpm and output frequency are included below. Standard accuracy is $\pm 0.3 \text{ m/s}$ (0.6mph). For greater accuracy, the sensor must be individually calibrated in comparison with a wind speed standard. Contact the factory or your supplier to schedule a NIST (National Institute of Standards & Technology) traceable wind tunnel calibration in our facility.

To calibrate wind system electronics using a signal from the instrument, temporarily remove the propeller and connect an Anemometer Drive to the propeller shaft. Apply the appropriate calibration formula to the calibrating motor rpm and adjust the electronics for the proper value. For example, with the propeller shaft turning at 3600 rpm adjust an indicator to display 17.6 meters per second [$3600 \text{ rpm} \times 0.00490 \text{ (m/s)/rpm} = 17.6 \text{ m/s}$]

Details on checking bearing torque, which affects wind speed and direction threshold, appear in the following section.

CALIBRATION FORMULAS

Model 05103 Wind Monitor

WIND SPEED vs PROPELLER RPM

m/s	=	0.00490 x rpm
knots	=	0.00952 x rpm
mph	=	0.01096 x rpm
km/h	=	0.01764 x rpm

WIND SPEED vs OUTPUT FREQUENCY

m/s	=	0.0980 x Hz
knots	=	0.1904 x Hz
mph	=	0.2192 x Hz
km/h	=	0.3528 x Hz

MAINTENANCE

Given proper care, the Wind Monitor should provide years of service. The only components likely to need replacement due to normal wear are the precision ball bearings and the wind direction potentiometer. Only a qualified instrument technician should perform the replacement. If service facilities are not available, return the instrument to the company. Refer to the drawings to become familiar with part names and locations. The asterisk * which appears in the following outlines is a reminder that maximum torque on all set screws is 80 oz-in.

POTENTIOMETER REPLACEMENT

The potentiometer has a life expectancy of fifty million revolutions. As it becomes worn, the element may begin to produce noisy signals or become nonlinear. When signal noise or non-linearity becomes unacceptable, replace the potentiometer. Refer to exploded view drawing and proceed as follows:

1. REMOVE MAIN HOUSING

- a) Unscrew nose cone from main housing. Set o-ring aside for later use.
- b) Remove 4 screws attaching housing.
- c) Gently push main housing latch. (Inside housing)
- d) While pushing latch, lift main housing up and remove it from vertical shaft bearing rotor.

2. UNSOLDER TRANSDUCER WIRES

- Remove junction box cover, exposing circuit board.
- Remove screws holding circuit board.
- Unsolder three potentiometer wires (white, green, black), two wind speed coil wires (red, black) and earth ground wire (red) from board.

3. REMOVE POTENTIOMETER

- Loosen set screw on potentiometer coupling and remove it from potentiometer adjust thumbwheel.
- Loosen set screw on potentiometer adjust thumbwheel and remove it from potentiometer shaft extension.
- Loosen two set screws at base of transducer assembly and remove assembly from vertical shaft.
- Unscrew potentiometer housing from potentiometer mounting & coil assembly.
- Push potentiometer out of potentiometer mounting & coil assembly by applying firm but gentle pressure on potentiometer shaft extension. Set o-ring aside for later use.
- Loosen set screw on potentiometer shaft extension and remove it from potentiometer shaft.

4. INSTALL NEW POTENTIOMETER

- Place potentiometer shaft extension with o-ring on new potentiometer (Gap 0.040") and tighten set screw*. Regrease o-ring if necessary.
- Push new potentiometer into potentiometer mounting & coil assembly.
- Feed potentiometer and coil wires through hole in bottom of potentiometer housing.
- Screw potentiometer housing onto potentiometer mounting & coil assembly.
- Gently pull transducer wires through bottom of potentiometer housing to take up any slack. Apply a small amount of silicone sealant around hole.
- Install transducer assembly on vertical shaft allowing 0.5 mm (0.020") clearance from vertical bearing. Tighten set screws* at bottom of transducer assembly.
- Place potentiometer adjust thumbwheel on potentiometer shaft extension and tighten set screw*.
- Place potentiometer coupling on potentiometer adjust thumbwheel. Do Not tighten set screw yet.

5. RECONNECT TRANSDUCER WIRES

- Using needle-nose pliers or a paper clip bent to form a small hook, gently pull transducer wires through hole in junction box.
- Solder wires to circuit board according to wiring diagram. Observe color code.
- Secure circuit board in junction box using two screws removed in step 2b. Do not overtighten.

6. REPLACE MAIN HOUSING

- Place main housing over vertical shaft bearing rotor. Be careful to align indexing key and channel in these two assemblies.
- Place main housing over vertical shaft bearing rotor until potentiometer coupling is near top of main housing.
- Turn potentiometer adjust thumbwheel until potentiometer coupling is oriented to engage ridge in top of main housing. Set screw on potentiometer coupling should be facing the front opening.
- With potentiometer coupling properly oriented, continue pushing main housing onto vertical shaft bearing rotor until main housing latch locks into position with a "click".
- Replace 4 screws in housing skirt.

7. ALIGN VANE

- Connect excitation voltage and signal conditioning electronics to terminal strip according to wiring diagram.
- With mounting post held in position so junction box is facing due south, orient vane to a known angular reference. Details appear in CALIBRATION section.

- Reach in through front of main housing and turn potentiometer adjust thumbwheel until signal conditioning system indicates proper value.
- Tighten set screw* on potentiometer coupling.

8. REPLACE NOSE CONE

- Screw nose cone into main housing until o-ring seal is seated. Be certain threads are properly engaged to avoid cross-threading.

FLANGE BEARING REPLACEMENT

If anemometer bearings become noisy or wind speed threshold increases above an acceptable level, bearings may need replacement. Check anemometer bearing condition using a Model 18310 Propeller Torque Disc. If needed, bearings are replaced as follows.

1. REMOVE OLD BEARINGS

- Unscrew nose cone. Set o-ring aside for later use.
- Loosen set screw on magnet shaft collar and remove magnet.
- Slide propeller shaft out of nose cone assembly.
- Remove front bearing cap which covers front bearing.
- Remove both front and rear bearings from nose cone assembly. Insert edge of a pocket knife under bearing flange and lift it out.

2. INSTALL NEW BEARINGS

- Insert new front and rear bearings into nose cone.
- Replace front bearing cap.
- Carefully slide propeller shaft thru bearings.
- Place magnet on propeller shaft allowing 0.5 mm (0.020") clearance from rear bearing.
- Tighten set screw* on magnet shaft collar.
- Screw nose cone into main housing until o-ring seal is seated. Be certain threads are properly engaged to avoid cross-threading.

VERTICAL SHAFT BEARING REPLACEMENT

Vertical shaft bearings are much larger than the anemometer bearings. Ordinarily, these bearings require replacement less frequently than anemometer bearings. Check bearing condition using a Model 18331 Vane Torque Gauge.

Since this procedure is similar to POTENTIOMETER REPLACEMENT, only the major steps are listed here.

1. REMOVE MAIN HOUSING

2. UNSOLDER TRANSDUCER WIRES AND REMOVE TRANSDUCER ASSEMBLY

Loosen set screws at base of transducer assembly and remove entire assembly from vertical shaft.

3. REMOVE VERTICAL SHAFT BEARING ROTOR by sliding it upward off vertical shaft.

4. REMOVE OLD VERTICAL BEARINGS AND INSTALL NEW BEARINGS. When inserting new bearings, be careful not to apply pressure to bearing shields.

5. REPLACE VERTICAL SHAFT BEARING ROTOR.

6. REPLACE TRANSDUCER & RECONNECT WIRES

7. REPLACE MAIN HOUSING

8. ALIGN VANE

9. REPLACE NOSE CONE

WARRANTY

This product is warranted to be free of defects in materials and construction for a period of 12 months from date of initial purchase. Liability is limited to repair or replacement of defective item. A copy of the warranty policy may be obtained from R. M. Young Company.

*Max set screw torque 80 oz-in

CE COMPLIANCE

This product has been tested and shown to comply with European CE requirements for the EMC Directive (see Declaration of Conformity below). Please note that shielded cable must be used.

Declaration of Conformity

Application of Council Directives:

89/336/EEC

Standards to which Conformity is Declared:

EN 50082-1(IEC 801-2,3,4)

Manufacturer's Name and Address:

R. M. Young Company
Traverse City, MI, 49686, USA

Importer's Name and Address:

See Shipper or Invoice

Type of Equipment:

Meteorological Instruments

Model Number / Year of Manufacture:

05103/1996

I, the undersigned, hereby declare that the equipment specified conforms to the above Directives and Standards.

Place / Date:


Traverse City, Michigan, USA / February 19, 1996



David Poinsett
R & D Manager, R. M. Young Company



MODEL 05103 WIND MONITOR
MODEL 05305 WIND MONITOR-AQ
MODEL 05701 WIND MONITOR-RE




MODEL 05103	DWG A	PRD 02-98
WIND MONITOR	DWN JMT	DWG 05-02
CABLE & WIRING DIAGRAM	CHK <i>X.C.</i>	W05103
R.M. YOUNG CO. TRAVERSE CITY, MI 49686 U.S.A. 231-946-3980		



WIND MONITOR SECTION VIEW

BEARING REPLACEMENT/POTENTIOMETER ADJUSTMENT




NOTES:

- TO REMOVE MAIN HOUSING – UNTHREAD NOSE CONE ASSEMBLY, REMOVE HOUSING SCREWS, PUSH MAIN HOUSING LATCH, LIFT UPWARD.
- TO REPLACE ANEMOMETER FLANGE BEARINGS – UNTHREAD NOSE CONE, REMOVE SIX POLE MAGNET, SLIDE PROPELLER SHAFT AND HUB ASSEMBLY FORWARD, REMOVE FRONT BEARING CAP, AND FLANGE BEARINGS. AFTER BEARING REPLACEMENT, SET BEARING GAP TO 0.5mm (0.020")
- TO ADJUST POTENTIOMETER OUTPUT SIGNAL – REMOVE NOSE CONE, LOOSEN SET SCREW IN POTENTIOMETER COUPLING, ADJUST OUTPUT SIGNAL BY MEANS OF POTENTIOMETER ADJUSTMENT THUMBWHEEL, RE-TIGHTEN SET SCREW.

MODEL 05103-58 WIND MONITOR	DWG A	PRD 06-01
SECTION VIEW – BEARING REPLACEMENT/ POTENTIOMETER ADJUSTMENT	DWN JMT	DWG 06-01
	CHK <i>X.C.</i>	M05103-58
R.M. YOUNG CO. TRAVERSE CITY, MI 49686 U.S.A. 231-946-3980		



MODEL 05103-45 WIND MONITOR-ALPINE



MODIFICATIONS TO STANDARD 05103:

1. TAIL ASSY GLUED TO MAIN HOUSING
2. SCREWS SECURING MAIN HOUSING TO ROTOR
3. SCREW SECURING VERTICAL SHAFT TO MTG. POST
4. ICEPHOBIC COATING (WEARLON SUBER FI-ICE) ON MAIN COMPONENT PARTS

MODEL 05103-45 WIND MONITOR-ALPINE	DWG B	PRD 10/03
GENERAL ASSEMBLY & REPLACEMENT PARTS	DWN JMT	DWG 10/03
	CHK <i>[Signature]</i>	E05103-45
R.M. YOUNG CO. TRAVERSE CITY, MI 49686 U.S.A. 231-946-3980		