

# Wind Sentry Series

03002, 03101, and 03301



# Guarantee

---

This equipment is guaranteed against defects in materials and workmanship. We will repair or replace products which prove to be defective during the guarantee period as detailed on your invoice, provided they are returned to us prepaid. The guarantee will not apply to:

- Equipment which has been modified or altered in any way without the written permission of Campbell Scientific
- Batteries
- Any product which has been subjected to misuse, neglect, acts of God or damage in transit.

Campbell Scientific will return guaranteed equipment by surface carrier prepaid. Campbell Scientific will not reimburse the claimant for costs incurred in removing and/or reinstalling equipment. This guarantee and the Company's obligation thereunder is in lieu of all other guarantees, expressed or implied, including those of suitability and fitness for a particular purpose. Campbell Scientific is not liable for consequential damage.

Please inform us before returning equipment and obtain a Repair Reference Number whether the repair is under guarantee or not. Please state the faults as clearly as possible, and if the product is out of the guarantee period it should be accompanied by a purchase order. Quotations for repairs can be given on request. It is the policy of Campbell Scientific to protect the health of its employees and provide a safe working environment, in support of this policy a "Declaration of Hazardous Material and Decontamination" form will be issued for completion.

When returning equipment, the Repair Reference Number must be clearly marked on the outside of the package. Complete the "Declaration of Hazardous Material and Decontamination" form and ensure a completed copy is returned with your goods. Please note your Repair may not be processed if you do not include a copy of this form and Campbell Scientific Ltd reserves the right to return goods at the customers' expense.

Note that goods sent air freight are subject to Customs clearance fees which Campbell Scientific will charge to customers. In many cases, these charges are greater than the cost of the repair.



Campbell Scientific Ltd,  
80 Hathern Road,  
Shepshed, Loughborough, LE12 9GX, UK  
Tel: +44 (0) 1509 601141  
Fax: +44 (0) 1509 270924  
Email: [support@campbellsci.co.uk](mailto:support@campbellsci.co.uk)  
[www.campbellsci.co.uk](http://www.campbellsci.co.uk)

# About this manual

---

## Some useful conversion factors:

**Area:** 1 in<sup>2</sup> (square inch) = 645 mm<sup>2</sup>

**Length:** 1 in. (inch) = 25.4 mm  
1 ft (foot) = 304.8 mm  
1 yard = 0.914 m  
1 mile = 1.609 km

**Mass:** 1 oz. (ounce) = 28.35 g  
1 lb (pound weight) = 0.454 kg

**Pressure:** 1 psi (lb/in<sup>2</sup>) = 68.95 mb

**Volume:** 1 UK pint = 568.3 ml  
1 UK gallon = 4.546 litres  
1 US gallon = 3.785 litres

## Recycling information



At the end of this product's life it should not be put in commercial or domestic refuse but sent for recycling. Any batteries contained within the product or used during the products life should be removed from the product and also be sent to an appropriate recycling facility.

Campbell Scientific Ltd can advise on the recycling of the equipment and in some cases arrange collection and the correct disposal of it, although charges may apply for some items or territories.

For further advice or support, please contact Campbell Scientific Ltd, or your local agent.



Campbell Scientific Ltd, Campbell Park, 80 Hathern Road, Shepshed, Loughborough, LE12 9GX, UK  
Tel: +44 (0) 1509 601141 Fax: +44 (0) 1509 270924  
Email: [support@campbellsci.co.uk](mailto:support@campbellsci.co.uk)  
[www.campbellsci.co.uk](http://www.campbellsci.co.uk)

# Safety

---

DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND **TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.** FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at [www.campbellsci.eu](http://www.campbellsci.eu) or by telephoning +44(0) 1509 828 888 (UK). You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified engineer. If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

## General

- Prior to performing site or installation work, obtain required approvals and permits. Comply with all governing structure-height regulations, such as those of the FAA in the USA.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a **hardhat** and **eye protection**, and take **other appropriate safety precautions** while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

## Utility and Electrical

- **You can be killed** or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in **contact with overhead or underground utility lines**.
- Maintain a distance of at least one-and-one-half times structure height, or 20 feet, or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.

## Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

## Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CUSTOMER ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.

# Table of contents

---

<b>1. Introduction</b>	<b>1</b>
<b>2. Precautions</b>	<b>1</b>
<b>3. Initial inspection</b>	<b>1</b>
<b>4. QuickStart</b>	<b>2</b>
<b>5. Overview</b>	<b>4</b>
<b>6. Specifications</b>	<b>5</b>
6.1 Wind speed (anemometer)	5
6.2 Wind direction (vane)	6
6.3 Wind sentry assembly	7
<b>7. Installation</b>	<b>7</b>
7.1 Wiring	7
7.2 Programming	9
7.2.1 Wind speed	9
7.2.2 Wind direction	10
7.2.3 WindVector processing instruction	11
7.3 Siting	11
7.4 Assembly and mounting the 03002	11
7.5 Mounting the 03101 anemometer to a crossarm	13
7.6 Mounting the 03301 vane	14
<b>8. Sensor maintenance</b>	<b>14</b>
<b>9. Troubleshooting</b>	<b>15</b>
9.1 Wind direction	15
9.2 Wind speed	16
<b>10. References</b>	<b>16</b>
<b>Appendix A. Importing Short Cut code into CRBasic Editor</b>	<b>17</b>
<b>Appendix B. Example program</b>	<b>18</b>
<b>Appendix C. Wind direction sensor orientation</b>	<b>20</b>
C.1 Determining true north and sensor orientation	20


<b>Appendix D. Wind direction measurement theory .....</b>	<b>23</b>
--	-----------

# 1. Introduction

---

The 03002 Wind Sentry Set measures both wind speed and direction. It consists of a 3-cup anemometer and a wind vane mounted on a small crossarm. The anemometer and vane may be purchased separately.

## NOTE:

This manual provides information only for CRBasic data loggers. For retired Edlog data logger support, see an older manual at [www.campbellsci.com/old-manuals](http://www.campbellsci.com/old-manuals) .

## 2. Precautions

---

- READ AND UNDERSTAND the [Safety](#) section at the front of this manual.
- The 03002 is a precision instrument. Please handle it with care.
- Do not use cable lengths greater than 30 m (9 ft) in electrically noisy environments.
- The black outer jacket of the cable is Santoprene® rubber. This compound was chosen for its resistance to temperature extremes, moisture, and ultraviolet (UV) degradation. However, this jacket will support combustion in air. It is rated as slow burning when tested according to U.L. 94 H.B. and will pass FMVSS302. Local fire codes may preclude its use inside buildings.
- Wire color and functions of sensors purchased through Campbell Scientific may not correspond with the wire colours and functions given in the manufacturer's manual. To ensure proper function, follow the wiring provided in **Short Cut** or in the Campbell Scientific manual.

## 3. Initial inspection



---

- Upon receipt of the 03002, inspect the packaging and contents for damage. File damage claims with the shipping company. Immediately check package contents against the shipping documentation. Contact Campbell Scientific about any discrepancies.

- The model number and cable length are printed on a label at the connection end of the cable. Check this information against the shipping documents to ensure the expected product and cable length are received.
- The sensor is shipped with the cup wheel unattached to the anemometer shaft. Refer to the [Assembly and mounting the 03002](#) (p. 11) section.


## 4. QuickStart

A video that describes data logger programming using *Short Cut* is available at:

[www.campbellsci.eu/videos/cr1000x-datalogger-getting-started-program-part-3](http://www.campbellsci.eu/videos/cr1000x-datalogger-getting-started-program-part-3).  *Short Cut* is an easy way to program your data logger to measure this sensor and assign data logger wiring terminals. *Short Cut* is available as a download on [www.campbellsci.eu](http://www.campbellsci.eu).  It is included in installations of *LoggerNet*, *RTDAQ*, or *PC400*.

The following procedure shows using Short Cut to program the 03002.

1. Open *Short Cut* and create a new program.
2. Double-click the data logger model.
3. In the **Available Sensors and Devices** box, type 03002 or find the sensor in the **Sensors > Meteorological > Wind Speed & Direction** folder. Double-click **03002 Wind Speed & Direction Sensor**. The wind speed defaults to metres/second. This can be changed by clicking the **Wind Speed** box and selecting one of the other options.





- Click on the **Wiring** tab to see how the sensor is to be wired to the data logger. Click **OK** after wiring the sensor.

The screenshot shows the 'Properties' dialog box with the 'Wiring' tab selected. It displays the wiring configuration for the CR1000X Series sensor. The sensor is identified as '03002' and 'CR1000X Series'. The wiring table shows the following connections:

Color	Terminal
Green	1H
Black	⏏ (Ground)
Clear	⏏ (Ground)
White	⏏ (Ground)
Red	P1
Blue	VX1

Below the table, it says: 'Click a CR1000X Series terminal name to change a wire's location.'

At the bottom, there is a section for the sensor's units: 'RM Young 03002-5 Wind Speed & Direction Sensor', 'Units for Wind Speed: meters/second, kilometers/hour, miles/hour, knots', and 'Units for Wind Direction: degrees'.

Buttons at the bottom: OK, Cancel, Help.

- Select any other sensors you have, then finish the remaining *Short Cut* steps to complete the program.
- In **Output Setup**, enter the scan rate and **Data Output Storage Interval**.

The screenshot shows the 'Output Setup' dialog box. The 'Progress' list on the left includes: 1. New/Open, 2. Datalogger, 3. Sensors, 4. Output Setup (selected), 5. Adv. Outputs, 6. Output Select, 7. Finish.

The 'Wiring' section on the left includes: Wiring Diagram, Wiring Text.


The main area contains the following settings:

- 'How often should the CR1000X Series measure its sensor(s)?': 5 (highlighted with a red box), Seconds.
- 'Data is processed by the datalogger and then stored in an output table. Two tables are defined by default; up to 10 tables can be added.' (with an 'Add New Table' button).
- 'Table Name': Daily (highlighted with a red box).
- 'Data Output Storage Interval': 1440 (highlighted with a red box), Minutes.
- 'Advanced Outputs (all tables)': unchecked.

At the bottom, there is a help icon and a text box: 'Specify how often measurements are to be made and how often outputs are to be stored. Note that multiple output intervals can be specified, one for each output table. By default, an output table is set up to send data to memory based on time. Select the Advanced Output option to send data to memory based on one or more of the following conditions: time, the state of a flag, or the value of a measurement.'

Buttons at the bottom: Previous, Next, Finish, Help.

## 7. Select the output options.



- Click **Finish** and save the program. Send the program to the data logger if the data logger is connected to the computer.
- If the sensor is connected to the data logger, check the output of the sensor in the data display in *LoggerNet*, *RTDAQ*, or *PC400* to make sure it is making reasonable measurements.

# 5. Overview

The 03002 Wind Sentry Set is used to measure horizontal wind speed and direction.

Wind speed is measured with a three-cup anemometer. Rotation of the cup wheel produces an ac sine wave voltage with frequency proportional to wind speed. This is a special version of the 03102 built for Campbell Scientific by R. M. Young that has shielded bearings rather than sealed bearings. The shielded bearings provide a lower starting threshold than sealed bearings.

Vane position is transmitted by a 10 k $\Omega$  potentiometer. With a precision excitation voltage applied, the output voltage is proportional to wind direction.

The 03101 Anemometer and 03301 Vane can be ordered as separate sensors, which are also covered in this manual. These two sensors combined differ from the 03002 only by the absence of a junction box. The R. M. Young 03002 manual (see [References](#) [p. 16]) includes additional information on the operating principles, installation, and maintenance of the sensor.

Cable length for the Wind Sentry is specified when the sensor is ordered. [Table 5-1](#) (p. 5) gives the recommended cable length for mounting the sensor at the top of the tripod/tower with a CM200-series crossarm.

Table 5-1: Recommended cable lengths						
CM106B	CM110	CM115	CM120	UT10	UT20	UT30
4.2 m (14 ft)	4.2 m (14 ft)	5.8 m (19 ft)	7.3 m (24 ft)	4.2 m (14 ft)	7.3 m (24 ft)	11.3 m (37 ft)

**NOTE:**  
Maximum cable length is 304.8 m (1000 ft).

**CAUTION:**  
Do not use cable lengths greater than 30 m (9 ft) in electrically noisy environments.

**Features:**

- Designed for continuous, long term, unattended operation in adverse conditions
- Small size, simplicity, and rugged construction provide a quality instrument for a modest price
- Ideal for wind profile studies
- Campbell Scientific version uses shielded bearings, which lowers the anemometer starting threshold
- Compatible with the LLAC4 4-channel Low Level AC Conversion Module, which increases the number of anemometers one data logger can measure
- Compatible with Campbell Scientific CRBasic data loggers: CR6, CR1000X, CR800 series, CR350 series, CR300 series, CR3000, and CR1000

## 6. Specifications

### 6.1 Wind speed (anemometer)

**Range:** 0 to 50 m/s (112 mph), gust survival 60 m/s (134 mph)

**Sensor:** 12 cm diameter cup wheel assembly, 40 mm diameter hemispherical cups

Accuracy:	±0.5 m/s (1.1 mph)
Turning factor:	75 cm (2.5 ft)
Distance constant (63% recovery):	2.3 m (7.5 ft)
Threshold:	0.5 m/s (1.1 mph)
Transducer:	Stationary coil, 1300-ohm nominal resistance
Output:	AC sine wave signal induced by rotating magnet on cup wheel shaft 100 mV peak-to-peak at 60 rpm; 6 V peak-to-peak at 3600 rpm
Output frequency:	1 cycle per cup wheel revolution; 0.75 m/s per Hz
Cup wheel diameter:	12 cm (4.7 in)
Weight:	113 g (4 oz)

## 6.2 Wind direction (vane)

Range:	360° mechanical, 352° electrical (8° open)
Sensor:	Balanced vane, 16 cm turning radius
Settling time:	20 ms
Damping ratio:	0.2
Delay distance (50% recovery):	0.5 m (1.6 ft)
Threshold:	0.8 m/s (1.8 mph) at 10° displacement (1.8 m/s (4 mph) at 5° displacement)
Transducer:	Precision conductive plastic potentiometer; 10 kΩ resistance; 1.0% linearity; life expectancy 50 million revolutions  Rated 1 W at 40 °C, 0 W at 125 °C
Transducer excitation	
Requirement:	Regulated DC voltage, 15 VDC max
Output:	Analogue DC voltage proportional to wind direction angle with regulated excitation voltage supplied by the data logger
Vane length:	22 cm (8.7 in)
Vane weight:	170 g (6 oz)

## 6.3 Wind sentry assembly

Operating temperature: –50 to 50 °C assuming non-riming conditions

Overall height: 32 cm (12.6 in)

Crossarm length: 40 cm (15.7 in) between instruments (center-to-center)

Mounting diameter: 34 mm (1.34 in), mounts on standard 1 inch IPS pipe

# 7. Installation

If you are programming your data logger with *Short Cut*, skip [Wiring](#) (p. 7) and [Programming](#) (p. 9). *Short Cut* does this work for you. See [QuickStart](#) (p. 2) for a *Short Cut* tutorial.

## 7.1 Wiring

Connections to CRBasic data loggers are given in [Table 7-1](#) (p. 7), [Table 7-2](#) (p. 8), and [Table 7-3](#) (p. 8). When *Short Cut* software is used to create the data logger program, the sensor is wired to the terminals shown in the wiring diagram created by *Short Cut*.

Table 7-1: 03002 Wind Sentry Set wire colour, wire function, and data logger connection		
Wire colour	Wire function	Data logger connection terminal
Red	WS signal	U configured for pulse input <sup>1</sup> , P (pulse input), or P_LL (pulse, low-level ac)
Black	WS signal reference	⏏
Green	WD signal	U configured for single-ended analogue input <sup>1</sup> , SE (single-ended, analogue input)
Blue	WD voltage excitation	U configured for voltage excitation <sup>1</sup> , EX, or VX (voltage excitation)
White	WD signal reference	⏏ (analogue ground)
Clear	Shield	⏏ (analogue ground)
<sup>1</sup> U terminals are automatically configured by the measurement instruction.		

**Table 7-2: 03101 anemometer wire colour, wire function, and data logger connection**


Wire colour	Wire function	Data logger connection terminal
Black	WS signal	U configured for pulse input <sup>1</sup> , P (pulse input), or P_LL (pulse, low-level ac)
White	WS signal reference	⏏
Clear	Shield	⏏ (analogue ground)

<sup>1</sup>U terminals are automatically configured by the measurement instruction.


**Table 7-3: 03301 vane wire colour, wire function, and data logger connection**

Wire colour	Wire function	Data logger connection terminal
Red	WD signal	U configured for single-ended analogue input <sup>1</sup> , SE (single-ended, analogue input)
Black	WD voltage excitation	U configured for voltage excitation <sup>1</sup> , EX, or VX (voltage excitation)
White	WD signal reference	⏏ (analogue ground)
Clear	Shield	⏏ (analogue ground)

<sup>1</sup>U terminals are automatically configured by the measurement instruction.



**Wind Speed 03101**




**Wind Direction 03301**

## 7.2 Programming

**Short Cut** is the best source for up-to-date data logger programming code. If your data acquisition requirements are simple and you are connecting the sensor to a pulse terminal, you can probably create and maintain a data logger program exclusively by using **Short Cut**. If your data acquisition needs are more complex, the files that **Short Cut** creates are a great source for programming code to start a new program or add to an existing custom program.

### NOTE:

**Short Cut** cannot edit programs after they are imported and edited in **CRBasic Editor**.

A **Short Cut** tutorial is available in [QuickStart](#) (p. 2). If you wish to import **Short Cut** code into **CRBasic Editor** to create or add to a customized program, follow the procedure in [Importing Short Cut code into CRBasic Editor](#) (p. 17). Programming basics for CRBasic data loggers are provided in the following sections. A complete program is provided in [Example program](#) (p. 18). Programming basics and programming examples for Edlog data loggers are provided at [www.campbellsci.com/old-manuals](http://www.campbellsci.com/old-manuals) .

### 7.2.1 Wind speed

Wind speed is measured by using the **PulseCount()** instruction. Syntax of the **PulseCount()** instruction is:

**PulseCount**(Dest, Reps, PChan, PConfig, POption, Mult, Offset)

Set the **PConfig** parameter to **Low Level AC** and the **POption** parameter to **Frequency**.

The expression for wind speed (U) is:

$$U = Mx + B$$

where

M = multiplier

x = number of pulses per second (Hertz)

B = offset

[Table 7-4](#) (p. 10) lists the multipliers to obtain miles/hour or metres/second when the measurement instruction is configured to output Hz.

Table 7-4: Wind speed multiplier (with pulse terminal configuration set to Low Level AC, output "Hz")		
Model	Metres/second	Miles/hour
03002 / 03101	M = 0.750 Off = 0.2	M = 1.677 Off = 0.4
*When the pulse terminal configuration is set to Low Level AC, output "counts", the multiplier above is divided by the execution interval in seconds.		

## 7.2.2 Wind direction

The wind vane is coupled to a 10 k $\Omega$  potentiometer, which has a 8-degree electrical dead band between 352 and 360 degrees. A 1 M $\Omega$  resistor between the signal and ground pulls the signal to 0 mV (0 degrees) when wind direction is in the dead band (between 352 and 360 degrees).

Wind direction is measured by the [BRHa1f\(\)](#) instruction.

Some CRBasic measurement sequences can cause the measurement of the wind direction to return a negative wind direction ( $-30^\circ$ ) while in the dead band. To overcome this problem, all program examples use a delay of 20 ms (20,000  $\mu$ s) and set any negative wind direction values to 0.0: If WindDir < 0, then WindDir = 0.0.

The excitation voltage, range codes, and multipliers for the different data logger types are listed in [Table 7-5](#) (p. 10). [Wind direction measurement theory](#) (p. 23) has additional information on the [BRHa1f\(\)](#) measurement instruction.

Table 7-5: Parameters for wind direction					
	CR300 Series	CR800, CR850, CR1000	CR1000X	CR6	CR3000
Measurement range	mV2500	mV2500	mV5000	mV5000	mV5000
Excitation voltage	2500 mV	2500 mV	2500 mV	2500 mV	5000 mV
Reverse excitation	NA	True	True	True	True
Delay or settling time	20000 $\mu$ s	20000 $\mu$ s	20000 $\mu$ s	20000 $\mu$ s	20000 $\mu$ s
Multiplier	352	352	352	352	352
Offset	0	0	0	0	0



## 7.2.3 WindVector processing instruction

The **WindVector** output is used to process and store mean wind speed, unit vector mean wind direction, and standard deviation of the wind direction (optional) by using the measured wind speed and direction samples.

## 7.3 Siting

Locate wind sensors away from obstructions such as trees or buildings. Generally, there should be a horizontal distance of at least ten times the height of the obstruction between the wind monitor and the obstruction. If the sensors need to be mounted on a roof, the height of the sensors above the roof, should be at least 1.5 times the height of the building. See [References](#) (p. 16) for a list of references that discuss siting wind speed and direction sensors.

## 7.4 Assembly and mounting the 03002


Materials required:

- 5/64 inch hex key wrench
- 1/2 inch open end wrench
- Compass and declination angle for the site (see [Wind direction sensor orientation](#) [p. 20])
- Small screw driver provided with data logger
- UV resistant cable ties
- 6 to 10 inch torpedo level
- Unthreaded aluminium pipe, 1-inch IPS, 12-inch length (shipped with the sensor)
- 1-inch-by-1-inch Nu-Rail crossover fitting
- Cup wheel
- 03002 assembly

The following procedure is for assembling the sensor and mounting it to a crossarm.

1. Install the cup wheel to the anemometer shaft using the hex key wrench provided with the sensor.

2. Mount a crossarm to a tripod or tower.



*Figure 7-1. 03002 mounted to a crossarm with 1 x 1 inch Nu-Rail fitting*

3. If a pyranometer is also being mounted on the crossarm, orient the crossarm north-south with the Nu-Rail on the end farthest from the equator. Otherwise, the crossarm may be oriented north-south, east west, or any other angle desired. [Wind direction sensor orientation](#) (p. 20) contains detailed information on determining true north by using a compass and the magnetic declination for the site.
4. Secure the 12-inch aluminium pipe to the Nu-Rail fitting.
5. Place the 03002 on the pipe, and orient the sensor crossarm North-South with the vane to the North.
6. Tighten the mounting post band clamp. Final sensor orientation is done after the data logger has been programmed to measure wind direction as described in [Wind direction sensor orientation](#) (p. 20).
7. Use the torpedo level to ensure that the sensor is level.
8. Route the sensor cable along the underside of the crossarm to the tripod or tower, and to the instrument enclosure.
9. Secure the cable to the crossarm and tripod or tower by using cable ties.

The 03002 can also use a CM221 Right-Angle Mounting Kit or CM216 Sensor Mounting Kit; see the following figures. The CM221 uses U-bolts to secure the sensor to a crossarm. The CM216 mounts the wind monitor on top of a CM106B, CM110, CM115, or CM120 tripod. The CM216 extends 10 cm (4 in) above the mast of the tripod.



*Figure 7-2. CM221 Right-Angle Mounting Kit*



*Figure 7-3. The CM216 allows an 03002 or 03101 to mount atop a tripod mast*

## 7.5 Mounting the 03101 anemometer to a crossarm

1. Install the cup wheel to the anemometer shaft using the hex key wrench provided with the sensor.
2. Mount a crossarm to a tripod or tower.
3. Secure the 3/4-inch IPS, 10-inch-long, threaded aluminium pipe to the CM220 mount or 3/4 x 1 inch Nu-Rail fitting ([Figure 7-4](#) [p. 14]).
4. Place the 03101 on the pipe.
5. Route the sensor cable along the underside of the crossarm to the tripod or tower, and to the instrument enclosure.
6. Secure the cable to the crossarm and tripod or tower by using cable ties.




Figure 7-4. 03101 mounted to a crossarm via a 3/4 x 1 inch Nu-Rail fitting


## 7.6 Mounting the 03301 vane

The 03301 wind vane has three mounting options:

- No Mounting (option –NM) is used when the 03301 will be replacing an existing 03301 within a Wind Sentry Set.
- Pipe Offset Mount (option –P) is used when the 03301 will be deployed on its own next to an anemometer that already has its own mount. With this option, the 03301 mounts to a crossarm using the CM220 mount or 3/4 x 1 inch Nu-Rail fitting.
- 03101 Conversion Kit (option –SM) is used when the 03301 will be mounted next to a previously purchased 03101 Anemometer (Wind Sentry Anemometer). This conversion kit includes the crossarm and other hardware to mount both sensors to a common crossarm as if they had been purchased originally as a complete Wind Sentry Set.


## 8. Sensor maintenance

Every month do a visual/audio inspection of the anemometer at low wind speeds. Verify that the propeller and wind vane bearing rotate freely. Inspect the sensor for physical damage.

Replace the anemometer bearings when they become noisy, or the wind speed threshold increases above an acceptable level. The condition of the bearings can be checked by using the Propeller Torque Disc as described in the R. M. Young manual (see [www.youngusa.com/product-category/wind-sensors-accessories](http://www.youngusa.com/product-category/wind-sensors-accessories) )

The potentiometer has a life expectancy of fifty million revolutions. As it becomes worn, the element can produce noisy signals or become non-linear. Replace the potentiometer when the noise or non-linearity becomes unacceptable.

**NOTE:**

Campbell Scientific recommends factory replacement of the bearings and potentiometer. Refer to the [About this manual](#) page of this document for the procedure of acquiring a Returned Materials Authorization (RMA). Mechanically-adept users may choose to replace the bearings or potentiometer themselves. Instructions for replacing the bearings and potentiometer are given in R. M. Young manuals  ([www.youngusa.com](http://www.youngusa.com))

## 9. Troubleshooting

---

### 9.1 Wind direction

Symptom: NAN, -9999, or no change in direction

1. Check that the sensor is wired to the excitation and single-ended terminal specified by the measurement instruction.
2. Verify that the excitation voltage and range code are correct for the data logger type.
3. Disconnect the sensor from the data logger and use an ohmmeter to check the potentiometer. Resistance should be about 10 k $\Omega$  between the wind direction signal and reference wires. The resistance between either the black/red or white/red wires for the 03301 and blue/green or white/green wires for the 03002 should vary from 1 k $\Omega$  to 11 k $\Omega$  depending on vane position. Resistance when the vane is in the 8-degree dead band should be about 1 M $\Omega$ .

Symptom: Incorrect wind direction

1. Verify that the excitation voltage, range code, multiplier and offset parameters are correct for the data logger type.
2. Check orientation of sensor as described in [Assembly and mounting the 03002](#) (p. 11).


## 9.2 Wind speed

Symptom: No wind speed

1. Check that the sensor is wired to the pulse terminal specified by the pulse count instruction.
2. Disconnect the sensor from the data logger and use an ohmmeter to check the coil. The resistance between the white and black wires for the 03101 and black and red wires for the 03002 should be a nominal 1300  $\Omega$ . Infinite resistance indicates an open coil; low resistance indicates a shorted coil.
3. Verify that the configuration code, and multiplier and offset parameters for the pulse count instruction are correct for the data logger type.

## 10. References

---

Component part numbers and other information is available in the R. M. Young 03002 manual available at [www.campbellsci.eu/03002-wind-sentry](http://www.campbellsci.eu/03002-wind-sentry).  Because Campbell Scientific cables the sensor, the wiring in the R. M. Young manual will be different than the wiring listed in this manual.

The following references give detailed information on siting wind speed and wind direction sensors.

EPA, 1989: *Quality Assurance Handbook for Air Pollution Measurements System*, Office of Research and Development, Research Triangle Park, NC, 27711.

EPA, 1987: *On-Site Meteorological Program Guidance for Regulatory Modeling Applications*, EPA-450/4-87-013, Office of Air Quality Planning and Standards, Research Triangle Park, NC 27711.

The State Climatologist, 1985: *Publication of the American Association of State Climatologists: Height and Exposure Standards*, for Sensors on Automated Weather Stations, vol. 9, No. 4.

WMO, 1983: *Guide to Meteorological Instruments and Methods of Observation*, World Meteorological Organization, No. 8, 5th edition, Geneva, Switzerland.

# Appendix A. Importing *Short Cut* code into *CRBasic Editor*

---


*Short Cut* creates a .DEF file that contains wiring information and a program file that can be imported into the *CRBasic Editor*. By default, these files reside in the C:\campbellsci\SCWin folder.

Import *Short Cut* program file and wiring information into *CRBasic Editor*:

1. Create the *Short Cut* program. After saving the *Short Cut* program, click the **Advanced** tab then the **CRBasic Editor** button. A program file with a generic name will open in CRBasic. Provide a meaningful name and save the CRBasic program. This program can now be edited for additional refinement.

**NOTE:**

Once the file is edited with *CRBasic Editor*, *Short Cut* can no longer be used to edit the program it created.

2. To add the *Short Cut* wiring information into the new CRBasic program, open the .DEF file located in the C:\campbellsci\SCWin folder, and copy the wiring information, which is at the beginning of the .DEF file.
3. Go into the CRBasic program and paste the wiring information into it.
4. In the CRBasic program, highlight the wiring information, right-click, and select **Comment Block**. This adds an apostrophe (') to the beginning of each of the highlighted lines, which instructs the data logger compiler to ignore those lines when compiling. The **Comment Block** feature is demonstrated at about 5:10 in the [CRBasic | Features](#) video .

# Appendix B. Example program

---

This example program measures the 03002 every 5 seconds, and stores mean wind speed, unit vector mean direction, and standard deviation of the direction every 60 minutes. Wiring for the example is given in [Table B-1](#) (p. 18).

Table B-1: Wiring for example program		
Colour	Wire label	CR1000X
Red	WS Signal	P1
Black	WS Reference	⏏
Clear	Shield	⏏
Green	WD Signal	SE 1
Blue	WD Volt Excit	VX 1
White	WD Reference	⏏



## CRBasic Example 1: CR1000X program measuring the 03002

```
'CR1000X
'Declare Variables and Units
Public Batt_Volt
Public WS_ms
Public WindDir
Units Batt_Volt=Volts
Units WS_ms=meters/second
Units WindDir=Degrees

'Define Data Tables
DataTable(Hour,True,-1)
  DataInterval(0,60,Min,10)
  WindVector (1,WS_ms,WindDir,FP2,False,0,0,0)
  FieldNames("WS_ms_S_WVT,WindDir_D1_WVT,WindDir_SD1_WVT")
EndTable

'Main Program
BeginProg
  Scan(5,Sec,1,0)
    'Default Data Logger Battery Voltage measurement Batt_Volt:
    Battery(Batt_Volt)

    '03002 or 03101 RM Young Wind Sentry Wind Speed Sensor measurement
    'WS_ms:
    PulseCount(WS_ms,1,P1,5,1,0.75,0.2)
    If WS_ms<0.21 Then WS_ms=0

    '03002 or 03301 RM Young Wind Sentry Wind Direction Sensor
    'measurement - WindDir:
    BrHalf(WindDir,1,mV1000,1,Vx1,1,1000,True,20000,_60Hz,352,0)
    'Use mV5000 range and 5000 mV excitation for CR3000 and CR5000
    'data loggers.
    If WindDir>=360 OR WindDir<0 Then WindDir=0
    'Call Data Tables and Store Data
    CallTable(Hour)
  NextScan
EndProg
```

# Appendix C. Wind Direction Sensor Orientation

---

## C.1 Determining True North and Sensor Orientation

Orientation of the wind direction sensor is done after the datalogger has been programmed, and the location of True North has been determined. True North is usually found by reading a magnetic compass and applying the correction for magnetic declination; where magnetic declination is the number of degrees between True North and Magnetic North. Magnetic declination for a specific site can be obtained from a USGS map, local airport, or through a computer service offered by the USGS at [www.ngdc.noaa.gov/geomag](http://www.ngdc.noaa.gov/geomag). A general map showing magnetic declination is shown in Figure C-1.

Declination angles east of True North are considered negative, and are subtracted from 0 degrees to get True North as shown Figure C-2. Declination angles west of True North are considered positive, and are added to 0 degrees to get True North as shown in Figure C-3. For example, the declination for Logan, Utah is 14° East. True North is  $360 - 14^\circ$ , or 346° as read on a compass.

Orientation is most easily done with two people, one to aim and adjust the sensor, while the other observes the wind direction displayed by the datalogger.

1. Establish a reference point on the horizon for True North.
2. Sighting down the instrument centre line, aim the nose cone, or counterweight at True North. Display the input location or variable for wind direction using a hand-held keyboard display, PC, or palm.
3. Loosen the u-bolt on the CM220 or the set screws on the Nu-Rail that secure the base of the sensor to the crossarm. While holding the vane position, slowly rotate the sensor base until the datalogger indicates 0 degrees. Tighten the set screws.




FIGURE C-1. Magnetic Declination at 2012.5 (degrees relative to true north, positive is east)





FIGURE C-2. Declination Angles East of True North are Subtracted from 0 to get True North



*FIGURE C-3. Declination Angles West of True North are Added to 9 to get True North*



## Global Sales & Support Network

*A worldwide network to help meet your needs*



### Campbell Scientific Regional Offices

#### Australia

**Location:** Garbutt, QLD Australia  
**Phone:** 61.7.4401.7700  
**Email:** [info@campbellsci.com.au](mailto:info@campbellsci.com.au)  
**Website:** [www.campbellsci.com.au](http://www.campbellsci.com.au)

#### Brazil

**Location:** São Paulo, SP Brazil  
**Phone:** 11.3732.3399  
**Email:** [vendas@campbellsci.com.br](mailto:vendas@campbellsci.com.br)  
**Website:** [www.campbellsci.com.br](http://www.campbellsci.com.br)

#### Canada

**Location:** Edmonton, AB Canada  
**Phone:** 780.454.2505  
**Email:** [dataloggers@campbellsci.ca](mailto:dataloggers@campbellsci.ca)  
**Website:** [www.campbellsci.ca](http://www.campbellsci.ca)

#### China

**Location:** Beijing, P. R. China  
**Phone:** 86.10.6561.0080  
**Email:** [info@campbellsci.com.cn](mailto:info@campbellsci.com.cn)  
**Website:** [www.campbellsci.com.cn](http://www.campbellsci.com.cn)

#### Costa Rica

**Location:** San Pedro, Costa Rica  
**Phone:** 506.2280.1564  
**Email:** [info@campbellsci.cc](mailto:info@campbellsci.cc)  
**Website:** [www.campbellsci.cc](http://www.campbellsci.cc)

#### France

**Location:** Vincennes, France  
**Phone:** 0033.0.1.56.45.15.20  
**Email:** [info@campbellsci.fr](mailto:info@campbellsci.fr)  
**Website:** [www.campbellsci.fr](http://www.campbellsci.fr)

#### Germany

**Location:** Bremen, Germany  
**Phone:** 49.0.421.460974.0  
**Email:** [info@campbellsci.de](mailto:info@campbellsci.de)  
**Website:** [www.campbellsci.de](http://www.campbellsci.de)

#### India

**Location:** New Delhi, DL India  
**Phone:** 91.11.46500481.482  
**Email:** [info@campbellsci.in](mailto:info@campbellsci.in)  
**Website:** [www.campbellsci.in](http://www.campbellsci.in)

#### South Africa

**Location:** Stellenbosch, South Africa  
**Phone:** 27.21.8809960  
**Email:** [sales@campbellsci.co.za](mailto:sales@campbellsci.co.za)  
**Website:** [www.campbellsci.co.za](http://www.campbellsci.co.za)

#### Spain

**Location:** Barcelona, Spain  
**Phone:** 34.93.2323938  
**Email:** [info@campbellsci.es](mailto:info@campbellsci.es)  
**Website:** [www.campbellsci.es](http://www.campbellsci.es)

#### Thailand

**Location:** Bangkok, Thailand  
**Phone:** 66.2.719.3399  
**Email:** [info@campbellsci.asia](mailto:info@campbellsci.asia)  
**Website:** [www.campbellsci.asia](http://www.campbellsci.asia)

#### UK

**Location:** Shepshed, Loughborough, UK  
**Phone:** 44.0.1509.601141  
**Email:** [sales@campbellsci.co.uk](mailto:sales@campbellsci.co.uk)  
**Website:** [www.campbellsci.co.uk](http://www.campbellsci.co.uk)

#### USA

**Location:** Logan, UT USA  
**Phone:** 435.227.9120  
**Email:** [info@campbellsci.com](mailto:info@campbellsci.com)  
**Website:** [www.campbellsci.com](http://www.campbellsci.com)