

INSTRUCTION MANUAL



03002 R.M. Young Wind Sentry Set
03101 R.M. Young Wind Sentry Anemometer
03301 R.M. Young Wind Sentry Vane

Revision: 2/18



Copyright © 1986-2018
Campbell Scientific, Inc.

Guarantee

This equipment is guaranteed against defects in materials and workmanship. We will repair or replace products which prove to be defective during the guarantee period as detailed on your invoice, provided they are returned to us prepaid. The guarantee will not apply to:

- Equipment which has been modified or altered in any way without the written permission of Campbell Scientific
- Batteries
- Any product which has been subjected to misuse, neglect, acts of God or damage in transit.

Campbell Scientific will return guaranteed equipment by surface carrier prepaid. Campbell Scientific will not reimburse the claimant for costs incurred in removing and/or reinstalling equipment. This guarantee and the Company's obligation thereunder is in lieu of all other guarantees, expressed or implied, including those of suitability and fitness for a particular purpose. Campbell Scientific is not liable for consequential damage.

Please inform us before returning equipment and obtain a Repair Reference Number whether the repair is under guarantee or not. Please state the faults as clearly as possible, and if the product is out of the guarantee period it should be accompanied by a purchase order. Quotations for repairs can be given on request. It is the policy of Campbell Scientific to protect the health of its employees and provide a safe working environment, in support of this policy a "Declaration of Hazardous Material and Decontamination" form will be issued for completion.

When returning equipment, the Repair Reference Number must be clearly marked on the outside of the package. Complete the "Declaration of Hazardous Material and Decontamination" form and ensure a completed copy is returned with your goods. Please note your Repair may not be processed if you do not include a copy of this form and Campbell Scientific Ltd reserves the right to return goods at the customers' expense.

Note that goods sent air freight are subject to Customs clearance fees which Campbell Scientific will charge to customers. In many cases, these charges are greater than the cost of the repair.



Campbell Scientific Ltd,
80 Hathern Road,
Shepshed, Loughborough, LE12 9GX, UK
Tel: +44 (0) 1509 601141
Fax: +44 (0) 1509 270924
Email: support@campbellsci.co.uk
www.campbellsci.co.uk

PLEASE READ FIRST

About this manual

Please note that this manual was originally produced by Campbell Scientific Inc. primarily for the North American market. Some spellings, weights and measures may reflect this origin.

Some useful conversion factors:

Area: 1 in² (square inch) = 645 mm²

Length: 1 in. (inch) = 25.4 mm
1 ft (foot) = 304.8 mm
1 yard = 0.914 m
1 mile = 1.609 km

Mass: 1 oz. (ounce) = 28.35 g
1 lb (pound weight) = 0.454 kg

Pressure: 1 psi (lb/in²) = 68.95 mb

Volume: 1 UK pint = 568.3 ml
1 UK gallon = 4.546 litres
1 US gallon = 3.785 litres

In addition, while most of the information in the manual is correct for all countries, certain information is specific to the North American market and so may not be applicable to European users.

Differences include the U.S standard external power supply details where some information (for example the AC transformer input voltage) will not be applicable for British/European use. *Please note, however, that when a power supply adapter is ordered it will be suitable for use in your country.*

Reference to some radio transmitters, digital cell phones and aerials may also not be applicable according to your locality.

Some brackets, shields and enclosure options, including wiring, are not sold as standard items in the European market; in some cases alternatives are offered. Details of the alternatives will be covered in separate manuals.

Part numbers prefixed with a “#” symbol are special order parts for use with non-EU variants or for special installations. Please quote the full part number with the # when ordering.

Recycling information



At the end of this product's life it should not be put in commercial or domestic refuse but sent for recycling. Any batteries contained within the product or used during the products life should be removed from the product and also be sent to an appropriate recycling facility.

Campbell Scientific Ltd can advise on the recycling of the equipment and in some cases arrange collection and the correct disposal of it, although charges may apply for some items or territories.

For further advice or support, please contact Campbell Scientific Ltd, or your local agent.



Campbell Scientific Ltd, 80 Hathern Road, Shepshed, Loughborough, LE12 9GX,
UK Tel: +44 (0) 1509 601141 Fax: +44 (0) 1509 270924
Email: support@campbellsci.co.uk
www.campbellsci.co.uk

Precautions

DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC. FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at www.campbellsci.eu or by telephoning +44(0) 1509 828 888 (UK). You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified engineer. If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

General

- Prior to performing site or installation work, obtain required approvals and permits. Comply with all governing structure-height regulations, such as those of the FAA in the USA.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a **hardhat** and **eye protection**, and take **other appropriate safety precautions** while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

Utility and Electrical

- **You can be killed** or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in **contact with overhead or underground utility lines**.
- Maintain a distance of at least one-and-one-half times structure height, or 20 feet, or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.

Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CUSTOMER ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.

Table of Contents

PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.

1. Introduction	1
2. Precautions	1
3. Initial Inspection.....	1
3.1 Ships With List	2
4. QuickStart.....	2
5. Overview	4
6. Specifications.....	5
6.1 Wind Speed (Anemometer).....	6
6.2 Wind Direction (Vane).....	6
6.3 Wind Sentry Assembly	7
7. Installation.....	7
7.1 Siting.....	7
7.2 Assembly and Mounting	7
7.2.1 Mounting the 03002 to a Crossarm.....	8
7.2.2 Mounting the 03101 Anemometer to a Crossarm.....	10
7.2.3 Mounting the 03002 or 03101 Atop a Tripod Mast	10
7.2.4 Mounting the 03301 Vane	11
7.3 Wiring	11
7.4 Programming.....	13
7.4.1 Wind Speed.....	13
7.4.2 Wind Direction	14
7.4.3 Wind Vector Processing Instruction	14
8. Sensor Maintenance	15
9. Troubleshooting.....	15
9.1 Wind Direction.....	15
9.2 Wind Speed.....	15
10. References.....	16

Appendices

A. Importing Short Cut Code Into CRBasic Editor ...	A-1
--	------------

B. Example Programs.....	B-1
C. Wind Direction Sensor Orientation.....	C-1
C.1 Magnetic Declination	C-1
D. Wind Direction Measurement Theory	D-1
D.1 BRHalf Instruction	D-1

Figures

7-1. Crossarm with CM220 Right Angle Mounting Bracket.....	8
7-2. 03002 mounted to a crossarm with the CM220.....	9
7-3. 03002 mounted to a crossarm with 1 x 1 inch Nu-Rail fitting	9
7-4. 03101 mounted to a crossarm via a 3/4 x 1 inch Nu-Rail fitting.....	10
7-5. The CM216 allows an 03002 or 03101 to mount atop the mast of a CM106B, CM110, CM115, or CM120 tripod.....	11
C-1. Declination angles - true north to east of magnetic north.....	C-1
C-2. Declination angles - true north to west of magnetic north.....	C-2
C-3. Magnetic Declination at 2012.5 (degrees relative to true north, positive is east).....	C-2
D-1. 03002 and 03301 potentiometer in a half bridge circuit.....	D-1

Tables

5-1. Recommended Cable Lengths.....	5
7-1. 03002 Wire Colour, Wire Function, and Datalogger Connection	12
7-2. 03101 or 03301 Wire Colour, Wire Function, and Datalogger Connection	12
7-3. Wind Speed Multiplier (With Pulse Channel Configuration Set to Low Level AC, Output “Hz”).....	14
7-4. Parameters for Wind Direction.....	14
B-1. Wiring for Example Programs.....	B-1

CRBasic Examples

B-1. CR1000X Program Measuring the 03002	B-1
B-2. CR6 Program Measuring the 03002	B-2
B-3. CR200(X) Program Measuring the 03002.....	B-3

R.M. Young Wind Sentry

1. Introduction

The 03002 Wind Sentry Set measures both wind speed and direction. It consists of a 3-cup anemometer and a wind vane mounted on a small crossarm. The anemometer (pn #03101) and vane (pn #03301) may be purchased separately.

NOTE

This manual provides information only for CRBasic dataloggers. It is also compatible with the most of our retired Edlog dataloggers. For Edlog datalogger support, see an older manual at www.campbellsci.eu/old-manuals.

2. Precautions

- READ AND UNDERSTAND the *Safety* section at the front of this manual.
- The 03002 is a precision instrument. Please handle it with care.
- If the 03002 is to be installed at heights over 6 feet, be familiar with tower safety and follow safe tower climbing procedures.
- Danger — Use extreme care when working near overhead electrical wires. Check for overhead wires before mounting the 03002 or before raising a tower.
- The black outer jacket of the cable is Santoprene® rubber. This compound was chosen for its resistance to temperature extremes, moisture, and UV degradation. However, this jacket will support combustion in air. It is rated as slow burning when tested according to U.L. 94 H.B. and will pass FMVSS302. Local fire codes may preclude its use inside buildings.

3. Initial Inspection

- Upon receipt of the 03002, inspect the packaging and contents for damage. File damage claims with the shipping company. Immediately check package contents against the shipping documentation (see Section 3.1, *Ships With List* (p. 2)). Contact Campbell Scientific about any discrepancies.
- The model number and cable length are printed on a label at the connection end of the cable. Check this information against the shipping documents to ensure the expected product and cable length are received.

3.1 Ships With List

The 03002 Wind Sentry ships with:

- (1) 03002 Wind Sentry including
 - 03102 anemometer
 - 03302 vane
 - crossarm
 - band clamp
- (1) 1-inch IPS, 12-inch-long, unthreaded aluminium pipe
- (1) Allen wrench

The 03101 anemometer ships with:

- (1) 03101 anemometer
- (1) 3/4-inch IPS, 10-inch-long, threaded aluminium pipe
- (1) Allen wrench

The 03301 vane ships with:

- (1) 03301 vane
- (1) 3/4-inch IPS, 10-inch-long threaded aluminium pipe; this assumes mounting option –P.
- (1) Allen wrench



4. QuickStart

Short Cut is an easy way to program your datalogger to measure the 03002 and assign datalogger wiring terminals. *Short Cut* is available as a download on www.campbellsci.com. It is included in installations of *LoggerNet*, *PC200W*, *PC400*, or *RTDAQ*.

The following procedure shows using *Short Cut* to program the 03002.

1. Open *Short Cut* and click **Create New Program**.
2. Double-click the datalogger model.

- In the search box under the **Available Sensors and Devices** heading, type in 03002 or find the sensor in the **Sensors | Meteorological | Wind Speed & Direction**. Double-click **03002 Wind Speed & Direction Sensor**. The wind speed defaults to metres/second. This can be changed by clicking the **Wind Speed** box and selecting one of the other options. After entering the **Properties**, click on the **Wiring** tab to see how the sensor is to be wired to the datalogger.



- Select any other sensors you have, then finish the remaining *Short Cut* steps to complete the program.

5. In **Output Setup**, enter the scan rate and **Data Output Storage Interval**.

6. Select the output options.

7. If *LoggerNet*, *PC400*, *RTDAQ*, or *PC200W* is running on your computer, and the computer to datalogger connection is active, you can click **Finish** in *Short Cut* and you will be prompted to send the program just created to the datalogger.
8. If the sensor is connected to the datalogger, as shown in the wiring diagram, check the output of the sensor in the datalogger support software data display to make sure it is making reasonable measurements.

5. Overview

The 03002 Wind Sentry Set is used to measure horizontal wind speed and direction.

Wind speed is measured with a three-cup anemometer. Rotation of the cup wheel produces an ac sine wave voltage with frequency proportional to wind speed. This is a special version of the 03102 built for Campbell Scientific by

R.M. Young that has shielded bearings rather than sealed bearings. The shielded bearings provide a lower starting threshold than sealed bearings.

Vane position is transmitted by a 10 k Ω potentiometer. With a precision excitation voltage applied, the output voltage is proportional to wind direction.

The 03101 Anemometer and 03301 Vane can be ordered as separate sensors, which are also covered in this manual. These two sensors combined differ from the 03002 only by the absence of a junction box. The R.M. Young 03002 manual (see Section 10, *References (p. 16)*) includes additional information on the operating principles, installation, and maintenance of the sensor.

Cable length for the Wind Sentry is specified when the sensor is ordered. TABLE 5-1 gives the recommended lead length for mounting the sensor at the top of the tripod/tower with a CM200-series crossarm.

TABLE 5-1. Recommended Cable Lengths						
CM106B	CM110	CM115	CM120	UT10	UT20	UT30
12 ft	15 ft	20 ft	25 ft	15 ft	25 ft	38 ft

NOTE

Do not exceed 1,000 feet of cable.

CAUTION

Do not use long lead lengths in electrically noisy environments.

The 03002's cable can terminate in:

- Pigtails that connect directly to a Campbell Scientific datalogger (option –PT).
- Connector that attaches to a prewired enclosure (option –PW). Refer to www.campbellsci.eu/prewired-enclosures for more information.
- Connector that attaches to a CWS900 Wireless Sensor Interface (option –CWS). The CWS900 allows the 03002 to be used in a wireless sensor network. Refer to www.campbellsci.eu/cws900 for more information.

6. Specifications

Features:

- Designed for continuous, long term, unattended operation in adverse conditions
- Small size, simplicity, and rugged construction provide a quality instrument for a modest price
- Ideal for wind profile studies
- Compatible with the LLAC4 4-channel Low Level AC Conversion Module, which increases the number of anemometers one datalogger can measure

- Campbell Scientific version uses shielded bearings, which lowers the anemometer's starting threshold
- Compatible with Campbell Scientific CRBasic dataloggers: CR200(X) series, CR300 series, CR6 series, CR800 series, CR1000, CR1000X series, CR3000, CR5000, and CR9000X

6.1 Wind Speed (Anemometer)

Range:	0 to 50 m s ⁻¹ (112 mph), gust survival 60 m s ⁻¹ (134 mph)
Sensor:	12 cm diameter cup wheel assembly, 40 mm diameter hemispherical cups
Accuracy:	±0.5 m s ⁻¹ (1.1 mph)
Turning Factor:	75 cm (2.5 ft)
Distance Constant (63% recovery):	2.3 m (7.5 ft)
Threshold:	0.5 m s ⁻¹ (1.1 mph)
Transducer:	Stationary coil, 1300-ohm nominal resistance
Output:	AC sine wave signal induced by rotating magnet on cup wheel shaft 100 mV peak-to-peak at 60 rpm; 6 V peak-to-peak at 3600 rpm
Output Frequency:	1 cycle per cup wheel revolution; 0.75 m s ⁻¹ per Hz
Cup Wheel Diameter:	12 cm (4.7 in)
Weight:	113 g (4 oz)

6.2 Wind Direction (Vane)

Range:	360° mechanical, 352° electrical (8° open)
Sensor:	Balanced vane, 16 cm turning radius
Settling Time:	20 ms
Damping Ratio:	0.2
Delay Distance (50% recovery):	0.5 m (1.6 ft)
Threshold:	0.8 m s ⁻¹ (1.8 mph) at 10° displacement (1.8 m s ⁻¹ (4 mph) at 5° displacement)
Transducer:	Precision conductive plastic potentiometer; 10 kΩ resistance; 1.0% linearity; life expectancy 50 million revolutions Rated 1 W at 40 °C, 0 W at 125 °C

Transducer Excitation Requirement:	Regulated dc voltage, 15 Vdc max
Output:	Analogue dc voltage proportional to wind direction angle with regulated excitation voltage supplied by the datalogger
Vane Length:	22 cm (8.7 in)
Vane Weight:	170 g (6 oz)

6.3 Wind Sentry Assembly

Operating Temperature:	–50 to 50 °C assuming non-riming conditions
Overall Height:	32 cm (12.6 in)
Crossarm Length:	40 cm (15.7 in) between instruments (centre-to-centre)
Mounting Diameter:	34 mm (1.34 in), mounts on standard 1 inch IPS pipe

7. Installation

If you are programming your datalogger with *Short Cut*, skip Section 7.3, *Wiring* (p. 11), and Section 7.4, *Programming* (p. 13). *Short Cut* does this work for you. See Section 4, *QuickStart* (p. 2), for a *Short Cut* tutorial.

7.1 Siting

Locate wind sensors away from obstructions (e.g., trees and buildings). As a general rule of thumb, there should be a horizontal distance of at least ten times the height of the obstruction between the wind set and the obstruction. If it is necessary to mount the sensors on the roof of a building, the height of the sensors above the roof, should be at least 1.5 times the height of the building. See Section 10, *References* (p. 16), for a list of references that discuss siting wind speed and direction sensors.

7.2 Assembly and Mounting

Tools required:

- 5/64-inch Allen wrench
- Allen wrench provided with sensor
- 1/2-inch open end wrench
- compass and declination angle for the site (see Appendix C, *Wind Direction Sensor Orientation* (p. C-1))
- small screw driver provided with datalogger
- UV resistant cable ties
- small pair of diagonal-cutting pliers
- 6- to 10-inch torpedo level

7.2.1 Mounting the 03002 to a Crossarm

Install the 03002 using:

- Standard 1.0-inch IPS schedule 40 pipe
 - CM220 Right-Angle Mounting Kit (FIGURE 7-1 and FIGURE 7-2),
or
 - 1 x 1 inch Nu-Rail Crossover Fitting (FIGURE 7-3)
1. Install the cup wheel to the anemometer shaft using the Allen wrench provided with the sensor.
 2. Mount the crossarm to the tripod or tower.
 3. Orient the crossarm North-South, with the CM220 mount or Nu-Rail on the north end. Appendix C, *Wind Direction Sensor Orientation (p. C-1)*, contains detailed information on determining True North using a compass and the magnetic declination for the site.
 4. Secure the 12-inch aluminium pipe to the CM220 mount or Nu-Rail. The aluminium pipe is shipped with the 03002.
 5. Place the 03002 on the pipe, and orient the sensor crossarm North-South with the vane to the North.
 6. Tighten the mounting post band clamp. Final sensor orientation is done after the datalogger has been programmed to measure wind direction as described in Appendix C, *Wind Direction Sensor Orientation (p. C-1)*.
 7. Route the sensor cable along the underside of the crossarm to the tripod or tower, and to the instrument enclosure.
 8. Secure the cable to the crossarm and tripod or tower using cable ties.




FIGURE 7-1. Crossarm with CM220 Right Angle Mounting Bracket




FIGURE 7-2. 03002 mounted to a crossarm with the CM220




FIGURE 7-3. 03002 mounted to a crossarm with 1 x 1 inch Nu-Rail fitting

7.2.2 Mounting the 03101 Anemometer to a Crossarm

1. Install the cup wheel to the anemometer shaft using the Allen wrench provided with the sensor.
2. Mount the crossarm to the tripod or tower.
3. Secure the 3/4-inch IPS, 10-inch-long, threaded aluminium pipe to the CM220 mount (FIGURE 7-1) or 3/4 x 1 inch Nu-Rail fitting (FIGURE 7-4).
4. Place the 03101 on the pipe.
5. Route the sensor cable to the instrument enclosure. If using a crossarm the cable should be routed along the underside of the crossarm.
6. Secure the cable to the crossarm and tripod or tower using cable ties.




FIGURE 7-4. 03101 mounted to a crossarm via a 3/4 x 1 inch Nu-Rail fitting

7.2.3 Mounting the 03002 or 03101 Atop a Tripod Mast

The 03002 and 03101 mount at the top of a CM106B, CM110, CM115, or CM120 tripod with the CM216 (see FIGURE 7-5). The CM216 extends 10 cm (4 in) above the mast of the tripod.




FIGURE 7-5. The CM216 allows an 03002 or 03101 to mount atop the mast of a CM106B, CM110, CM115, or CM120 tripod

7.2.4 Mounting the 03301 Vane

The 03301 wind vane has three mounting options


- No Mounting (option –NM) is used when the 03301 will be replacing an existing 03301 within a Wind Sentry Set.
- Pipe Offset Mount (option –P) is used when the 03301 will be deployed on its own next to an anemometer that already has its own mount. With this option, the 03301 mounts to a crossarm using the CM220 mount or 3/4 x 1 inch Nu-Rail fitting.
- 03101 Conversion Kit (option –SM) is used when the 03301 will be mounted next to a previously purchased 03101 Anemometer (Wind Sentry Anemometer). This conversion kit includes the crossarm and other hardware to mount both sensors to a common crossarm as if they had been purchased originally as a complete Wind Sentry Set.

7.3 Wiring

Connections to CRBasic dataloggers are given in TABLE 7-1 and TABLE 7-2. To wire an Edlog datalogger, see an older manual at www.campbellsci.com/old-manuals.

TABLE 7-1. 03002 Wire Colour, Wire Function, and Datalogger Connection		
Wire Colour	Wire Function	Datalogger Connection Terminal
Red	WS Signal	U configured for pulse input ¹ , P (pulse input), or P_LL (pulse, low-level ac)
Black	WS Signal Reference	\perp
Green	WD Signal	U configured for single-ended analogue input ¹ , SE (single-ended, analogue input)
Blue	WD Voltage Excitation	U configured for voltage excitation ¹ , EX , or VX (voltage excitation)
White	WD Signal Reference	\perp (analogue ground)
Clear	Shield	\perp (analogue ground)
¹ U channels are automatically configured by the measurement instruction.		

TABLE 7-2. 03101 or 03301 Wire Colour, Wire Function, and Datalogger Connection		
Wire Colour	Wire Function	Datalogger Connection Terminal
Black	WS Signal	U configured for pulse input ¹ , P (pulse input), or P_LL (pulse, low-level ac)
White	WS Signal Reference	\perp
Clear	Shield	\perp (analogue ground)
Red	WD Signal	U configured for single-ended analogue input ¹ , SE (single-ended, analogue input)
Black	WD Voltage Excitation	U configured for voltage excitation ¹ , EX , or VX (voltage excitation)
White	WD Signal Reference	\perp (analogue ground)
Clear	Shield	\perp (analogue ground)
¹ U channels are automatically configured by the measurement instruction.		



7.4 Programming

Short Cut is the best source for up-to-date datalogger programming code. Programming code is needed when:

- Creating a program for a new datalogger installation
- Adding sensors to an existing datalogger program

If your data acquisition requirements are simple and you are connecting the sensor to a pulse port, you can probably create and maintain a datalogger program exclusively with *Short Cut*. If your data acquisition needs are more complex, the files that *Short Cut* creates are a great source for programming code to start a new program or add to an existing custom program.

NOTE

Short Cut cannot edit programs after they are imported and edited in *CRBasic Editor*.

A *Short Cut* tutorial is available in Section 4, *QuickStart* (p. 2). If you wish to import *Short Cut* code into *CRBasic Editor* to create or add to a customized program, follow the procedure in Appendix A, *Importing Short Cut Code Into CRBasic Editor* (p. A-1). Programming basics for *CRBasic* dataloggers are provided in the following sections. Complete program examples for select *CRBasic* dataloggers can be found in Appendix B, *Example Programs* (p. B-1). Programming basics and programming examples for *Edlog* dataloggers are provided at www.campbellsci.com/old-manuals.

7.4.1 Wind Speed

Wind speed is measured with the Pulse Count instruction (**PulseCount()**) in *CRBasic*. Use the low level AC configuration.

The expression for wind speed (U) is:

$$U = MX + B$$

where

M = multiplier

X = number of pulses per second (Hertz)

B = offset

TABLE 7-3 lists the multipliers (M) and offsets (Off) to obtain metres/second or miles/hour when the **Pulse Count** instruction is configured to output the result in hertz.

TABLE 7-3. Wind Speed Multiplier (With Pulse Channel Configuration Set to Low Level AC, Output “Hz”)		
Model	Metres/Second	Miles/Hour
03002 / 03101	M = 0.750 Off = 0.2	M = 1.677 Off = 0.4
*When the pulse channel configuration is set to Low Level AC, output “counts”, the multiplier above is divided by the execution interval in seconds.		

7.4.2 Wind Direction

The wind vane is coupled to a 10 k Ω potentiometer, which has an 8-degree electrical dead band between 352 and 360 degrees.

The CR200(X) dataloggers use the **ExDelSE()** instruction to measure wind direction. All other CRBasic dataloggers use the **BRHalf()** instruction.

Some CRBasic measurement sequences can cause the measurement of the wind direction to return a negative wind direction (-30°) while in the dead band. To overcome this problem, all program examples use a delay of 20 ms (20,000 μ s) and set any negative wind direction values to 0.0: If WindDir < 0, then WindDir = 0.0.

Excitation voltages, range codes, and multipliers for Campbell Scientific dataloggers are listed in TABLE 7-4. Appendix D, *Wind Direction Measurement Theory (p. D-1)*, has additional information on the **BRHalf()** measurement instructions.

TABLE 7-4. Parameters for Wind Direction						
	CR200(X)	CR300 Series	CR800, CR850, CR1000	CR1000X	CR6	CR5000, CR3000
Measurement Range	NA	mV2500	mV2500	mV5000	mV1000	mV5000
Excitation Voltage	2500 mV	2500 mV	2500 mV	2500 mV	1000 mV	5000 mV
Reverse Excitation	NA	NA	True	True	True	True
Delay or Settling Time	20000 μ s	20000 μ s	20000 μ s	20000 μ s	20000 μ s	20000 μ s
Multiplier	0.1408	352	352	352	352	352
Offset	0	0	0	0	0	0

7.4.3 Wind Vector Processing Instruction

The **Wind Vector** output instruction is used to process and store mean wind speed, unit vector mean wind direction, and standard deviation of the wind direction (optional) from the measured wind speed and direction values.

8. Sensor Maintenance

Every month do a visual/audio inspection of the anemometer at low wind speeds. Verify that the cup assembly and wind vane rotate freely. Inspect the sensor for physical damage.

Replace the anemometer bearings when they become noisy, or the wind speed threshold increases above an acceptable level. The condition of the bearings can be checked with a paper clip as described in the R.M. Young 03002 manual (see Section 10, *References* (p. 16)).

The potentiometer has a life expectancy of fifty million revolutions. As it becomes worn, the element can produce noisy signals or become nonlinear. Replace the potentiometer when the noise or nonlinearity becomes unacceptable.

Refer to the [Assistance](#) page at the beginning of this document for the procedure of returning the sensor to Campbell Scientific for wind vane and bearing replacement.

9. Troubleshooting

9.1 Wind Direction

Symptom: NAN, -9999, or no change in direction

1. Check that the sensor is wired to the excitation and single-ended channel specified by the measurement instruction.
2. Verify that the excitation voltage and range code are correct for the datalogger type.
3. Disconnect the sensor from the datalogger and use an ohm meter to check the potentiometer. Resistance should be about 10 k Ω between the black and white wires. The resistance between either the black/red or white/red wires for the 03301 and blue/red or white/red for the 03002 should vary from 1 k Ω to 11 k Ω depending on vane position. Resistance when the vane is in the 8-degree dead band should be about 1 M Ω .

Symptom: Incorrect wind direction

1. Verify that the excitation voltage, range code, multiplier, and offset parameters are correct for the datalogger type.
2. Check orientation of sensor as described in Section 7.2, *Assembly and Mounting* (p. 7).

9.2 Wind Speed

Symptom: No wind speed

1. Check that the sensor is wired to the pulse channel specified by the pulse count instruction.

2. Disconnect the sensor from the datalogger and use an ohm meter to check the coil. The resistance between the white and black wires for the 03101 and black and red wires for the 03002 should be a nominal 1300 ohms. Infinite resistance indicates an open coil; low resistance indicates a shorted coil.
3. Verify that the configuration code, and multiplier and offset parameters for the pulse count instruction are correct for the datalogger type.

10. References

Component part numbers and other information is available in the R.M. Young 03002 manual available at www.campbellsci.eu/03002-wind-sentry. Because Campbell Scientific cables the sensor, the wiring in the R.M. Young manual will be different than the wiring listed in this manual.

The following references give detailed information on siting wind speed and wind direction sensors.

EPA, 1989: *Quality Assurance Handbook for Air Pollution Measurements System*, Office of Research and Development, Research Triangle Park, NC, 27711.

EPA, 1987: *On-Site Meteorological Program Guidance for Regulatory Modeling Applications*, EPA-450/4-87-013, Office of Air Quality Planning and Standards, Research Triangle Park, NC 27711.

The State Climatologist, 1985: *Publication of the American Association of State Climatologists: Height and Exposure Standards*, for Sensors on Automated Weather Stations, vol. 9, No. 4.

WMO, 1983: *Guide to Meteorological Instruments and Methods of Observation*, World Meteorological Organization, No. 8, 5th edition, Geneva, Switzerland.

Appendix A. Importing Short Cut Code Into CRBasic Editor

This tutorial shows:

- How to import a *Short Cut* program into a program editor for additional refinement
- How to import a wiring diagram from *Short Cut* into the comments of a custom program

Short Cut creates files, which can be imported into *CRBasic Editor*. Assuming defaults were used when *Short Cut* was installed, these files reside in the C:\campbellsci\SCWin folder:

- .DEF (wiring and memory usage information)
- .CR2 (CR200(X)-series datalogger code)
- .CR300 (CR300-series datalogger code)
- .CR6 (CR6-series datalogger code)
- .CR8 (CR800-series datalogger code)
- .CR1 (CR1000 datalogger code)
- .CR1X (CR1000X-series datalogger code)
- .CR3 (CR3000 datalogger code)
- .CR5 (CR5000 datalogger code)
- .CR9 (CR9000(X) datalogger code)

Use the following procedure to import *Short Cut* code and wiring diagram into *CRBasic Editor*.

1. Create the *Short Cut* program following the procedure in Section 4, *QuickStart* (p. 2). Finish the program. On the **Advanced** tab, click the **CRBasic Editor** button. The program opens in CRBasic with the name **noname.CR_**. Now save the program with your desired name in any folder.

NOTE

Once the file is edited with *CRBasic Editor*, *Short Cut* can no longer be used to edit the datalogger program. Change the name of the program file or move it, or *Short Cut* may overwrite it next time it is used.

2. The program can now be edited, saved, and sent to the datalogger.
3. Import wiring information to the program by opening the associated .DEF file. By default, it will be in the c:\campbellsci\SCWin folder. Copy and paste the section beginning with heading “–Wiring for CRXXX–” into the CRBasic program, usually at the head of the file. After pasting, edit the information such that an apostrophe (') begins each line. This character instructs the datalogger compiler to ignore the line when compiling. You can highlight several lines of CRBasic code then right-click and select **Comment Block**. (This feature is demonstrated at about 5:10 in the [CRBasic | Features](#) video.)

Appendix B. Example Programs

These example programs measure the 03002 every 5 seconds, and store mean wind speed, unit vector mean direction, and standard deviation of the direction every 60 minutes. Wiring for the examples is given in TABLE B-1.

TABLE B-1. Wiring for Example Programs				
Colour	Wire Label	CR1000X	CR6	CR200X
Red	WS Signal	P1	U4	P_LL
Black	WS Reference	⏏	⏏	⏏
Clear	Shield	⏏	⏏	⏏
Green	WD Signal	SE 1	U2	SE 1
Blue	WD Volt Excit	VX 1	U1	VX1
White	WD Reference	⏏	⏏	⏏

CRBasic Example B-1. CR1000X Program Measuring the 03002

```
'CR1000X
'Declare Variables and Units
Public Batt_Volt
Public WS_ms
Public WindDir
Units Batt_Volt=Volts
Units WS_ms=metres/second
Units WindDir=Degrees

'Define Data Tables
DataTable(Hour,True,-1)
  DataInterval(0,60,Min,10)
  WindVector(1,WS_ms,WindDir,FP2,False,0,0,0)
  FieldNames("WS_ms_S_WVT,WindDir_D1_WVT,WindDir_SD1_WVT")
EndTable

'Main Program
BeginProg
  Scan(5,Sec,1,0)
    'Default Datalogger Battery Voltage measurement Batt_Volt:
    Battery(Batt_Volt)

    '03002 or 03101 RM Young Wind Sentry Wind Speed Sensor measurement
    'WS_ms:
    PulseCount(WS_ms,1,P1,5,1,0.75,0.2)
    If WS_ms<0.21 Then WS_ms=0

    '03002 or 03301 RM Young Wind Sentry Wind Direction Sensor
    'measurement - WindDir:
    BrHalf(WindDir,1,mV1000,1,Vx1,1,1000,True,20000,_60Hz,352,0)
    'Use mV5000 range and 5000 mV excitation for CR3000 and CR5000
    'dataloggers.
    If WindDir>=360 OR WindDir<0 Then WindDir=0
    'Call Data Tables and Store Data
    CallTable(Hour)
  NextScan
EndProg
```

CRBasic Example B-2. CR6 Program Measuring the 03002

```

'CR6 Series

'Declare Variables and Units
Public BattV
Public PTemp_C
Public WS_ms
Public WindDir

Units BattV=Volts
Units PTemp_C=Deg C
Units WS_ms=metres/second
Units WindDir=degrees

'Define Data Tables
DataTable(Hour,True,-1)
  DataInterval(0,60,Min,10)
  WindVector(1,WS_ms,WindDir,FP2,False,0,0,0)
  FieldNames("WS_ms_S_WVT,WindDir_D1_WVT,WindDir_SD1_WVT")
EndTable

'Main Program
BeginProg
'Main Scan
Scan(5,Sec,1,0)
'Default Datalogger Battery Voltage measurement 'BattV'
Battery(BattV)

'Default Wiring Panel Temperature measurement 'PTemp_C'
PanelTemp(PTemp_C,60)

'03002 Wind Speed & Direction Sensor measurements 'WS_ms' and 'WindDir'
'WS_ms
PulseCount(WS_ms,1,U4,5,1,0.75,0.2)
If WS_ms<0.21 Then WS_ms=0

'WindDir
BrHalf(WindDir,1,mV1000,U2,U1,1,1000,True,20000,60,352,0)
If WindDir>=360 OR WindDir<0 Then WindDir=0

'Call Data Tables and Store Data
CallTable Hour
NextScan
EndProg

```

CRBasic Example B-3. CR200(X) Program Measuring the 03002

```

'CR200/CR200X Series

'Declare Variables and Units
Public BattV
Public WS_ms
Public WindDir

Units BattV=Volts
Units WS_ms=metres/second
Units WindDir=degrees

'Define Data Tables
DataTable(Hour,True,-1)
  DataInterval(0,60,Min)
  WindVector(WS_ms,WindDir,False,0,0)
  FieldNames("WS_ms_S_WVT,WindDir_D1_WVT,WindDir_SD1_WVT")
EndTable

'Main Program
BeginProg
  'Main Scan
  Scan(5,Sec)
    'Default Datalogger Battery Voltage measurement 'BattV'
    Battery(BattV)

    '03002 Wind Speed & Direction Sensor measurements 'WS_ms' and 'WindDir'
    'WS_ms
    PulseCount(WS_ms,P_LL,1,1,0.75,0.2)
    If WS_ms<0.21 Then WS_ms=0

    'WindDir
    ExDeISe(WindDir,1,1,1,mV2500,20000,0.1408,0)
    If WindDir>=360 OR WindDir<0 Then WindDir=0

    'Call Data Tables and Store Data
    CallTable Hour
  NextScan
EndProg

```


Appendix C. Wind Direction Sensor Orientation

C.1 Determining True North and Sensor Orientation

Orientation of the wind direction sensor is done after the datalogger has been programmed, and the location of True North has been determined. True North is usually found by reading a magnetic compass and applying the correction for magnetic declination; where magnetic declination is the number of degrees between True North and Magnetic North. Magnetic declination for a specific site can be obtained from a USGS map, local airport, or through a computer service offered by the USGS at www.ngdc.noaa.gov/geomag. A general map showing magnetic declination is shown in Figure C-1.

Declination angles east of True North are considered negative, and are subtracted from 0 degrees to get True North as shown Figure C-2. Declination angles west of True North are considered positive, and are added to 0 degrees to get True North as shown in Figure D-3. For example, the declination for Logan, Utah is 14° East. True North is 360° - 14°, or 346° as read on a compass.

Orientation is most easily done with two people, one to aim and adjust the sensor, while the other observes the wind direction displayed by the datalogger.

1. Establish a reference point on the horizon for True North.
2. Sighting down the instrument centre line, aim the nose cone, or counterweight at True North. Display the input location or variable for wind direction using a hand-held keyboard display, PC, or palm.
3. Loosen the u-bolt on the CM220 or the set screws on the Nu-Rail that secure the base of the sensor to the crossarm. While holding the vane position, slowly rotate the sensor base until the datalogger indicates 0 degrees. Tighten the set screws.




Figure C-1. Magnetic Declination at 2012.5 (degrees relative to true north, positive is east)




Figure C-2. Declination Angles East of True North Are Subtracted From 0 to Get True North




Figure C-3. Declination Angles West of True North Are Added to 0 to Get True North

Appendix D. Wind Direction Measurement Theory

It is not necessary to understand the concepts in this section for the general operation of the 03002 with Campbell Scientific's datalogger.




FIGURE D-1. 03002 and 03301 potentiometer in a half bridge circuit

D.1 BRHalf Instruction

The **BRHalf()** instruction outputs a precise excitation voltage (V_x), and measures the voltage between the wiper and ground (V_s). The resistance between the wiper and ground, R_s , and V_s varies with wind direction. The measurement result is the ratio of the measured voltage to the excitation voltage (V_s/V_x). This ratio is related to the resistance as shown below:

$$V_s/V_x = R_s/(R_t + R_s)$$

The maximum value that R_s will reach is R_f , just before it crosses over from the west side of north to the east side of north (at this point $R_t = 0$). V_s/V_x reaches its maximum value of 1.0 mV/mV at 352 degrees. The multiplier to convert V_s/V_x to degrees is 352 degrees / 1.0 $V_s/V_x = 352$. See datalogger manual for more information on the bridge measurements.

Campbell Scientific Companies

Campbell Scientific, Inc.

815 West 1800 North
Logan, Utah 84321
UNITED STATES

www.campbellsci.com • info@campbellsci.com

Campbell Scientific Canada Corp.

14532 – 131 Avenue NW
Edmonton AB T5L 4X4
CANADA

www.campbellsci.ca • dataloggers@campbellsci.ca

Campbell Scientific Africa Pty. Ltd.

PO Box 2450
Somerset West 7129
SOUTH AFRICA

www.campbellsci.co.za • cleroux@csafrica.co.za

Campbell Scientific Centro Caribe S.A.

300 N Cementerio, Edificio Breller
Santo Domingo, Heredia 40305
COSTA RICA

www.campbellsci.cc • info@campbellsci.cc

Campbell Scientific Southeast Asia Co., Ltd.

877/22 Nirvana@Work, Rama 9 Road
Suan Luang Subdistrict, Suan Luang District
Bangkok 10250
THAILAND

www.campbellsci.asia • info@campbellsci.asia

Campbell Scientific Ltd.

Campbell Park
80 Hathern Road
Shepshed, Loughborough LE12 9GX
UNITED KINGDOM

www.campbellsci.co.uk • sales@campbellsci.co.uk

Campbell Scientific Australia Pty. Ltd.

PO Box 8108
Garbutt Post Shop QLD 4814
AUSTRALIA

www.campbellsci.com.au • info@campbellsci.com.au

Campbell Scientific Ltd.

3 Avenue de la Division Leclerc
92160 ANTONY
FRANCE

www.campbellsci.fr • info@campbellsci.fr

Campbell Scientific (Beijing) Co., Ltd.

8B16, Floor 8 Tower B, Hanwei Plaza
7 Guanghua Road
Chaoyang, Beijing 100004
P.R. CHINA

www.campbellsci.com • info@campbellsci.com.cn

Campbell Scientific Ltd.

Fahrenheitstraße 13
28359 Bremen
GERMANY

www.campbellsci.de • info@campbellsci.de

Campbell Scientific do Brasil Ltda.

Rua Apinagés, n.br. 2018 — Perdizes
CEP: 01258-00 — São Paulo — SP
BRASIL

www.campbellsci.com.br • vendas@campbellsci.com.br

Campbell Scientific Spain, S. L.

Avda. Pompeu Fabra 7-9, local 1
08024 Barcelona
SPAIN

www.campbellsci.es • info@campbellsci.es

Please visit www.campbellsci.com to obtain contact information for your local US or international representative.