



4.650"  
[11.8 cm]

(Serial Numbers Less than SN1311 only)

6.100"  
[15.5 cm]



**CAMPBELL  
SCIENTIFIC**

## CD100 Mounting Template

### TEMPLATE INSTRUCTIONS:

1. Carefully remove center from paper template.
2. Prepunch center of marked mounting holes.
3. Position template on lid.
4. Mark lid by tracing inside center area and center of mounting holes.
5. Remove template.
6. Cut out center.
7. Drill mounting holes.
8. Mount CD100

MOUNTING  
HOLES  
Ø .150 [3.8 mm]  
(4X)

**CAUTION:** The CD100 must be mounted in an area that allows at least 1.8" (4.6cm) clearance from the inside face of the lid.