



(Serial Numbers SN1311 and higher only)

 **CAMPBELL SCIENTIFIC CD100 Mounting Template**

TEMPLATE INSTRUCTIONS:

- 1. Carefully remove center from paper template.
- 2. Prepunch center of marked mounting holes.
- 3. Position template on lid.
- 4. Mark lid by tracing inside center area and center of mounting holes.
- 5. Remove template.
- 6. Cut out center.
- 7. Drill mounting holes.
- 8. Mount CD100

MOUNTING HOLES
Ø .150 [3.8 mm]
(4X)

CAUTION: The CD100 must be mounted in an area that allows at least 1.8" (4.6cm) clearance from the inside face of the lid.