

INSTRUCTION MANUAL



SC32B Optically Isolated RS-232 Interface



Issued: 17.3.14

Copyright © 1987-2013 Campbell Scientific Inc.
Printed under Licence by Campbell Scientific Ltd.

Guarantee

This equipment is guaranteed against defects in materials and workmanship. This guarantee applies for twelve months from date of delivery. We will repair or replace products which prove to be defective during the guarantee period provided they are returned to us prepaid. The guarantee will not apply to:

- Equipment which has been modified or altered in any way without the written permission of Campbell Scientific
- Batteries
- Any product which has been subjected to misuse, neglect, acts of God or damage in transit.

Campbell Scientific will return guaranteed equipment by surface carrier prepaid. Campbell Scientific will not reimburse the claimant for costs incurred in removing and/or reinstalling equipment. This guarantee and the Company's obligation thereunder is in lieu of all other guarantees, expressed or implied, including those of suitability and fitness for a particular purpose. Campbell Scientific is not liable for consequential damage.

Please inform us before returning equipment and obtain a Repair Reference Number whether the repair is under guarantee or not. Please state the faults as clearly as possible, and if the product is out of the guarantee period it should be accompanied by a purchase order. Quotations for repairs can be given on request. It is the policy of Campbell Scientific to protect the health of its employees and provide a safe working environment, in support of this policy a "Declaration of Hazardous Material and Decontamination" form will be issued for completion.

When returning equipment, the Repair Reference Number must be clearly marked on the outside of the package. Complete the "Declaration of Hazardous Material and Decontamination" form and ensure a completed copy is returned with your goods. Please note your Repair may not be processed if you do not include a copy of this form and Campbell Scientific Ltd reserves the right to return goods at the customers' expense.

Note that goods sent air freight are subject to Customs clearance fees which Campbell Scientific will charge to customers. In many cases, these charges are greater than the cost of the repair.



Campbell Scientific Ltd,
Campbell Park, 80 Hathern Road,
Shepshed, Loughborough, LE12 9GX, UK
Tel: +44 (0) 1509 601141
Fax: +44 (0) 1509 601091
Email: support@campbellsci.co.uk
www.campbellsci.co.uk

PLEASE READ FIRST

About this manual

Please note that this manual was originally produced by Campbell Scientific Inc. primarily for the North American market. Some spellings, weights and measures may reflect this origin.

Some useful conversion factors:

Area: 1 in² (square inch) = 645 mm²

Length: 1 in. (inch) = 25.4 mm
1 ft (foot) = 304.8 mm
1 yard = 0.914 m
1 mile = 1.609 km

Mass: 1 oz. (ounce) = 28.35 g
1 lb (pound weight) = 0.454 kg

Pressure: 1 psi (lb/in²) = 68.95 mb

Volume: 1 UK pint = 568.3 ml
1 UK gallon = 4.546 litres
1 US gallon = 3.785 litres

In addition, while most of the information in the manual is correct for all countries, certain information is specific to the North American market and so may not be applicable to European users.

Differences include the U.S standard external power supply details where some information (for example the AC transformer input voltage) will not be applicable for British/European use. *Please note, however, that when a power supply adapter is ordered it will be suitable for use in your country.*

Reference to some radio transmitters, digital cell phones and aerials may also not be applicable according to your locality.

Some brackets, shields and enclosure options, including wiring, are not sold as standard items in the European market; in some cases alternatives are offered. Details of the alternatives will be covered in separate manuals.

Part numbers prefixed with a “#” symbol are special order parts for use with non-EU variants or for special installations. Please quote the full part number with the # when ordering.

Recycling information



At the end of this product's life it should not be put in commercial or domestic refuse but sent for recycling. Any batteries contained within the product or used during the products life should be removed from the product and also be sent to an appropriate recycling facility.

Campbell Scientific Ltd can advise on the recycling of the equipment and in some cases arrange collection and the correct disposal of it, although charges may apply for some items or territories.

For further advice or support, please contact Campbell Scientific Ltd, or your local agent.



Campbell Scientific Ltd, Campbell Park, 80 Hathern Road, Shepshed, Loughborough, LE12 9GX, UK
Tel: +44 (0) 1509 601141 Fax: +44 (0) 1509 601091
Email: support@campbellsci.co.uk
www.campbellsci.co.uk

Contents

PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.

1. Function	1
2. Specifications	2
3. Connector Descriptions	2
3.1 RS-232	2
3.2 9 Pin	2
4. Operation.....	2
5. Application	3

Figure

1-1. SC32B Optically Isolated RS-232 Interface.....	1
---	---

Table

3-1. SC32B Connector Descriptions	2
---	---

SC32B Optically Isolated RS-232 Interface

1. Function



Figure 1-1. SC32B Optically Isolated RS-232 Interface

The SC32B interfaces an RS-232 peripheral, commonly a computer or terminal, to the CS I/O port of a Campbell Scientific datalogger. The SC32B has the same functions as the SC32A. Functions include:

1. Converting datalogger logic levels to RS-232 logic levels.
2. Optically isolating the datalogger and the RS-232 peripheral. Optical isolation separates the SC32B into a datalogger section and an RS-232 section. Signals entering from either side are electrically independent, protecting against ground loops, normal static discharge, and noise.
3. Passing data when modem enable pin 5 is high and SDE/printer enable pin 6 is low (normal telecommunications mode).

The SC32B blocks data sent out the datalogger CS I/O port when the SDE/print enable pin 6 is high. This prevents data sent to an SDE device (for example, storage module) or printer output from being sent out the RS-232 port. The SC32B cannot be configured to pass Instruction 96 serial printer or computer data. Contact Campbell Scientific if this capability is required.

2. Specifications

Operating Temperature:	-25° to +50°C (typical)
Power:	Powered by datalogger; see Section 4, <i>Operation</i>
Ports:	9 pin female RS-232 configured as DCE. 9 pin male CS I/O
Baud Rate:	1200 bps to 115.2 kbps; see Section 4, <i>Operation</i>
Size:	4.1 x 2.3 x 7.6 cm (1.6 x 0.9 x 3 in)
Weight:	45.4 g (1.6 oz)

3. Connector Descriptions

Table 3-1. SC32B Connector Descriptions					
RS-232 9 Pin Female Connector			CS I/O 9 Pin Male Connector		
Pin #	I/O	Description	Pin #	I/O	Description
1	Out	DCD	1	In	+5 V
2	Out	RXD	2		Ground
3	In	TXD	3	Out	Ring
4	In	DTR	4	Out	RX
5		Ground	5	In	ME
6	Out	DSR	6	In	PE (SDE)
7	In	RTS	7		No Connection
8	Out	CTS	8		No Connection
9		No Connection	9	In	TX

3.1 RS-232

The DB9 RS-232 port is configured as Data Communications Equipment (DCE) for direct cable connection to Data Terminal Equipment (DTE). Most computers are configured as DTE. For connection to DCE devices such as modems, the SC932 or SC932A should be used in place of the SC32B.

3.2 9 Pin

The CS I/O port connects to the datalogger through the SC12 Two Peripheral Cable supplied with the SC32B. Pin descriptions and direction (Input/Output) are given in Table 3-1.

4. Operation

Power for the SC32B datalogger section comes from the 5 V supply on pin 1 of the datalogger CS I/O. Communication logic levels to and from the datalogger are referenced to this voltage, ranging from 0 to slightly less than 5 V.

Power for the RS-232 section is isolated from the datalogger 5 V supply via a transformer/isolator. An on-board DC to DC converter supplies the negative voltage required for RS-232 signals.

When the SC32B first receives a character from the RS-232 peripheral (pin 3), 5 V is applied to the datalogger Ring line (pin 3) until the datalogger Modem Enable (ME) goes high, putting the datalogger into the Telecommunications Mode.

The SC32B does not perform baud rate translation. The data speed going out will match the data speed coming in. If you are having trouble communicating, check that the datalogger's CS I/O ME baud rate matches that being used by the computer/*LoggerNet*. When other devices are also connected to the datalogger's CS I/O port, it may be necessary to lower the baud rate used for the SC32B. If you encounter communication issues, consider starting at 9600. If communication is successful, you can increase the baud rate until communication problems return.

5. Application

The SC32B provides a direct interface between the CS I/O port on a Campbell Scientific datalogger and the RS-232 port on a computer. Some Campbell Scientific dataloggers (for example, the CR23X and CR5000) have a built-in RS-232 port in addition to the CS I/O port. With these dataloggers, the SC32B is only necessary if you wish to connect to the CS I/O port instead of the RS-232 port.

The SC32B blocks data sent out the CS I/O port when the datalogger sets the printer enable/SDE (pin 6) high. The SC932 or SC932A (CS I/O to RS-232 DTE interface) can be used to interface to an RS-232 modem.

CAMPBELL SCIENTIFIC COMPANIES

Campbell Scientific, Inc. (CSI)

815 West 1800 North
Logan, Utah 84321
UNITED STATES

www.campbellsci.com • info@campbellsci.com

Campbell Scientific Africa Pty. Ltd. (CSAf)

PO Box 2450
Somerset West 7129
SOUTH AFRICA

www.csafrica.co.za • sales@csafrica.co.za

Campbell Scientific Australia Pty. Ltd. (CSA)

PO Box 8108
Garbutt Post Shop
QLD 4814 AUSTRALIA

www.campbellsci.com.au • info@campbellsci.com.au

Campbell Scientific do Brazil Ltda. (CSB)

Rua Luisa Crapsi Orsi, 15 Butantã
CEP: 005543-000 São Paulo SP BRAZIL

www.campbellsci.com.br • suporte@campbellsci.com.br

Campbell Scientific Canada Corp. (CSC)

11564 - 149th Street NW
Edmonton, Alberta T5M 1W7
CANADA

www.campbellsci.ca • dataloggers@campbellsci.ca

Campbell Scientific Centro Caribe S.A. (CSCC)

300N Cementerio, Edificio Brelle
Santo Domingo, Heredia 40305
COSTA RICA

www.campbellsci.cc • info@campbellsci.cc

Campbell Scientific Ltd. (CSL)

Campbell Park
80 Hathern Road
Shephed, Loughborough LE12 9GX
UNITED KINGDOM

www.campbellsci.co.uk • sales@campbellsci.co.uk

Campbell Scientific Ltd. (France)

3 Avenue de la Division Leclerc
92160 ANTONY
FRANCE

www.campbellsci.fr • info@campbellsci.fr

Campbell Scientific Spain, S. L.

Avda. Pompeu Fabra 7-9
Local 1 - 08024 BARCELONA
SPAIN

www.campbellsci.es • info@campbellsci.es

Campbell Scientific Ltd. (Germany)

Fahrenheitstrasse 13, D-28359 Bremen
GERMANY

www.campbellsci.de • info@campbellsci.de

Please visit www.campbellsci.com to obtain contact information for your local US or International representative.