



# For Communication, Configuration, and Testing

## Overview

The A205 CWS-to-PC Interface supports communication between your wireless sensors and your computer. The A205 is necessary for configuring your wireless sensors prior to

deployment. You can also use the A205 to test and troubleshoot your wireless sensors.

## Detailed Description

The A205 has a four-pin connector that attaches to the four-pin male connector located behind the battery pack of a CWS sensor. The A205 connects with the computer via a USB port. When the A205 is connected to a computer's USB port, the interface supplies power to the wireless sensor.

## Specifications

Connectors	› Type B USB female	Dimensions	13.97 x 10.16 x 3.81 cm (5.5 x 4.0 x 1.5 in.)
	› Four-pin female		
		Weight	68.04 g (0.15 lb)

For comprehensive details, visit: [www.campbellsci.com/a205](http://www.campbellsci.com/a205) 