


CPEC200

Closed Path
Eddy Covariance System

Quick Deploy Guide




May 2014




CAMPBELL[®]
SCIENTIFIC
WHEN MEASUREMENTS MATTER


1. Setup tripod and mount enclosures.




2. Ground tripod and enclosures.




3. Setup tripod or mast with CM20X Crossarm.




4. Mount gas analyzer and sonic anemometer.




5. Connect EC155 and CSAT3A to EC100 Electronics.




6. Connect system plumbing.



7. Connect system wiring and insert compact flash (CF) card.






EC100
Power Cable

EC100 SDM
Cable

Power Cable to +12Vdc
Power Supply (off)


Power Cable
to EC100




SDM Cable to EC100

8. **Turn on the +12 Vdc power supply and use the datalogger keyboard display to set settings and initiate zero/span checks.** (Follow the steps from left to right, top to bottom).


8.1 Press <Esc> to activate the display. Press <Enter> to display the System Control Menu.




8.2 Select "Configure System."




8.3 Select "SONIC_AZIMU."




8.4 Enter the CSAT3A sonic head azimuth.




8.5 If the CPEC does not have a valve module, skip to the **8.10**. Otherwise, select "Zero/Span Config."




8.6 Select "CO2_SPAN.PP: 0.00000."




8.7 Set CO2_SPAN_PPM to CO2 tank concentration.




8.8 Select CHECK_ZERO, SET_ZERO, CHECK_SPAN1, SET_SPAN1 in sequence.




8.9 For each value selected on the previous screen, change the setting from "False" to "True" for auto zero/span.



8.10 Press <ESC> to exit.





Campbell Scientific (Canada) Corp.
14532 131 Avenue NW | Edmonton AB T5L 4X4
780.454.2505 | fax 780.454.2655 | campbellsci.ca

Please visit www.campbellsci.com to obtain contact information for your local US or International representative.