

# TE525-Series

## Tipping Bucket Rain Gage



# Table of contents

---

<b>1. Introduction</b> .....	<b>1</b>
<b>2. Precautions</b> .....	<b>1</b>
<b>3. Initial inspection</b> .....	<b>2</b>
<b>4. QuickStart</b> .....	<b>2</b>
<b>5. Overview</b> .....	<b>5</b>
5.1 Wind screen .....	5
5.2 Snowfall adapter .....	5
<b>6. Specifications</b> .....	<b>6</b>
<b>7. Installation</b> .....	<b>7</b>
7.1 Wiring to data logger .....	7
7.2 Data logger programming .....	8
7.3 Siting .....	8
7.4 Mounting .....	9
<b>8. Operation</b> .....	<b>12</b>
8.1 Sensor schematic .....	12
8.2 Measurement .....	12
<b>9. Troubleshooting and maintenance</b> .....	<b>12</b>
9.1 Troubleshooting .....	13
9.2 Maintenance .....	13
9.3 Calibration .....	13
<b>Appendix A. Importing Short Cut code into CRBasic Editor</b> .....	<b>15</b>
<b>Appendix B. Example program</b> .....	<b>16</b>
<b>Appendix C. Changing funnels with a different size</b> .....	<b>17</b>
C.1 TE525 and TE525MM .....	17
C.2 TE525WS .....	17

# 1. Introduction

---

The TE525-series tipping bucket rain gages are adaptations of the standard National Weather Service tipping bucket rain gages. They funnel rain into a mechanism that tips when filled to the calibrated level. The TE525 and TE525WS measure in 0.01-inch increments and the TE525MM measures in 0.1-mm increments. The TE525WS conforms to the National Weather Service recommendation for an 8-inch funnel orifice. The TE525 and TE525MM have an orifice diameter of 6 inch and 24.5 cm, respectively.

**NOTE:**

This manual provides information only for CRBasic data loggers. For retired Edlog data logger support, see an older manual at [www.campbellsci.com/old-manuals](http://www.campbellsci.com/old-manuals) .

## 2. Precautions

---

- READ AND UNDERSTAND the [Safety](#) section at the back of this manual.
- TE525-series tipping bucket rain gages are precision instruments that must be handled with care.
- Sensor is factory-calibrated and should not require field calibration. Refer to [Maintenance](#) (p. 13) for field calibration check and factory calibration.
- During field installation, ensure that you have removed the small rubber band that secures the tipping mechanism during shipping.
- Debris filters, funnel, and bucket reservoirs should be kept clean.
- Santoprene® rubber, which composes the black outer jacket of the TE525 cable, will support combustion in air. It is used because of its resistance to temperature extremes, moisture, and UV degradation. It is rated as slow burning when tested according to U.L. 94 H.B. and passes FMVSS302. However, local fire codes may preclude its use inside buildings.

## 3. Initial inspection

---

- Upon receipt, inspect the packaging and contents for damage. File damage claims with the shipping company.
- The model number and cable length are printed on a label at the connection end of the cable. Check this information against the shipping documents to ensure the correct product and cable length are received.

## 4. QuickStart

---


A video that describes data logger programming using *Short Cut* is available at:

[www.campbellsci.com/videos/cr1000x-data-logger-getting-started-program-part-3](http://www.campbellsci.com/videos/cr1000x-data-logger-getting-started-program-part-3) . *Short Cut* is an easy way to program your data logger to measure the sensor and assign data logger wiring terminals. *Short Cut* is available as a download on [www.campbellsci.com](http://www.campbellsci.com) . It is included in installations of *LoggerNet*, *RTDAQ*, and *PC400*.


The following procedure also describes programming with *Short Cut*.

1. Open *Short Cut* and click **Create New Program**.
2. Double-click the data logger model.

3. In the **Available Sensors and Devices** box, type TE525 or locate the sensor in the **Sensors > Meteorological > Precipitation** folder. Double click **TE525/TE525WS Rain Gauge** or **TE525MM/TE525M Rain Gauge**, depending on which model you have. Data defaults to millimeters. This can be changed by clicking the **mm** box and selecting **inch**.




4. Click the **Wiring** tab to see how the sensor is to be wired to the data logger. Click **OK** after wiring the sensor.




5. Repeat step three for other sensors being measured.

- In **Output Setup**, enter the scan rate, **Data Output Storage Intervals**, and meaningful table names.



- Select the measurement and its associated output options.



- Click **Finish** and save the program. Send the program to the data logger if the data logger is connected to the computer.
- If the sensor is connected to the data logger, check the output of the sensor in the data display in **LoggerNet**, **RTDAQ**, or **PC400** to make sure it is making reasonable measurements.

# 5. Overview

---

TE525-series tipping bucket rain gages funnel precipitation into a bucket mechanism that tips when filled to a calibrated level. A magnet attached to the tipping mechanism actuates a switch as the bucket tips. The momentary switch closure is counted by the pulse-counting circuitry of Campbell Scientific data loggers.

The TE525-series tipping bucket rain gages are manufactured by Texas Electronics and cabled by Campbell Scientific.

## Features:

- High precision
- Compatible with all Campbell Scientific data loggers
- TE525WS conforms to the National Weather Service recommendation for an 8-inch funnel orifice.
- TE525WS is directly compatible with the CS705 Snowfall Adapter, allowing it to measure the water content of snow.

## 5.1 Wind screen

Campbell Scientific offers the 260-953 Wind Screen to help minimize the effect of wind on rain measurements. This wind screen consists of 32 freely hanging leaves that swing as wind moves past them. Refer to the [260-953 manual](#) for siting information and the installation procedure.

## 5.2 Snowfall adapter

Campbell Scientific CS705 Snowfall Conversion Adapter uses antifreeze to melt snow, allowing the TE525WS to measure the water content of snow. The CS705 cannot be used with either the TE525 or TE525MM. However, both the TE525 and TE525MM can be converted to a TE525WS by returning them to Campbell Scientific (see [Assistance](#) page at the back of this document). Refer to the [CS705 manual](#) for siting information and the installation procedure.

# 6. Specifications

---

<b>Sensor type:</b>	Tipping bucket/potted magnetic momentary-contact reed switch
<b>Operating temperature range:</b>	0 to 50 °C
<b>Storage temperature range:</b>	-40 to 70 °C
<b>Switch ratings:</b>	30 VDC at 2 A 115 VAC at 1 A
<b>Closure time:</b>	135 ms
<b>Bounce settling time:</b>	0.75 ms
<b>Resolution:</b>	1 tip
<b>Accuracy:</b>	1.0% up to 2 in/hour (50 mm/hr)
<b>Materials</b>	
<b>Bucket:</b>	White powder-coated spun aluminum
<b>Funnel collector:</b>	Gold anodized spun aluminum
<b>Screen:</b>	Gold anodized spun aluminum
<b>Locking snap ring:</b>	Stainless steel
<b>Tipping mechanism:</b>	UV protected black ABS plastic with hardened stainless steel jewel bearings and pivot
<b>Cable:</b>	2-conductor shielded cable (length must be specified for all -L options at time of order)
<b>Cable weight:</b>	0.1 kg (0.2 lb) per 10 ft
<b>Mounting:</b>	Gold anodized aluminum side bracket with adjustable pipe clamps for pole or mast mounting

	TE525	TE525WS	TE525MM
Volume per tip <sup>1</sup>	4.73 ml (0.16 fl. oz)	8.24 ml (0.28 fl. oz)	4.73 ml (0.16 fl. oz)
Rainfall per tip	0.01 in (0.254 mm)	0.01 in (0.254 mm)	0.1 mm (0.004 in)
Funnel collector diameter <sup>2</sup>	15.4 cm (6.060 in)	20.3 cm (8 in)	24.5 cm (9.7 in)
Height	24.1 cm (9.5 in)	26.7 cm (10.5 in)	29.2 cm (11.5 in)
Tipping bucket weight	0.9 kg (2 lb)	1 kg (2.2 lb)	1.1 kg (2.4 lb)

<sup>1</sup>The volume of water required to cause a tip in the TE525 and the TE525MM is the same. The difference in calibration is strictly due to funnel size.

<sup>2</sup>If the CS705 Snowfall Adapter or other eight-inch funnel is installed on these gages, refer to [Table 7-2](#) (p. 8) for the multiplier. See [Changing funnels with a different size](#) (p. 17) before replacing funnels on any TE525 tipping bucket rain gage with a different size funnel.

## 7. Installation

If you are programming your data logger with *Short Cut*, skip [Wiring to data logger](#) (p. 7) and [Data logger programming](#) (p. 8). *Short Cut* does this work for you. See [QuickStart](#) (p. 2) for a *Short Cut* tutorial.

### 7.1 Wiring to data logger

Wire color	Wire function	Data logger connection
Black	Rain signal	P or U <sup>1</sup> (pulse terminal)
White	Rain signal reference	⏏ (analog ground)
Clear	Shield	⏏ (analog ground)

<sup>1</sup>U terminals are automatically configured by the measurement instruction.

## 7.2 Data logger programming

*Short Cut* is the best source for up-to-date programming code for Campbell Scientific data loggers. If your data acquisition requirements are simple, you can probably create and maintain a data logger program exclusively with *Short Cut*. If your data acquisition needs are more complex, the files that *Short Cut* creates are a great source for programming code to start a new program or add to an existing custom program.

**NOTE:**

*Short Cut* cannot edit programs after they are imported and edited in *CRBasic Editor*.

A *Short Cut* tutorial is available in [QuickStart](#) (p. 2). If you wish to import *Short Cut* code into *CRBasic Editor* to create or add to a customized program, follow the procedure in [Importing Short Cut code into CRBasic Editor](#) (p. 15). This section provides programming basics for CRBasic data loggers. A complete program example can be found in [Example program](#) (p. 16).

The [PulseCount\(\)](#) instruction programs CRBasic data loggers to measure the TE525 rain gage.

[PulseCount](#)(Dest,Reps,PChan,PConfig,POption,Mult,Offset)

- Choose Switch Closure for the **PConfig** parameter. For the CR6 and CR1000X, choose Switch Closure with pull up.
- The **Multiplier** parameter determines the units in which rainfall is reported ([Table 7-2](#) (p. 8)).

Rain gage	Inches	Millimeters
TE525	0.01	0.254
TE525WS	0.01	0.254
TE525MM	0.00394	0.1
TE525 or TE525MM w/8 in funnel	0.0057	0.1459

## 7.3 Siting

Mount the rain gage in a relatively level spot representative of the surrounding area. Ensure that the lip of the funnel is horizontal, at least 30 cm above the ground, and higher than the average snow depth.

Place the rain gage away from objects that obstruct the wind. The distance should be two to four times the height of the obstruction.

## 7.4 Mounting

The TE525 includes hose clamps to mount the gage to a 1-inch to 2-inch IPS vertical pole. For additional stability and better leveling capabilities, the CM270 leveling base can be used instead (FIGURE 7-1 (p. 9)). This leveling base is included with the CM705 Snowfall Adapter, but can be purchased separately. The CM270 is compatible with a pole with an outer diameter of 2 inches or less. For more information, see CM270 Installation Guide at <https://s.campbellsci.com/documents/us/technical-papers/cm270.pdf>.



*FIGURE 7-1. CM270 Rain Gage Mount attaches to the base of a TE525-series rain gage to give added stability*

Both the hose clamps and the CM270 leveling base can mount to the CM300 series mounting poles. The models are stainless steel 1.5 IPS vertical poles of different lengths (Table 7-3 (p. 9)).

Model	Pole length
CM300	58 cm (23 in)
CM305	119 cm (47 in)
CM310	142 cm (56 in)

The pole or pipe can be attached to a concrete foundation using J-bolts or self supporting legs (7.4 (p. 9)) or placed directly into a concrete foundation (FIGURE 7-3 (p. 11)). A concrete pad is recommended, but it should not be installed over a large paved or concrete surface.



*FIGURE 7-2. Mounting pole base options*




FIGURE 7-3. TE525 Tipping Bucket Rain Gage

Mount the gage with its lip at least 5 cm (2 in) above the post or pole (FIGURE 7-3 (p. 11)). The mounting pole must be vertical. Use a torpedo level to get the pole as vertical as possible.

The rain gage has a bubble level to ensure it is level. To access the bubble level, loosen the thumbscrews holding the funnel on the bucket and then take the funnel off the top of the bucket. The bubble level is inside the bucket toward the bottom. Center the bubble level while mounting the bucket to the pole.

While the funnel is off the bucket, remove the small rubber band securing the tipping bucket, which protects it during shipping. Seat the funnel back on to the rain gage, and push the funnel all the way down until it is fully seated on the main body. Hand tighten the thumb screws (if present) to secure the funnel to the body.

**NOTE:**

Press either end of the bucket down against its stop to make sure the bucket is NOT hung up in the center beforehand tightening the thumb screws.

# 8. Operation

---

## 8.1 Sensor schematic

Campbell Scientific installs a 100  $\Omega$  resistor, connected in series, at the switch to prevent arcing by limiting current (FIGURE 8-1 (p. 12)).




FIGURE 8-1. TE525-series rain gage schematic

## 8.2 Measurement

Campbell Scientific data loggers measure TE525 rain gages by counting switch closures and converting the total to rainfall. The [PulseCount\(\)](#) instruction employs dedicated pulse count accumulators, which continuously monitor the input signal, even when the data logger is between program scans. To create a pulse, an internal 100 k $\Omega$  pull-up resistor pulls the pulse input to 5 VDC when the switch is open, and a switch closure to ground pulls the input to 0 VDC.

# 9. Troubleshooting and maintenance

---

**NOTE:**

All factory repairs and recalibrations require a returned material authorization (RMA) and completion of the "Declaration of Hazardous Material and Decontamination" form. Refer to the [Assistance](#) page at the back of this manual for more information.

# 9.1 Troubleshooting

Symptom: No Precipitation

1. Check that the sensor is wired to the pulse terminal specified by the **PulseCount()** instruction.
2. Verify that the **Configuration Code** (switch closure) and **Multiplier** parameters for the **PulseCount()** instruction are correct.
3. Disconnect the sensor from the data logger and use an ohmmeter to do a continuity check of the switch. The resistance measured at the terminal block on the inside of the bucket between the black and white wires should vary from infinite (switch open) when the bucket is tipped, to less than an ohm (switch closed) when the bucket is balanced.

# 9.2 Maintenance

The funnel and bucket mechanism must be kept clean. Routinely check for and remove debris such as leaves, dust, or insects.

# 9.3 Calibration

A field calibration check is advised every 12 months.

**Field calibration check:**

1. Secure a can or bottle that will hold at least 16 oz of water.
2. Punch a very small hole in the bottom of the can or bottle. If it takes less than 45 minutes for 16 oz of water to run out, the hole in the can is too large.
3. Place the can in the top funnel of the rain gage and pour 16 fluid ounces of water into the can. (A 16 oz soft drink bottle filled to within 2.5 inches of the top may be used for a rough field calibration. An exact volume will allow for a more precise calibration.)
4. The following number of tips should occur:

TE525, TE525MM  $100 \pm 3$

TE525WS  $57 \pm 2$

5. Adjusting screws are located on the bottom adjacent to the large center drain hole. Adjust both screws the same number of turns. Rotation clockwise increases the number of tips per 16 oz. of water; counter clockwise rotation decreases the number of tips per 16 oz. of water. One half turn of both screws causes a 2% to 3% change.
6. Check and re-level the rain gage.

**Factory calibration:**

If factory calibration is required, contact Campbell Scientific to obtain an RMA (see [Assistance](#) at back of manual).

# Appendix A. Importing *Short Cut* code into *CRBasic Editor*

---

*Short Cut* creates a .DEF file that contains wiring information and a program file that can be imported into the *CRBasic Editor*. By default, these files reside in the C:\campbellsci\SCWin folder.

Import *Short Cut* program file and wiring information into *CRBasic Editor*:

1. Create the *Short Cut* program. After saving the *Short Cut* program, click the **Advanced** tab then the **CRBasic Editor** button. A program file with a generic name will open in CRBasic. Provide a meaningful name and save the CRBasic program. This program can now be edited for additional refinement.

**NOTE:**

Once the file is edited with *CRBasic Editor*, *Short Cut* can no longer be used to edit the program it created.

2. To add the *Short Cut* wiring information into the new CRBasic program, open the .DEF file located in the C:\campbellsci\SCWin folder, and copy the wiring information, which is at the beginning of the .DEF file.
3. Go into the CRBasic program and paste the wiring information into it.
4. In the CRBasic program, highlight the wiring information, right-click, and select **Comment Block**. This adds an apostrophe (') to the beginning of each of the highlighted lines, which instructs the data logger compiler to ignore those lines when compiling. The **Comment Block** feature is demonstrated at about 5:10 in the [CRBasic | Features](#) video .

# Appendix B. Example program

## CRBasic Example 1: CR1000X program measuring the TE525 or TE525WS using a pulse terminal

*'Program records precipitation from one TE525 or TE525WS Rain Gage once a second and stores the total every 60 minutes*

*'Wiring Diagram*

*'=====*  
*'TE525 or TE525WS*

<i>' Wire</i>	<i>' Color</i>	<i>' Function</i>	<i>' CR1000X</i>
<i>' -----</i>	<i>' -----</i>	<i>' -----</i>	<i>' -----</i>
<i>' Black</i>	<i>' Pulse Output</i>	<i>' P1</i>	
<i>' White</i>	<i>' Ground</i>	<i>' ⚡</i>	
<i>' Clear</i>	<i>' Shield</i>	<i>' ⚡</i>	

*'Declare the variables and units for the rain measurement*

**Public** Rain\_mm

**Units** Rain\_mm=mm

**DataTable**(Rain,True,-1)

**DataInterval**(0,60,Min,0)

**Totalize**(1,Rain\_mm,FP2,0)

**EndTable**

**BeginProg**

**Scan**(1,Sec,1,0)

**PulseCount**(Rain\_mm,1,P1,1,0,0.254,0)

*'For TE525MM Rain Gage, use multiplier of 0.1 in PulseCount instruction*

*'Call Data Table*

**CallTable**(Rain)

**NextScan**

**EndProg**

# Appendix C. Changing funnels with a different size

---

## C.1 TE525 and TE525MM

The TE525 and TE525MM rain gages use the same tipping mechanism that is calibrated to tip with the same amount of water. Changing the funnel does not necessitate changing the tipping mechanism, but it does require changing the multiplier in the data logger program to match the funnel size. See [Table 7-2](#) (p. 8) for the correct multiplier.

## C.2 TE525WS

The TE525WS rain gage uses a different tipping mechanism that is calibrated differently than the TE525 or TE525MM. The tipping mechanism must be replaced to work with a TE525 or TE525MM funnel. Send the rain bucket into the Campbell Scientific repair department for modifications. Contact Campbell Scientific to obtain an RMA (see [Assistance](#) at back of manual).

# Limited warranty

---

Products manufactured by Campbell Scientific are warranted by Campbell Scientific to be free from defects in materials and workmanship under normal use and service for three years from the date of shipment unless otherwise specified on the corresponding product webpage. See Product Details on the Ordering Information pages at [www.campbellsci.com](http://www.campbellsci.com). Other manufacturer's products, that are resold by Campbell Scientific, are warranted only to the limits extended by the original manufacturer.

Refer to [www.campbellsci.com/terms#warranty](http://www.campbellsci.com/terms#warranty) for more information.

**CAMPBELL SCIENTIFIC EXPRESSLY DISCLAIMS AND EXCLUDES ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** Campbell Scientific hereby disclaims, to the fullest extent allowed by applicable law, any and all warranties and conditions with respect to the Products, whether express, implied or statutory, other than those expressly provided herein.

# Assistance

---

Products may not be returned without prior authorization.

Products shipped to Campbell Scientific require a Returned Materials Authorization (RMA) or Repair Reference number and must be clean and uncontaminated by harmful substances, such as hazardous materials, chemicals, insects, and pests. Please complete the required forms prior to shipping equipment.

Campbell Scientific regional offices handle repairs for customers within their territories. Please see the back page for the Global Sales and Support Network or visit [www.campbellsci.com/contact](http://www.campbellsci.com/contact)  to determine which Campbell Scientific office serves your country.

To obtain a Returned Materials Authorization or Repair Reference number, contact your CAMPBELL SCIENTIFIC regional office. Please write the issued number clearly on the outside of the shipping container and ship as directed.

For all returns, the customer must provide a "Statement of Product Cleanliness and Decontamination" or "Declaration of Hazardous Material and Decontamination" form and comply with the requirements specified in it. The form is available from your CAMPBELL SCIENTIFIC regional office. Campbell Scientific is unable to process any returns until we receive this statement. If the statement is not received within three days of product receipt or is incomplete, the product will be returned to the customer at the customer's expense. Campbell Scientific reserves the right to refuse service on products that were exposed to contaminants that may cause health or safety concerns for our employees.

# Safety

---

**DANGER** — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND **TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.** FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at [www.campbellsci.com](http://www.campbellsci.com). You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified engineer. If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

## General

- Protect from over-voltage.
- Protect electrical equipment from water.
- Protect from electrostatic discharge (ESD).
- Protect from lightning.
- Prior to performing site or installation work, obtain required approvals and permits. Comply with all governing structure-height regulations.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a **hardhat** and **eye protection**, and take **other appropriate safety precautions** while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

## Utility and Electrical

- **You can be killed** or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in **contact with overhead or underground utility lines**.
- Maintain a distance of at least one-and-one-half times structure height, 6 meters (20 feet), or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.
- Only use power sources approved for use in the country of installation to power Campbell Scientific devices.

## Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

## Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

## Internal Battery

- Be aware of fire, explosion, and severe-burn hazards.
- Misuse or improper installation of the internal lithium battery can cause severe injury.
- Do not recharge, disassemble, heat above 100 °C (212 °F), solder directly to the cell, incinerate, or expose contents to water. Dispose of spent batteries properly.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CUSTOMER ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.



## Global Sales & Support Network

A worldwide network to help meet your needs



### Campbell Scientific Regional Offices

#### Australia

**Location:** Garbutt, QLD Australia  
**Phone:** 61.7.4401.7700  
**Email:** [info@campbellsci.com.au](mailto:info@campbellsci.com.au)  
**Website:** [www.campbellsci.com.au](http://www.campbellsci.com.au)

#### Brazil

**Location:** São Paulo, SP Brazil  
**Phone:** 11.3732.3399  
**Email:** [vendas@campbellsci.com.br](mailto:vendas@campbellsci.com.br)  
**Website:** [www.campbellsci.com.br](http://www.campbellsci.com.br)

#### Canada

**Location:** Edmonton, AB Canada  
**Phone:** 780.454.2505  
**Email:** [dataloggers@campbellsci.ca](mailto:dataloggers@campbellsci.ca)  
**Website:** [www.campbellsci.ca](http://www.campbellsci.ca)

#### China

**Location:** Beijing, P. R. China  
**Phone:** 86.10.6561.0080  
**Email:** [info@campbellsci.com.cn](mailto:info@campbellsci.com.cn)  
**Website:** [www.campbellsci.com.cn](http://www.campbellsci.com.cn)

#### Costa Rica

**Location:** San Pedro, Costa Rica  
**Phone:** 506.2280.1564  
**Email:** [info@campbellsci.com](mailto:info@campbellsci.com)  
**Website:** [www.campbellsci.com](http://www.campbellsci.com)

#### France

**Location:** Vincennes, France  
**Phone:** 0033.0.1.56.45.15.20  
**Email:** [info@campbellsci.fr](mailto:info@campbellsci.fr)  
**Website:** [www.campbellsci.fr](http://www.campbellsci.fr)

#### Germany

**Location:** Bremen, Germany  
**Phone:** 49.0.421.460974.0  
**Email:** [info@campbellsci.de](mailto:info@campbellsci.de)  
**Website:** [www.campbellsci.de](http://www.campbellsci.de)

#### India

**Location:** New Delhi, DL India  
**Phone:** 91.11.46500481.482  
**Email:** [info@campbellsci.in](mailto:info@campbellsci.in)  
**Website:** [www.campbellsci.in](http://www.campbellsci.in)

#### South Africa

**Location:** Stellenbosch, South Africa  
**Phone:** 27.21.8809960  
**Email:** [sales@campbellsci.co.za](mailto:sales@campbellsci.co.za)  
**Website:** [www.campbellsci.co.za](http://www.campbellsci.co.za)

#### Spain

**Location:** Barcelona, Spain  
**Phone:** 34.93.2323938  
**Email:** [info@campbellsci.es](mailto:info@campbellsci.es)  
**Website:** [www.campbellsci.es](http://www.campbellsci.es)

#### Thailand

**Location:** Bangkok, Thailand  
**Phone:** 66.2.719.3399  
**Email:** [info@campbellsci.asia](mailto:info@campbellsci.asia)  
**Website:** [www.campbellsci.asia](http://www.campbellsci.asia)

#### UK

**Location:** Shepshed, Loughborough, UK  
**Phone:** 44.0.1509.601141  
**Email:** [sales@campbellsci.co.uk](mailto:sales@campbellsci.co.uk)  
**Website:** [www.campbellsci.co.uk](http://www.campbellsci.co.uk)

#### USA

**Location:** Logan, UT USA  
**Phone:** 435.227.9120  
**Email:** [info@campbellsci.com](mailto:info@campbellsci.com)  
**Website:** [www.campbellsci.com](http://www.campbellsci.com)