

INSTRUCTION MANUAL



SC32B Optically Isolated RS-232 Interface

Revision: 2/03

Copyright (c) 1987-2003
Campbell Scientific, Inc.

Warranty and Assistance

The **SC32B OPTICALLY ISOLATED RS-232 INTERFACE** is warranted by CAMPBELL SCIENTIFIC, INC. to be free from defects in materials and workmanship under normal use and service for twelve (12) months from date of shipment unless specified otherwise. Batteries have no warranty. CAMPBELL SCIENTIFIC, INC.'s obligation under this warranty is limited to repairing or replacing (at CAMPBELL SCIENTIFIC, INC.'s option) defective products. The customer shall assume all costs of removing, reinstalling, and shipping defective products to CAMPBELL SCIENTIFIC, INC. CAMPBELL SCIENTIFIC, INC. will return such products by surface carrier prepaid. This warranty shall not apply to any CAMPBELL SCIENTIFIC, INC. products which have been subjected to modification, misuse, neglect, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for a particular purpose. CAMPBELL SCIENTIFIC, INC. is not liable for special, indirect, incidental, or consequential damages.

Products may not be returned without prior authorization. The following contact information is for US and International customers residing in countries served by Campbell Scientific, Inc. directly. Affiliate companies handle repairs for customers within their territories. Please visit www.campbellsci.com to determine which Campbell Scientific company serves your country. To obtain a Returned Materials Authorization (RMA), contact CAMPBELL SCIENTIFIC, INC., phone (435) 753-2342. After an applications engineer determines the nature of the problem, an RMA number will be issued. Please write this number clearly on the outside of the shipping container. CAMPBELL SCIENTIFIC's shipping address is:

CAMPBELL SCIENTIFIC, INC.

RMA# _____
815 West 1800 North
Logan, Utah 84321-1784

CAMPBELL SCIENTIFIC, INC. does not accept collect calls.

SC32B Table of Contents

PDF viewers note: These page numbers refer to the printed version of this document. Use the Adobe Acrobat® bookmarks tab for links to specific sections.

1. Function	1
2. Specifications	1
3. Connector Descriptions	2
3.1 RS-232	2
3.2 9 Pin.....	2
4. Operation	2
5. Application	3

SC32B Optically Isolated RS-232 Interface



1. Function

The SC32B interfaces an RS-232 peripheral, commonly a computer or terminal, to the CS I/O of a CSI datalogger. The SC32B has the same functions as the SC32A. Functions include:

1. Converting datalogger logic levels to RS-232 logic levels.
2. Optically isolating the datalogger and the RS-232 peripheral. Optical isolation separates the SC32B into a datalogger section and an RS-232 section. Signals entering from either side are electrically independent, protecting against ground loops, normal static discharge, and noise.
3. Passing data when modem enable pin 5 is high and SDE/printer enable pin 6 is low (normal telecommunications mode).

The SC32B blocks data sent out the datalogger CS I/O port when the SDE/print enable pin 6 is high. This prevents data sent to an SDE device (e.g., storage module) or printer output from being sent out the RS-232 port. The SC32B cannot be configured to pass Instruction 96 serial printer or computer data. Contact CSI if this capability is required.

2. Specifications

Operating temperature: -25 to +50°C (typical)

Power: Powered by datalogger, see "Operation" section

Ports: 9 pin female RS-232 configured as DCE. 9 pin male CS I/O

Size: 1.6" x 0.9" x 3" (4.1 x 2.3 x 7.6 cm)

Weight: 1.6 oz. (45.4 g)

3. Connector Descriptions

TABLE 3-1. SC32B Connector Descriptions					
RS-232 9 Pin Female Connector			CS I/O 9 Pin Male Connector		
Pin #	I/O	Description	Pin #	I/O	Description
1	Out	DCD	1	In	+5 V
2	Out	RXD	2		Ground
3	In	TXD	3	Out	Ring
4	In	DTR	4	Out	RX
5		Ground	5	In	ME
6	Out	DSR	6	In	PE (SDE)
7	In	RTS	7		No Connection
8	Out	CTS	8		No Connection
9		No Connection	9	In	TX

3.1 RS-232

The DB9 RS-232 port is configured as Data Communications Equipment (DCE) for direct cable connection to Data Terminal Equipment (DTE). Most computers are configured as DTE. For connection to DCE devices such as modems, the SC932 or SC932A should be used in place of the SC32B.

3.2 9 Pin

The CS I/O port connects to the datalogger through the SC12 Two Peripheral Cable supplied with the SC32B. Pin descriptions and direction (Input/Output) are given in Table 3-1.

4. Operation

Power for the SC32B datalogger section comes from the 5 V supply on pin 1 of the datalogger CS I/O. Communication logic levels to and from the datalogger are referenced to this voltage, ranging from 0 to slightly less than 5 V.

Power for the RS-232 section is isolated from the datalogger 5 V supply via a transformer/isolator. An on-board DC to DC converter supplies the negative voltage required for RS-232 signals.

When the SC32B first receives a character from the RS-232 peripheral (pin 3), 5 V is applied to the datalogger Ring line (pin 3) until the datalogger Modem Enable (ME) goes high, putting the datalogger into the Telecommunications Mode.

5. Application

The SC32B provides a direct interface between the CS I/O port on a Campbell Scientific datalogger and the RS-232 port on a computer. Some Campbell Scientific dataloggers (e.g., the CR23X and CR5000) have a built-in RS-232 port in addition to the CS I/O port. With these dataloggers the SC32B is only necessary if you wish to connect to the CS I/O port instead of the RS-232 port.

The SC32B blocks data sent out the CS I/O port when the datalogger sets the printer enable/SDE (pin 6) high. The SC932 or SC932A (CS I/O to RS-232 DTE interface) can be used to interface to an RS-232 modem.

Campbell Scientific Companies

Campbell Scientific, Inc. (CSI)

815 West 1800 North
Logan, Utah 84321
UNITED STATES
www.campbellsci.com
info@campbellsci.com

Campbell Scientific Africa Pty. Ltd. (CSAf)

PO Box 2450
Somerset West 7129
SOUTH AFRICA
www.csafrica.co.za
sales@csafrica.co.za

Campbell Scientific Australia Pty. Ltd. (CSA)

PO Box 444
Thuringowa Central
QLD 4812 AUSTRALIA
www.campbellsci.com.au
info@campbellsci.com.au

Campbell Scientific do Brazil Ltda. (CSB)

Rua Luisa Crapsi Orsi, 15 Butantã
CEP: 005543-000 São Paulo SP BRAZIL
www.campbellsci.com.br
suporte@campbellsci.com.br

Campbell Scientific Canada Corp. (CSC)

11564 - 149th Street NW
Edmonton, Alberta T5M 1W7
CANADA
www.campbellsci.ca
dataloggers@campbellsci.ca

Campbell Scientific Ltd. (CSL)

Campbell Park
80 Hathern Road
Shepshed, Loughborough LE12 9GX
UNITED KINGDOM
www.campbellsci.co.uk
sales@campbellsci.co.uk

Campbell Scientific Ltd. (France)

Miniparc du Verger - Bat. H
1, rue de Terre Neuve - Les Ulis
91967 COURTABOEUF CEDEX
FRANCE
www.campbellsci.fr
campbell.scientific@wanadoo.fr

Campbell Scientific Spain, S. L.

Psg. Font 14, local 8
08013 Barcelona
SPAIN
www.campbellsci.es
info@campbellsci.es