

INSTRUCTION MANUAL



015ARM, CM225, CM255, CM255LS Solar Radiation Sensor Mounts

5/16



Copyright © 2016
Campbell Scientific, Inc.

WARRANTY AND ASSISTANCE

This equipment is warranted by CAMPBELL SCIENTIFIC (CANADA) CORP. ("CSC") to be free from defects in materials and workmanship under normal use and service for **twelve (12) months** from date of shipment unless specified otherwise. ***** **Batteries are not warranted.** ***** CSC's obligation under this warranty is limited to repairing or replacing (at CSC's option) defective products. The customer shall assume all costs of removing, reinstalling, and shipping defective products to CSC. CSC will return such products by surface carrier prepaid. This warranty shall not apply to any CSC products which have been subjected to modification, misuse, neglect, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for a particular purpose. CSC is not liable for special, indirect, incidental, or consequential damages.

Products may not be returned without prior authorization. To obtain a Return Merchandise Authorization (RMA), contact CAMPBELL SCIENTIFIC (CANADA) CORP., at (780) 454-2505. An RMA number will be issued in order to facilitate Repair Personnel in identifying an instrument upon arrival. Please write this number clearly on the outside of the shipping container. Include description of symptoms and all pertinent details.

CAMPBELL SCIENTIFIC (CANADA) CORP. does not accept collect calls.

Non-warranty products returned for repair should be accompanied by a purchase order to cover repair costs.



Campbell Scientific (Canada) Corp.
14532 131 Avenue NW | Edmonton AB T5L 4X4
780.454.2505 | fax 780.454.2655 | campbellsci.ca

Assistance

Products may not be returned without prior authorization. The following contact information is for Canadian and international clients residing in countries served by Campbell Scientific (Canada) Corp. directly. Affiliate companies handle repairs for clients within their territories. Please visit www.campbellsci.ca to determine which Campbell Scientific company serves your country.

To obtain a Returned Materials Authorization (RMA), contact CAMPBELL SCIENTIFIC (CANADA) CORP., phone (780) 454-2505. After a measurement consultant determines the nature of the problem, an RMA number will be issued. Please write this number clearly on the outside of the shipping container. Campbell Scientific's shipping address is:

CAMPBELL SCIENTIFIC (CANADA) CORP.

RMA# _____
14532 131 Avenue NW
Edmonton, Alberta T5L 4X4
Canada

For all returns, the client must fill out a "Statement of Product Cleanliness and Decontamination" form and comply with the requirements specified in it. The form is available from our web site at www.campbellsci.ca/repair. A completed form must be either emailed to repair@campbellsci.ca or faxed to (780) 454-2655. Campbell Scientific (Canada) Corp. is unable to process any returns until we receive this form. If the form is not received within three days of product receipt or is incomplete, the product will be returned to the client at the client's expense. Campbell Scientific (Canada) Corp. reserves the right to refuse service on products that were exposed to contaminants that may cause health or safety concerns for our employees.

Precautions

DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC. FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at www.campbellsci.ca or by telephoning (780) 454-2505 (Canada). You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified personnel (e.g. engineer). If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

General

- Prior to performing site or installation work, obtain required approvals and permits.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a **hardhat** and **eye protection**, and take **other appropriate safety precautions** while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

Utility and Electrical

- **You can be killed** or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in **contact with overhead or underground utility lines**.
- Maintain a distance of at least one-and-one-half times structure height, 6 meters (20 feet), or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.

Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CLIENT ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.

PLEASE READ FIRST

About this manual

Please note that this manual was originally produced by Campbell Scientific Inc. (CSI) primarily for the US market. Some spellings, weights and measures may reflect this origin.

Some useful conversion factors:

Area:	1 in ² (square inch) = 645 mm ²
Length:	1 in. (inch) = 25.4 mm
	1 ft (foot) = 304.8 mm
	1 yard = 0.914 m
	1 mile = 1.609 km
Mass:	1 oz. (ounce) = 28.35 g
	1 lb (pound weight) = 0.454 kg
Pressure:	1 psi (lb/in ²) = 68.95 mb
Volume:	1 US gallon = 3.785 litres

In addition, part ordering numbers may vary. For example, the CABLE5CBL is a CSI part number and known as a FIN5COND at Campbell Scientific Canada (CSC). CSC Technical Support will be pleased to assist with any questions.

About sensor wiring

Please note that certain sensor configurations may require a user supplied jumper wire. It is recommended to review the sensor configuration requirements for your application and supply the jumper wire is necessary.

Table of Contents

PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.

1. Introduction	1
2. Precautionary Statements	1
3. Initial Inspection.....	1
4. Overview	2
5. Specifications.....	3
6. Installation	4
6.1 Siting.....	4
6.2 Installation.....	5
7. Maintenance	7

Figures

1-1. Pyranometer Mounting Brackets.....	1
4-1. CM255 mounted level and at an angle.....	2
6-1. Solar sensor placement.....	4
6-2. Mounting hole locations for solar sensors.....	5
6-3. 015ARM and CM255 showing U-bolt mounting.....	6
6-4. CM255LS.....	7

015ARM, CM225, CM255, CM255LS Solar Radiation Sensor Mounts

1. Introduction

The 015ARM, CM225, CM255, and CM255LS solar radiation sensor mounts are designed to be mounted on a mast, crossarm, or pole. The mounting holes on the top plate allow a wide variety of sensors to be mounted.

The 015ARM mounts to a vertical mast or tripod. The CM225 is designed to be mounted either horizontally to a crossarm or vertically to a mast or a pole to keep the mounting plate level. The CM255 and CM255LS can also be mounted horizontally or vertically, but include a 90° adjustment. This allows the mount to be positioned at different angles, as shown in FIGURE 1-1.



FIGURE 1-1. Pyranometer Mounting Brackets

2. Precautionary Statements

- READ AND UNDERSTAND the [Safety](#) section at the front of this manual.
- WARNING — Ensure the mounting bracket is securely fastened during setup and weather extremes to minimize the chance of damaging the instruments. Read all instructions carefully.

3. Initial Inspection

- Upon receiving the solar radiation sensor mount, inspect the packaging and contents for damage. Claims for shipping damage must be filed with the shipping company.
- Locate the packing slip for the order and compare the items listed on the packing slip to the items that were actually shipped. Report any discrepancies to Campbell Scientific.

4. Overview

Campbell Scientific solar radiation sensor mounts provide a stable mounting platform for a pyranometer, quantum sensor, or radiometer. The flexibility in these designs allows a sensor to be mounted to a horizontal crossarm, or to a vertical mast or tower. With the 015ARM, the sensor is mounted away from the vertical pipe, allowing for a more unobstructed view of the sky. The CM255 and CM255LS may be mounted at different angles, depending on the user's needs (FIGURE 4-1).







FIGURE 4-1. CM255 mounted level and at an angle

5. Specifications

Mount		Description	Compatible Sensors ¹	Mounts to
015ARM Solar Sensor Mounting Arm		Consists of a square platform, mounting arm, and mounting hardware. Platform area is 15.2 x 15.2 cm (6.0 x 6.0 in), arm length is 106.7 cm (42.0 in), and weight is 2.5 kg (5.5 lb).	CS300 ² , LI200X ² , LI200S ² , LI190R ² , CMP3, CMP6 ³ , CMP11 ³ , CMP21 ³ , LP02	tripod or tower mast or user-supplied pipe with 1 in. to 1.5 in. OD
CM225 Solar Sensor Mounting Stand		Consists of a rectangular plate, mounting bracket, and mounting hardware. Dimensions are 8.9 x 11.3 x 6.4 cm (3.5 x 4.5 x 2.5 in), and weight is 0.34 kg (0.75 lb).	CS300 ² , LI200X ² , LI200S ² , LI190R ² , CMP3, CMP6 ³ , CMP11 ³ , CMP21 ³ , LP02, SP-LITE2, PQS1	U-bolt in bottom holes CM202, CM202SS, CM203, CM204, CM204SS, or CM206 crossarm U-bolt in side holes tripod or tower mast or user-supplied pipe with 1 in. to 1.5 in. OD
CM255 Adjustable Angle, Mounting Stand		Includes slots that can be adjusted to any angle from horizontal to vertical. Dimensions are 15.88 x 10.8 x 9.53 cm (6.25 x 4.25 x 3.75 in), and weight is 0.57 kg (1.25 lb).	CS300 ² , LI200X ² , LI200S ² , LI190R ² , CMP3, CMP6 ³ , CMP11 ³ , CMP21 ³ , LP02, SP-LITE2, PQS1 (not compatible with rotating shadowband radiometers (RSRs))	CM202, CM202SS, CM203, CM204, CM204SS, or CM206 crossarm, mast, or user-supplied pipe with a 1.0 in. to 2.1 in. OD
CM255LS Fully Adjustable Solar Sensor Mounting Stand with Leveling Screws		Includes leveling screws that allow leveling in a horizontal position and then pivoting or tilting to the correct azimuth. Dimensions are 15.88 x 10.8 x 15.88 cm (6.25 x 4.25 x 6.25 in), and weight is 0.61 kg (1.35 lb).	CS300 ² , LI200X ² , LI200S ² , LI190R ² , CMP3, CMP6 ³ , CMP11 ³ , CMP21 ³ , LP02, SP-LITE2, PQS1, SR20-T2-L ⁴ (not compatible with RSRs)	CM202, CM202SS, CM203, CM204, CM204SS, or CM206 crossarm, mast, or user-supplied pipe with a 1.0 in. to 2.1 in. OD
¹ Retired sensors may also be compatible. Contact Campbell Scientific for more information. ² A leveling base is required to mount the CS300, LI200X, LI200S, or LI190R. ³ Assumes the CMP6, CMP11, and CMP21 are not housed in the CVF4 Heater/Ventilation Unit. ⁴ Assumes the SR20-T2-L is not housed in the VU01 Heater/Ventilation Unit.				

6. Installation

6.1 Siting

The solar radiation sensor is usually installed horizontally, but can also be installed at any angle including an inverted position. In all cases, it will measure the flux that is incident on the surface that is parallel to the sensor surface. Site the sensor to allow easy access for maintenance while ideally avoiding any obstructions or reflections above the plane of the sensing element. It is important to mount the sensor such that a shadow or a reflection will not be cast on it at any time. FIGURE 6-1 shows how to calculate the distance needed from any potential obstruction, using the CMP3 as an example.




FIGURE 6-1. Solar sensor placement

If this is not possible, try to choose a site where any obstruction over the azimuth range between earliest sunrise and latest sunset has an elevation not exceeding 5° . Diffuse solar radiation is less influenced by obstructions near the horizon. For instance, an obstruction with an elevation of 5° over the whole azimuth range of 360° decreases the downward diffuse solar radiation by only 0.8%. The sensor should be mounted with the cable pointing towards the nearest magnetic pole. For example, in the northern hemisphere, point the cable toward the North Pole.

6.2 Installation

1. On a level surface, level the solar radiation sensor using the leveling feet on the sensor. Alternatively, remove the sensor leveling feet to allow it to be mounted directly to the mounting bracket.
2. Secure the solar radiation sensor to the mounting bracket. Refer to FIGURE 6-2 to determine which mounting holes are used by the sensor. Visually inspect the leveling feet on the sensor (if present) to ensure all feet are in contact with the mounting bracket.




FIGURE 6-2. Mounting hole locations for solar sensors.

3. Using a diopter in combination with a solar compass, install and orient the crossarm on the tripod or the mast. If installing the mounting bracket on a vertical pole, ensure the pole is truly vertical.
4. Secure the mounting bracket to the crossarm or the vertical pole using the hardware included with the mounting bracket. The 015ARM, CM225, and CM255 use one or two U-bolts, nuts, flat washers, and lock washers to mount the bracket (FIGURE 6-3).




FIGURE 6-3. 015ARM and CM255 showing U-bolt mounting

5. The CM225LS bracket (FIGURE 6-4) uses two set screws to secure the crossarm or the pole in the channel at the base of the bracket. For pyranometers mounted horizontally, ensure the mounting bracket is horizontal in two dimensions. For pyranometers to be mounted at an angle with the CM255 or CM255LS, set the mounting bracket angle to the desired angle prior to tightening the mounting hardware.




FIGURE 6-4. CM255LS

6. Verify all mounting hardware is firmly tightened, and that the mounting bracket is at the desired angle. The CM255LS includes leveling bolts for additional adjustment of the pyranometer level.

7. Maintenance

Periodically (at least yearly) check for wear and damage, and take necessary corrective actions. Ensure all bolts are securely tightened.

Campbell Scientific Companies

Campbell Scientific, Inc.

815 West 1800 North
Logan, Utah 84321
UNITED STATES

www.campbellsci.com • info@campbellsci.com

Campbell Scientific Canada Corp.

14532 – 131 Avenue NW
Edmonton AB T5L 4X4
CANADA

www.campbellsci.ca • dataloggers@campbellsci.ca

Campbell Scientific Africa Pty. Ltd.

PO Box 2450
Somerset West 7129
SOUTH AFRICA

www.campbellsci.co.za • cleroux@csafrica.co.za

Campbell Scientific Centro Caribe S.A.

300 N Cementerio, Edificio Breller
Santo Domingo, Heredia 40305
COSTA RICA

www.campbellsci.cc • info@campbellsci.cc

Campbell Scientific Southeast Asia Co., Ltd.

877/22 Nirvana@Work, Rama 9 Road
Suan Luang Subdistrict, Suan Luang District
Bangkok 10250
THAILAND

www.campbellsci.asia • info@campbellsci.asia

Campbell Scientific Ltd.

Campbell Park
80 Hathern Road
Shepshed, Loughborough LE12 9GX
UNITED KINGDOM

www.campbellsci.co.uk • sales@campbellsci.co.uk

Campbell Scientific Australia Pty. Ltd.

PO Box 8108
Garbutt Post Shop QLD 4814
AUSTRALIA

www.campbellsci.com.au • info@campbellsci.com.au

Campbell Scientific Ltd.

3 Avenue de la Division Leclerc
92160 ANTONY
FRANCE

www.campbellsci.fr • info@campbellsci.fr

Campbell Scientific (Beijing) Co., Ltd.

8B16, Floor 8 Tower B, Hanwei Plaza
7 Guanghua Road
Chaoyang, Beijing 100004
P.R. CHINA

www.campbellsci.com • info@campbellsci.com.cn

Campbell Scientific Ltd.

Fahrenheitstraße 13
28359 Bremen
GERMANY

www.campbellsci.de • info@campbellsci.de

Campbell Scientific do Brasil Ltda.

Rua Apinagés, n.br. 2018 — Perdizes
CEP: 01258-00 — São Paulo — SP
BRASIL

www.campbellsci.com.br • vendas@campbellsci.com.br

Campbell Scientific Spain, S. L.

Avda. Pompeu Fabra 7-9, local 1
08024 Barcelona
SPAIN

www.campbellsci.es • info@campbellsci.es

Please visit www.campbellsci.com to obtain contact information for your local US or international representative.