NSTR TION MANU/



Copyright © 2001-2018 Campbell Scientific, Inc.

WARRANTY AND ASSISTANCE

This equipment is warranted by CAMPBELL SCIENTIFIC (CANADA) CORP. ("CSC") to be free from defects in materials and workmanship under normal use and service for **twelve (12) months** from date of shipment unless specified otherwise. ******* Batteries are not warranted. ******* CSC's obligation under this warranty is limited to repairing or replacing (at CSC's option) defective products. The customer shall assume all costs of removing, reinstalling, and shipping defective products to CSC. CSC will return such products by surface carrier prepaid. This warranty shall not apply to any CSC products which have been subjected to modification, misuse, neglect, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for a particular purpose. CSC is not liable for special, indirect, incidental, or consequential damages.

Products may not be returned without prior authorization. To obtain a Return Merchandise Authorization (RMA), contact CAMPBELL SCIENTIFIC (CANADA) CORP., at (780) 454-2505. An RMA number will be issued in order to facilitate Repair Personnel in identifying an instrument upon arrival. Please write this number clearly on the outside of the shipping container. Include description of symptoms and all pertinent details.

CAMPBELL SCIENTIFIC (CANADA) CORP. does not accept collect calls.

Non-warranty products returned for repair should be accompanied by a purchase order to cover repair costs.



Campbell Scientific (Canada) Corp. 14532 131 Avenue NW | Edmonton AB T5L 4X4 780.454.2505 | fax 780.454.2655 | campbellsci.ca Products may not be returned without prior authorization. The following contact information is for Canadian and international clients residing in countries served by Campbell Scientific (Canada) Corp. directly. Affiliate companies handle repairs for clients within their territories. Please visit *www.campbellsci.ca* to determine which Campbell Scientific company serves your country.

To obtain a Returned Materials Authorization (RMA), contact CAMPBELL SCIENTIFIC (CANADA) CORP., phone (780) 454-2505. After a measurement consultant determines the nature of the problem, an RMA number will be issued. Please write this number clearly on the outside of the shipping container. Campbell Scientific's shipping address is:

CAMPBELL SCIENTIFIC (CANADA) CORP.

RMA#____ 14532 131 Avenue NW Edmonton, Alberta T5L 4X4 Canada

For all returns, the client must fill out a "Statement of Product Cleanliness and Decontamination" form and comply with the requirements specified in it. The form is available from our web site at *www.campbellsci.ca/repair*. A completed form must be either emailed to *repair@campbellsci.ca* or faxed to (780) 454-2655. Campbell Scientific (Canada) Corp. is unable to process any returns until we receive this form. If the form is not received within three days of product receipt or is incomplete, the product will be returned to the client at the client's expense. Campbell Scientific (Canada) Corp.f reserves the right to refuse service on products that were exposed to contaminants that may cause health or safety concerns for our employees.

Precautions

DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND **TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC**. FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at www.campbellsci.ca or by telephoning (780) 454-2505 (Canada). You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified personnel (e.g. engineer). If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

General

- Prior to performing site or installation work, obtain required approvals and permits.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a hardhat and eye protection, and take other appropriate safety precautions while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

Utility and Electrical

- You can be killed or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in contact with overhead or underground utility lines.
- Maintain a distance of at least one-and-one-half times structure height, 6 meters (20 feet), or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.

Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or nonessential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CLIENT ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.

PLEASE READ FIRST

About this manual

Please note that this manual was originally produced by Campbell Scientific Inc. (CSI) primarily for the US market. Some spellings, weights and measures may reflect this origin.

Some useful conversion factors:

Area:	1 in^2 (square inch) = 645 mm ²
Length:	1 in. (inch) = 25.4 mm
	1 ft (foot) = 304.8 mm
	1 yard = 0.914 m
	1 mile = 1.609 km
Mass:	1 oz. (ounce) = 28.35 g
	1 lb (pound weight) = 0.454 kg
Pressure:	1 psi (lb/in2) = 68.95 mb
Volume:	1 US gallon = 3.785 litres

In addition, part ordering numbers may vary. For example, the CABLE5CBL is a CSI part number and known as a FIN5COND at Campbell Scientific Canada (CSC). CSC Technical Support will be pleased to assist with any questions.

About sensor wiring

Please note that certain sensor configurations may require a user supplied jumper wire. It is recommended to review the sensor configuration requirements for your application and supply the jumper wire is necessary.

Table of Contents

PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.

1.	Introduc	tion1
2.	Precauti	ons1
3.	Initial In	spection1
4.	QuickSt	art2
	4.1 4.2 4.3	Remote Station Radio 2 Base Station Radio 2 LoggerNet Setup 2
5.	Overview	<i>N</i> 3
6.	Specific	ations3
7.	Product	Description5
	7.1 7.2 7.3 7.4 7.5 7.6 7.7 7 7 7	Mounting5Power.5USB5CS I/O.6RS-232.7LEDs.8Antenna.87.1Compatible Antennas8.7.22.7.2Electrostatic Issues and Surge Protection9.7.3Antenna Cables.10
8.	Configu	ring the RF407 Series10
	8.1	DevConfig10
9.	LoggerN 9.1 9.2	Jet Setup 11 Basic Setup 11 Using a Repeater 15
10	. Installati	ion Best Practices15
	10.1 10.2 10.3	Avoiding Interference
11.	. Operatio	on16
	11.1	Main17

11.1.1 Active Interface	17
11.1.2 SDC Address	18
11.1.3 RS-232 Baud Rate	18
11.1.4 Protocol	18
11.1.5 RF Hop Sequence	18
11.1.6 Network ID	19
11.1.7 Power Mode	19
11.1.8 Retry Level	19
11.1.9 Radio TX Power Level	
11.2 PakBus [®]	
11.2.1 PakBus Address	20
11.2.2 PakBus Reacon Interval	21
11.2.2 PakBus Derify Interval	21
11.2.5 Tukbus Verly interval	21
11.2.5 Neighbors Allowed	21
11.2. Advanced	21
11.2 1 Padia MAC Address	22
11.2.2 Available Encourancies	22
11.5.2 Available Frequencies	22
11.3.5 Kadio Channel Mask	22
11.3.4 Operating System Version	23
11.3.5 Kadio Firmware Version	23
11.3.6 Received Signal Strength	23
11.3.7 Battery Voltage	24
11.3.8 ME Baud Rate	24
11.3.9 RS-232 Parity	24
11.3.10RS-232 Stop Bits	24
11.3.11 RS-232 Character Length	24
11.3.12RS-232 Auto Power Down	24
12. Attributions	.25
Annendices	
Appendices	
A Dout 15 ECC Compliance Marning	~ 4
A. Part 15 FCC Compliance warning	A-1
D. Distance we Automa Opin Termin and Other	
B. Distance vs. Antenna Gain, Terrain, and Other	
Factors	B-1
D 1 Interchertien	D 1
B.1 Introduction	B-l
B.2 HOW Far Can You GO?	. В-2
B.2.1 Uverview	. в-2
B.2.2 Link Budget	. В-2
B.2.3 Transmitter Power	. В-З
B.2.4 Cable Loss	. B-3
B.2.5 Antenna Gain	. B-4
B.2.6 Receiver Sensitivity	B-5

Tables

B.3 B.4

7-1.	USB Pinout (USB Type B Jack)
7-2.	CS I/O Pinout (9-PIN D-SUB MALE)7

7-3.	RS-232 Pinout (9-PIN D-SUB FEMALE)	8
B-1.	Transmitter Power	B-3
B-2.	Cable Loss	B-4
B-3.	LMR-195 Cable Loss vs. Length @ 900 MHz	B-4
B-4.	Antenna Gain of Recommended Antennas	B-4
B-5.	Free Space Path Loss	B-5
B-6.	915 MHz Distance vs. Path Loss (Lpath in dB) per Two	
	Propagation Models*	B-6
B-7.	Path Type vs. Path Characteristics Selector	B-6
B-8.	Lpath vs. Distance for 2-Ray Propagation Model in Example #1.	B-7
B-9.	Fade Margin (dB) vs. Distance for 2-Ray Propagation Model in	
	Example #1	B-8
B-10.	Lpath vs. Distance for 2-Ray Propagation Model in Example #2.	B-8
B-11.	Fade Margin (dB) vs. Distance for 2-Ray Propagation Model in	
	Example #2	B-9

CRBasic Example

11-1.	Retrieving RSSI Information	24	4
-------	-----------------------------	----	---

1. Introduction

This manual discusses the configuration, operation, and maintenance of the Campbell Scientific RF407 series frequency-hopping spread-spectrum (FHSS) radios. This manual will refer to these devices collectively as either "radio," "RF407 series," or "RF407-series radio" unless otherwise noted.

The RF407-series radios are designed for license-free use in several countries:

- The RF407 has a 902 to 928 MHz operating-frequency range appropriate for use in the United States and Canada. (FCC / IC / IFT compliant)
- The RF412 has a 915 to 928 MHz operating-frequency range appropriate for use in Australia and New Zealand. (ACMA compliant)
- The RF422 has an 863 to 870 MHz operating-frequency range appropriate for use in most of Europe and some of Asia. (ETSI compliant)
- The RF427 has a 902 to 907 and 916 to 928 MHz operating-frequency range appropriate for use in Brazil. (ANATEL compliant)

2. Precautions

- This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. See Appendix A, *Part 15 FCC Compliance Warning (p. A-1)*, for more information.
- It is recommended that the RF422 868 MHz radio be installed at least 200 meters from any 4G LTE cellular transmitter including towers and cellular modems/gateways.
- Ensure maximum protection against surges. Use coaxial (antenna) surge protection. Keep RS-232, CS I/O, and USB connections short or use protective isolation and surge protection when appropriate.
- Where an AC adapter is used, Campbell Scientific recommends pn 15966. Any other AC adapter used must have a DC output not exceeding 16 volts measured without a load to avoid damage to the radio. Over-voltage damage is not covered by factory warranty.
- Line-of-sight obstructions and RF interference will affect the transmission distance. See Appendix B, *Distance vs. Antenna Gain, Terrain, and Other Factors (p. B-1)*, for a discussion of antenna gain and other factors affecting distance.

3. Initial Inspection

• The RF407-series radios ship with an SC12 serial cable, a USB A to USB B Cable, 2 grommets, and 2 screws.

- Upon receipt of the RF407-series radio, inspect the packaging and contents for damage. File damage claims with the shipping company. Contact Campbell Scientific to facilitate repair or replacement.
- Immediately check package contents against shipping documentation. Thoroughly check all packaging material for product that may be trapped. Contact Campbell Scientific immediately about any discrepancies. Model numbers are found on each product. On cables, the model number is often found at the connection end of the cable.

4. QuickStart

Out of the box, the radio is configured for use with a datalogger connecting via CS I/O and using CS I/O SDC address 7.

4.1 Remote Station Radio

Using the supplied SC12 serial cable, connect the radio's **CS I/O** port to the **CS I/O** port of the datalogger.

4.2 Base Station Radio

You will need to connect the radio to your PC and use *Device Configuration Utility* (*DevConfig*) to change the radio's **Active Interface** to **USB**. To learn more about connecting with *DevConfig* see Section 8.1, *DevConfig* (p. 10). Using *DevConfig*, set the radio's **Active Interface** setting to **USB**. The **Power Mode** setting should match that of the device you are connecting to. **Apply** the change(s), close *DevConfig*, and leave the radio connected to the PC via USB.

4.3 LoggerNet Setup

The next step is to run *LoggerNet* and configure it to connect to the datalogger via the radio link.

- 1. From the EZ View of the *LoggerNet Setup* screen, press Add, select your datalogger type, enter a name for your datalogger, and press Next.
- 2. Under Connection Type, select Direct Connect. Press Next.
- 3. Under COM Port Selection, select the port designated as RF407-Series.
- 4. Under Datalogger Settings, select a Baud Rate of 115200, enter the PakBus Address of the datalogger, and set Extra Response Time to 1 second. Press Next.
- 5. Under **Datalogger Settings Security**, enter any security codes that have been previously configured in the datalogger. Press **Next**.
- 6. Review the **Communication Setup Summary** and verify that all settings are correct. Press **Next**.
- On the Communication Test screen, select Yes and press Next to verify communication with the datalogger. If unable to communicate, press the Previous button and review your settings. Once you have successfully communicated with your datalogger, press the Finish button.
- 8. You are now ready to connect to your datalogger using the *LoggerNet Connect* screen.

5. Overview

Spread-spectrum radios spread the normally narrowband information signal over a relatively wide band of frequencies. This allows the communications to be more immune to noise and interference from RF sources such as pagers, cellular phones, and multipath. The RF407-series radios reduce susceptibility to RF interference from other spread-spectrum devices by providing user-selectable frequency-hopping patterns.

The RF407-series radios can provide up to three miles transmission range with an inexpensive whip antenna. The radios can provide greater than 16 mile transmission range when using a higher gain directional antenna at ideal conditions. Compatible antennas are described in Section 7.7.1, *Compatible Antennas (p. 8)*.

6. Specifications

General

Dimensions: 11.1 x 6.9 x 2.7 cm (4.4 x 2.7 x 1.1 in) Weight: 136 g (4.8 oz) Two-piece aluminum case, black anodized

Ra	dio
110	iuiu

	RF407	RF412	RF427	RF422
Radio Type	Frequency H	opping Spread Spec	trum (FHSS)	SRD860, LBT + AFA ³
Frequency	902 to 928 MHz	915 to 928 MHz	902-907 MHz, 916-928 MHz	863 to 870 MHz
Transmit Power Output ¹		5 to 250 mW		2 to 25 mW
Channel Capacity	Eight 25-channel hop sequences sharing 64 available channels	Eight 25-channel hop sequences sharing 31 available channels	Eight 25-channel hop sequences sharing 43 available channels	Ten 30-channel hop sequences ²
Receiver Sensitivity		-101 dBm		-106 dBm
RF Data Rate		200 kbps		10 kbps
Link Throughput	105 kbps (maximum)			8 kbps (maximum)
Average Current Consumption at 12 Vdc				
Transmit		< 80 mA		20 mA
Idle On	14 mA			12 mA
Idle 0.5 sec Power Mode	4 mA			3.5 mA
Idle 1 sec Power Mode	3 mA			2.5 mA
Idle 4 sec Power Mode		1.5 mA		1.5 mA

¹Software selectable

²30 channels (default), software configurable to meet local regulations; 10 sequences for reducing interference through channel hop

³See LBT + AFA Compliance and Performance below.

LBT + AFA Compliance and Performance

Complies with ETSI duty cycle requirements. Radio communication effective duty cycle = (number of channels • 100) / 3600. Channel Spacing: 100 kHz Receiver Bandwidth: 150 kHz Modulation Bandwidth: < 300 kHz LBT Threshold: < -88 dBm TX on Time: < 1 s

Power

Powered over CS I/O or 2.5 mm DC power jack Input Voltage: 9 to 16 Vdc

Connections

USB:

USB Type B jack

Can draw enough power for normal operation from standard USB host

RS-232:

9-pin, Female 1200, 4800, 9600, 19200, 38400, 57600, and 115200 baud rate supported

CS I/O:

9-pin, Male Provides power connection from datalogger for normal operation Supports SDC (7|8|10|11) and Modem Enable (ME) Master communication modes Does not support ME Peripheral mode

Antenna Connector

Reverse Polarity SMA (RPSMA)

Diagnostics

LEDs: TX/PWR, RX Received Signal Strength Indicator (RSSI) for Last Packet

Operating Temperature

Standard: -40 to 70 °C

Configuration

Device Configuration Utility via USB

Compliance

RF407: United States FCC Part 15.247: MCQ-XB900HP Industry Canada (IC): 1846A-XB900HP Mexico Federal Telecommunications Institute IFT# RCPDIXB15-0672-A1

RF412: ACMA RCM United States FCC Part 15.247: MCQ-XB900HP Industry Canada (IC): 1846A-XB900HP

RF422: View the RF422 EU Declaration of Conformity at www.campbellsci.com/rf422 RF427: This device complies with Brazil ANATEL standards in Resolution No. 506. The operating frequencies are 902 MHz to 907 MHz and 915 MHz to 928 MHz



7. Product Description

7.1 Mounting

The mounting holes are designed to align with a one-inch-on-center hole pattern and provide for ridged mounting of the radio in either a vertical or horizontal orientation. $#6-32 \times 0.375$ -inch stainless steel Phillips head screws (pn 505) and nylon grommets (pn 6044) are supplied for securing the radio to the backplate of a Campbell Scientific enclosure.

7.2 Power

There are three ways the radio may be powered for operation. The radio may be powered via CS I/O, USB, or the 2.5 mm DC power jack labeled as Power.

The power connector is most commonly used to supply power to the radio when the radio is used as a standalone PakBus[®] router / RF repeater or when the **RS-232** port is used for interconnect with another device. The Field Power Cable (pn 14291) or AC to DC power adapter (pn 15966) are used for supplying 12 Vdc to the power connector.

The power connector of the radio uses the inner conductor for positive (+) voltage and the outer / sleeve conductor for ground (-).

CAUTION There are many AC adapters available with barrel connectors that will fit the RF407 series. Damage that occurs from the use of an AC adapter that is not the 15966 AC to DC power adapter will not be covered by warranty. If using a different AC adapter, be sure that the adapter's "no load" voltage is below the 16 Vdc; measure the output with a DC voltmeter while the AC adapter is plugged into the outlet but not powering anything.

7.3 USB

The radio has a USB Type B jack that can be connected to your PC using the supplied 17648 USB cable. The connection is used for power, configuration, and data.

NOTE INSTALL the DEVICE DRIVER BEFORE connecting the radio to your PC via USB for the first time. You will need the device driver properly installed before you can connect to the radio via USB. To install the device driver, download the latest version of *DevConfig* from our website. Under Device Type, select Radio | RF407 Series. Click the Install the USB device driver link and follow the prompts.

Most host USB ports will supply a sufficient amount of voltage and current for all normal operations. When used as a base radio, an external power supply is generally not required. When sourcing operational power from the PC's USB port, connect the radio directly to the PC or to an externally powered USB hub.

When the radio is connected to the PC, a virtual COM port will be added to the list of available ports (COM and LPT) devices. It will be descriptively labeled, for example "RF407 Series (COM10)", where COM10 denotes the COM port enumerated by the Windows[®] operating system.

The **USB** port is always available for configuration purposes. Independent of the Active Interface radio setting, USB can always be used for connecting with *DevConfig* for radio configuration.

The USB interface is only available for operational, network communication when the radio **Active Interface** setting is set as **USB**.

TABLE 7-1. USB Pinout (USB Type B Jack)		
Pin	Function	
1	5V	
2	Data–	
3	Data+	
4	GND	

7.4 CS I/O

The **CS I/O** port is a 9-pin male D-Sub connector that is typically connected to a Campbell Scientific datalogger using the supplied SC12 cable. This connection is used for power and data.

The **CS I/O** port is not a typical RS-232 connection and is specific to Campbell Scientific products. CS I/O cannot be used for radio configuration using *DevConfig*.

For a typical remote radio site, the radio need only be connected to the datalogger **CS I/O** port using the supplied SC12 cable. This connection will supply operational power to the radio and serve as the data connection between the radio the datalogger. The **Active Interface** setting must be set to **CS I/O SDC**.

An alternative, but much less common, use of CS I/O is connection to another communication peripheral through an A100 CS I/O null modem adapter (pn

17366). This is typically only used when creating a "phone to RF base" configuration. The radio's **Active Interface** setting must be set to **CS I/O ME Master** and the other device (for example COM220) must be capable of being configured as a modem enabled (ME) peripheral.

	TABLE 7-2. CS I/O Pinout (9-PIN D-SUB MALE) Pinout (9-PIN D-SUB MALE)			
Pin	Function	I/O	Description	
1	5V	Ι	Sources 5 Vdc to power peripherals	
2	GND		GND for pin 1 and signals	
3	Ring	0	Raised by modem to put datalogger into telecommunications mode	
4	RX	0	Serial data receive line	
5	Modem Enable	Ι	Raised when datalogger determines that associated modem raised the ring line	
6	Synchronous Device Enable	Ι	Used by datalogger to address synchronous devices; can be used as a printer enable	
7	CLK/Handshake	I/O	Used by datalogger with SDE and TX lines to transfer data to synchronous devices	
8	12V supplied by datalogger	PWR	Sources 12 Vdc to power peripherals	
9	TX	Ι	Serial data transmit line	
1	I = Signal into the RF407 series, O = Signal out of the RF407 series			

7.5 RS-232

The **RS-232** port is a DCE, 9-pin female D-Sub connector used to for connecting the radio to the **RS-232** port of a datalogger, computer, or another RS-232 device. This connection is most commonly used when connecting the radio to a device without a **CS I/O** port or when linking two communication peripherals, for example directly connecting the radio to an Ethernet serial server.

The **RS-232** port can be connected to a DTE device, like a computer or NL201, using the pn 10873, 9-Pin female to 9-Pin male serial cable. The **RS-232** port can be connected to another DCE device, like a datalogger RS-232 or MD485 or cellular modem, using the 18663, 9-pin male-to-male null modem serial cable.

When using RS-232, 12 Vdc power should be supplied to the power connector using a field power connector or AC power adapter. The **Active Interface** setting must be set to **RS-232**, and the **RS-232** port configuration, like baud rate, should match the device the radio is connected to.

RS-232 cannot be used for radio configuration using DevConfig.

TABLE 7-3. RS-232 Pinout (9-PIN D-SUB FEMALE)		
Pin	I/O	Description
1		
2	0	TX
3	I	RX
4		
5		GND
6		
7		
8	0	CTS
9		
I = Signal into the RI	F407 series, O = Signal o	ut of the RF407 series

7.6 LEDs

The radios have a red LED labeled **TX/PWR** and a green LED labeled **RX**. When 12V power is applied, Both LEDs light for about one second.

The red LED lights to indicate when the receiver is actively listening. (Note that the light will blink in correlation with the **Power Mode**, that is, Always On, every 0.5 Sec, every 1 Sec, or every 4 Sec.) When the radio is transmitting, the red LED will flicker (it will not be on solid).

Green LED activity indicates that there is an RF signal being received

7.7 Antenna

The radio has a reverse polarity SMA (RPSMA) jack antenna connection. It is important to note the distinction between RPSMA and SMA connectors when selecting a mating antenna or antenna cable.

7.7.1 Compatible Antennas

Campbell Scientific offers antennas to satisfy the needs for various base station and remote station requirements. All antennas (or antenna cables) that attach directly to the radio have an RPSMA plug connector. The use of an unauthorized antenna could cause transmitted field strengths in excess of FCC rules, interfere with licensed services, and result in FCC sanctions against the user. One of the following antennas listed below must be used.

CAUTION An FCC authorized antenna is a required component. You must pick one of the antennas below.

CAUTION In order to comply with the FCC RF exposure requirements, the RF407 series may be used only with approved antennas that have been tested with these radios and a minimum separation distance of 20 cm must be maintained from the antenna to any nearby persons.

Approved Antennas		
Campbell Scientific Part Number	Description	
14201	900 MHz 9 dBd Yagi Antenna with Type N Female and Mounting Hardware	
14204	900 MHz 0 dBd Omnidirectional 1/2 Wave Whip Antenna with Right Angle and RPSMA Male	
14205	900 MHz 6 dBd Yagi Antenna with Type N Female and Mounting Hardware	
14221	900 MHz 3 dBd Omnidirectional Antenna with Type N Female and Mounting Hardware	
14310	900 MHz 0 dBd Omnidirectional 1/4 Wave Whip Antenna, Straight 3 inches Tall with RPSMA Male	
15730	900 MHz 0 dBd Omnidirectional 1/4 Wave Whip Antenna with Right Angle and RPSMA Male	
15731	900 MHz 0 dBd Omnidirectional 1/4 Wave Whip Antenna, Straight 2 inches Tall with RPSMA Male	
15970	900 MHz 1 dBd Dipole Antenna with Adhesive Mount and RPSMA Female 79 in. Cable	

7.7.2 Electrostatic Issues and Surge Protection

Many radio installations are outdoors and therefore susceptible to lightning damage, especially via the antenna system. Also, depending on climate and location, electrostatically-charged wind can damage sensitive electronics, if sufficient electric charge is allowed to accumulate on the antenna and cable.

To protect against electrostatic damage, the antenna connector of the radio is connected to the radio case which can be tied to a good earth ground for discharge of electrostatic build up.

Also to protect against electrostatic damage, Campbell Scientific offers pn 31314, Antenna Surge Protection Kit. The surge protection kit includes a PolyPhaser[®] surge protector, a coax jumper for connecting the RF407-series radio to the PolyPhaser, ground wire lead, and mounting hardware. The PolyPhaser has Type N jack connectors on both ends; one for connection to a COAXNTN-L cable and the other for connection to the 18-inch length of COAXRPSMA cable included in the kit. To have the surge protection kit pre-installed by Campbell Scientific (bulkhead-mounted through the enclosure wall), see pn 31312.

7.7.3 Antenna Cables

Some antennas require an additional antenna cable to connect to the radio directly or to an interconnected surge protector.

COAXRPSMA-L is a LMR195 coaxial cable terminated with a Type N plug on one end and a RPSMA plug on the other. The COAXRPSMA-L can be used to connect antennas with a Type N jack connector directly to the RF407-series radios. Such antennas include the 14201, 14205, and 14221.

COAXNTN-L is a RG8/U coax cable terminated with a Type N plug on both ends. The COAXNTN-L is typically used to connect antennas with a Type N jack connector to an inline surge protector, or to a bulk head Type N jack.

8. Configuring the RF407 Series

8.1 DevConfig

DevConfig is the primary tool for configuring the radio. *DevConfig* version 2.11 or later is required. *DevConfig* can be downloaded free of charge from *www.campbellsci.com/downloads*.

NOTE INSTALL the DEVICE DRIVER BEFORE plugging the radio into your PC for the first time. You will need the device driver properly installed before you can connect to the radio via USB. To install the device driver using *DevConfig*, select **Radio** | **RF407 Series** under **Device Type**. Click the **Install the USB device driver** link and follow the prompts.

- 1. Open DevConfig.
- 2. Under Device Type, select Radio | RF407 Series.
- 3. Carefully review the Connect Instructions text provided on the right.
- 4. With the USB device driver installation complete, connect the supplied USB cable between the USB port on your computer and the **USB** port on the radio.
- 5. Click the Browse button next to Communication Port.
- 6. Select the port labeled **RF407-Series**.
- 7. Click OK.
- 8. Click Connect.
- 9. Configure the radio as needed for your application. See Section 11, *Operation (p. 16)*.
- 10. Click Apply to save your changes.

You will be prompted to save your configuration. Doing so will allow you to easily recall the configuration later or apply this same configuration to other devices.

9. LoggerNet Setup

9.1 Basic Setup

Start *LoggerNet* and open the *Setup* screen from the **Main** category of the toolbar. Start the configuration by clicking on the **Add Root** button. From the **Add** submenu make the following selections:

- ComPort
- PakBusPort
- Your datalogger

Finally, click the **Close** button on the **Add** submenu. Your setup tree should appear as shown below:

×	Setup Screen	- • ×
File View Backup Tools Help	10	
Display Add Root Add	Delete Rename Undo Redo	EZ View
Entire Network	ComPort : ComPort Hardware Notes Standard Image: Communications Enabled ComPort Connection Communications Proceed Advanced Image: ComPort Connection Call-Back Enabled Image: ComPort Communication Proceed Delay Hangup 00 s ComPort Communication Delay 00 s	ort (COM1) v
Check Apply Cancel	No problems found with settings for the selected	device

With the setup tree entered, you will now need to complete the configuration of each element. Start with selecting the **ComPort** element at the root of the tree. Under **ComPort Connection**, select port labeled **RF407-Series**.

×	Setup Screen – 🗖 ×		
File View Backup Tools Help			
Display Add Root	Delete Rename Undo Redo	EZ View	
Entire Network ComPort ComPort PakBusPort CR1000	ComPort : ComPort Hardware Notes		
	Standard Communications Enabled ComPort Connection RE407-Series (COM9)		
	Advanced Call-Back Enabled Extra Response Time 01 s Delay Hangup 00 s 000 ms ComPort Communication Delay 00 s		
Chec <u>k</u> Apply <u>C</u> ancel			

Select the **PakBusPort** element in the tree, and select the **PakBus Port Always Open** checkbox. Set the **Maximum Baud Rate** to **115200**.

×	Setup Screen	- 🗆 🗙
File View Backup Tools Help		
Display Add Root Add	Delete Rename Undo Redo	EZ View
Entire Network	PakBusPort : PakBusPort	
CR1000	Hardware New PakBus Nodes Notes Standard Communications Enabled PakBus Port Always Open	
	Maximum Time On-Line 00 h 00 m 00 s	
	Maximum Baud Rate 115200 🗸	
	Beacon Interval 00 h 01 m 00 s	
	PakBus Verify Interval 00 h 00 m 00 s	
	Advanced	
	Extra Response Time 00 s	
	PakBus Address 4094	
	Delay Hangup 00 s 000 ms	
Chec <u>k</u> A <u>p</u> ply <u>C</u> ancel		

Finally, select your datalogger in the tree. Set the **PakBus Address** field to the PakBus[®] address of your datalogger. Enter the **Security Code**, if security has been set up in your datalogger.

×	Setup Screen -	
File View Backup Tools Help	10. 10.	
Display Add Root Add	Delete Rename Undo Redo	EZ View
Entire Network	CR1000 : CR1000	
CR1000	Hardware Schedule Data Files Clock Program File Retrieval Notes Standard Image: Communications Enabled Ima	
	Security Code 0 Delay Hangup 00 s 000 ms	
Check Apply Cancel	No final storage tables are defined in the station's program. Scheduled Data Collection is disabled.	\$

Press the **Apply** button to save your changes. You are now ready to connect to your datalogger using the *LoggerNet Connect* screen.

9.2 Using a Repeater

When using an RF407-series radio as a repeater in your network, it can be entered into the *LoggerNet Setup* screen using the **pbRouter** device and entering the PakBus[®] address of the RF407 series in the **PakBus Address** field. If the repeater is the first hop from *LoggerNet*, it should always be shown in the network map. This will force routes to go through the repeater. If the repeater is further down the network, it may still be helpful to display it in the network map. However, it does not force routes to go through the repeater.

×	Setup Screen - 🗆 🗙		
File View Backup Tools Help	10		
Display Add Root Add	Delete Rename Undo Redo	EZ View	
Entire Network	Detete Remaine Ondo Redu pbRouter : pbRouter Hardware Notes Standard Image: Communications Enabled PakBus Address 10 Advanced		
Check Apply Cancel	Maximum Packet Size 998 PakBus Encryption Key	ted device	

10. Installation Best Practices

10.1 Avoiding Interference

In-band interference within "view" of either radio in a link can significantly degrade communications. Attempt to avoid locating radios and antennas near other transmitters or transmitting through commercial communication tower locations. Additionally, a powerful signal of almost any frequency at very close range can simply overwhelm a receiver. Test such a site with a representative setup before committing to it. Relocating an antenna by a few feet vertically or horizontally or constraining the radiation pattern with a directional antenna may make a significant difference. Keep in mind that commercial tower sites

and urban areas tend to evolve over time meaning new sources of interference may develop over time.

10.2 Antenna Selection, Placement, and Mounting

Antenna selection and placement can play a large role in system performance. Often directional antennas are preferred over omnidirectional antennas when possible as RF energy can be more selectively directed and received and higher gains can be realized without the consumption of additional power. Additionally, a good rule of thumb is to place antennas as high as possible. Giving an antenna a higher elevation often increases the amount of area and distance it can "see" and cover with "line of sight". Sometimes performance can be improved by even slightly changing the horizontal or vertical position of the antenna.

10.3 Antenna Cables

- Routing
 - Route all conductors and cables in a neat, orderly fashion. Avoid routing directly over or across system components.
 - Avoid routing conductors carrying low level analog signals in close proximity and parallel to conductors carrying digital signals or switched voltage levels.
- Bend Radius
 - The RF cable used to interconnect the radio and antenna has a specified minimum bend radius. Exceeding it will lead to a degradation of system performance: extra losses, high VSWR, etc.
- Strain Relief
 - Avoid cable chaffing and connector fatigue by strain relieving all conductors and cables that span a distance of more than 12 inches or have a potential for relative motion due to vibration or wind.
- Connectors
 - All exposed RF connectors should be weatherproofed. A good method is to apply overlapping wraps of a good quality mastic tape, extending several inches beyond either side of the connection, then cover the mastic tape with tight, overlapping wraps of a good quality vinyl tape.
 - Maintain electrical connectors in a clean, corrosion-free condition by means of a periodic application of a good quality aerosol-based contact cleaner.

11. Operation

The following settings are available for the RF407-series radios. Configure them as appropriate for your application.

11.1 Main 11.1.1 Active Interface

The radio provides three physical ports for interfacing to a computer, datalogger, or other device. They are USB, RS-232, and CS I/O. The **CS I/O** port has two operational modes, SDC and ME Master. Additionally, there is PakBus Router which is a software defined interface that disables normal operation of all of the physical ports. Only one interface can be selected as active at any given time. Note that despite the value of this setting, the **USB** port will always be available for configuration.

Interface	Description
CS I/O SDC	Use this setting when the CS I/O port is connected to a Campbell Scientific datalogger CS I/O port. The devices will use the concurrent synchronous device for communication protocol. Also, see the setting SDC Address (<i>p. 18</i>) and make sure that multiple SDC devices connected to a single CS I/O port use unique SDC addresses.
RS-232	Use this setting when the RS-232 port is connected to the RS-232 port of a datalogger, computer, or another RS-232 device. This setting is most commonly used when connecting the radio to a device without a CS I/O port or when linking two communication peripherals, for example directly connecting the radio to an Ethernet serial server. Also, see RS-232 Baud Rate (<i>p. 18</i>) and the advanced settings RS-232 Parity (<i>p. 24</i>), Stop Bits (<i>p. 24</i>), Character Length (<i>p. 24</i>), and Auto Power Down (<i>p. 24</i>).
USB	Use this setting when connecting the radio to a computer. This setting is the most common when the device is used as a "base radio" for a network. A computer's USB port can simultaneously be used for powering and communicating with the device.
PakBus Router	Use this setting when a standalone PakBus [®] router is required to repeat messages through a network. In this mode, the CS I/O , RS-232 , and USB ports are NOT available for connecting other devices for normal network operations. Note that despite the value of this setting, the USB port will always be available for configuration. The Protocol setting must be set as PakBus Node . Also ensure that PakBus Address is unique within the PakBus network.
CS I/O ME Master	Use this setting only under special circumstances where the CS I/O port is connected to another Campbell Scientific peripheral configured for Modem Enable (ME) through an A100 Null Modem Adapter. The A100 will swap TX / RX and ME / RING and supply power to the devices. The ME Baud Rate of both devices must match. An example includes connecting this device to a COM2xx phone modem. Also see Section 11.3.8, <i>ME Baud Rate (p. 24)</i> .

11.1.2 SDC Address

Specifies the CS I/O port SDC address when Active Interface is set as CS I/O SDC.

11.1.3 RS-232 Baud Rate

Specifies the baud rate that will be used on the **RS-232** port when Active Interface is set as **RS-232**. Other related advanced settings include **RS-232** Parity, Stop Bits, Character Length, and Auto Power Down.

11.1.4 Protocol

Protocol	Description	
Transparent	Provides a transparent link with no interpretation of the data packet. This mode is most commonly used with array based dataloggers. This mode is also used for non PakBus [®] protocols like Modbus. When used this way, Retry Level must be set to None .	
PakBus Aware	This is the most commonly used protocol setting for PakBus [®] networks. The radio will automatically inherit an RF identifier equal to the PakBus address of the device it is serially attached to. In this mode, the radio will be capable of performing RF level retries and acknowledgements and provide a more reliable link than Transparent mode used for broadcast messaging. You do not need to manually set a unique RF radio address or a unique PakBus address. This device will not appear in <i>PakBus Graph</i> .	
PakBus Node	This mode is similar to PakBus Aware, but it requires the device to have a unique PakBus address specified. Because the radio is PakBus addressable, status information, such as received signal strength indicator (RSSI), can be queried through a get variables transaction. Additionally, if the radio is connected to a PakBus router, it will also be viewable in <i>PakBus</i> <i>Graph</i> and accessible by other remote PakBus devices. If attached to a PakBus router, network overhead will increase due to the increase in number of PakBus nodes in the network. If Active Interface is also set to PakBus Router , this mode will allow the device to function as a standalone RF repeater. This setting must be used if Active Interface is set as PakBus Router . This setting is most commonly used when a user wants to a) use the device as a standalone PakBus repeater, b) make the device available remotely for viewing and editing settings, or c) attach more than one radio to a single datalogger.	

11.1.5 RF Hop Sequence

Specifies the radio channel hop sequence. This setting must match in all radios in the same RF network. This setting can also be used to prevent radios in one RF network from listening to transmissions of another.

11.1.6 Network ID

Specifies the RF network. This setting must match in all radios in the same RF network. Valid entries are 0 to 32767.

11.1.7 Power Mode

Power Mode governs the duty cycle that the radio will use for powering its receiver. As such, it governs the amortized current drain for the radio. Note that choosing a low power mode that requires a long transmission header for a network with frequent communications can actually cause a higher average power draw; a large percentage of the communication interval is spent in high power transmission.

Power Mode	Typical Avg. Current Draw @12V	Description
Always on	< 12 mA	The radio receiver is always on. Additional wakeup header is never transmitted. Use this setting in a network with very frequent communications or when network latency needs to be minimized.
0.5 Second	< 2 mA	The radio receiver is turned on every 0.5 seconds for 100 milliseconds to look for RF activity. The radio transmits a 700 millisecond wakeup header with the first transmission occurring after a period of RF inactivity. This is one of the most common setting in networks that do not contain CR200(X)-series dataloggers.
1 Second	< 1 mA	The radio receiver is turned on every 1 second for 100 milliseconds to look for RF activity. The radio transmits a 1.2 second wakeup header with the first transmission occurring after a period of RF inactivity. This is one of the most common setting in networks that contain CR200(X)-series dataloggers.
4 Second	< 0.6 mA	The radio receiver is turned on every 4 seconds for 100 milliseconds to look for RF activity. The radio transmits an 4.2 second wakeup header with the first transmission occurring after a period of RF inactivity. Only use this setting in networks where time between communications is long (hours) and saving on average an additional 1 to 1.5 mA is essential.

11.1.8 Retry Level

An advantage of using one of the PakBus[®] protocol modes is that the radios will retry packet delivery at the RF level. This setting specifies the level to which the radio should retry to deliver an unacknowledged RF packet

transmission. When an RF packet fails to be acknowledged by the destination, the radio will delay a random amount of time before resending the packet again. A receiving radio responds to the sending radio with an ACK packet for every radio packet it receives addressed to it with a valid CRC.

Retry Level	Retry Count
None	0
Low	3
Medium	5
High	7

NOTE

If the Retry Level is increased in a network with poor reception and many nodes, latency will greatly increase, sometimes to the point of non-operation if inundated with traffic.

11.1.9 Radio TX Power Level

This setting specifies the power level at which the RF module transmits. Levels are approximate. The maximum TX power for the RF407, RF412, and RF427 is 250 mW (+24 dBm); for the RF422 it is 25 mW (14 dBm).

TX Power Level, dBm	TX Power Level, mW
7	5
15	32
18	63
21	125
24	250

Radio installations should be performed by a professional. It is very important that the TX power level selected and the gain of the attached antenna do not exceed the maximum allowed ERP permitted by local regulations. Regulations vary by country and region. As the equipment owner, you are responsible for making sure that your installation and maintenance of the radio equipment ensure local regulations are met. For example, in much of the United States, FCC part 15 rules limit the 900 MHz, ISM band transmission from the RF407 and RF412 to a maximum effective radiated power of +36 dBm. If the radio is set to transmit at +24 dBm (250 mW), the maximum gain antenna that may be attached is 11 dBi (~8.5 dBd).

11.2 PakBus[®]

11.2.1 PakBus Address

This setting specifies the PakBus[®] address for this device. The value for this setting must be chosen such that the address of the device will be unique in the scope of the PakBus network. Duplication of PakBus addresses in two or more devices can lead to failures and unpredictable behavior in the PakBus network.

Valid range is 1 to 4094. However, values greater than 3999 are generally reserved for software products.

11.2.2 PakBus Beacon Interval

This setting, in units of seconds, governs the rate at which beacons will be broadcast over the **Active Interface** for the purpose of discovering PakBus neighbors. When **Active Interface** is **PakBus Router**, beacons will be sent over RF; otherwise, beacons will be sent over the serial port selected as the **Active Interface**. Set to zero to disable beaconing.

If **PakBus Verify Interval** is set to zero, a verify interval of 2.5 times the **PakBus Beacon Interval** will be assumed by the device.

11.2.3 PakBus Verify Interval

This setting specifies the interval, in units of seconds, which will be reported as the link verification interval in the PakBus hello transaction message. It will indirectly govern the rate at which the device will attempt to start a hello transaction with a neighbor if no other communication has taken place within the negotiated PakBus link verification interval. When **Active Interface** is **PakBus Router**, hello transactions will occur over RF; otherwise, they will be sent over the serial port selected as the **Active Interface**.

If **PakBus Verify Interval** is set to zero, a verify interval of 2.5 times the **PakBus Beacon Interval** will be reported by the device.

NOTE It is advised that **PakBus Verify Interval** be set to an interval several times larger than your expected general communication interval, for example, data collection interval.

11.2.4 Central Router

Specifies the PakBus address of another device that the RF407 series will use as a **Central Router**. A valid setting is a single address between 1 and 4094. When set, the RF407 series will act as a branch router. Specifying a central router address can reduce the amount of PakBus RF traffic by eliminating the exchange of neighbor lists with routers beyond the central router. This is especially true when the network contains many transient or intermittent PakBus routers. If the RF407 series does not know how to explicitly route a packet, it will be handed off to the **Central Router** specified by this setting.

11.2.5 Neighbors Allowed

This setting specifies an explicit list of nodes the RF407 series will accept as neighbors when acting in the capacity of a PakBus RF repeater / router. If the list is empty (default), any node will be accepted as a neighbor. This setting will not affect the acceptance of a neighbor if that node's address is greater than 3999. The formal syntax for this setting is:

neighbor := { "(" range-begin "," range-end ")" }.
range-begin := pakbus-address. ;
range-end := pakbus-address.
pakbus-address := number. ; 0 < number < 4000</pre>

Example: (129,129) (1084, 1084)

In the example above, nodes 129 and 1084 are assigned as neighbors to the RF407 series.

11.3 Advanced

11.3.1 Radio MAC Address

The radio MAC Address.

11.3.2 Available Frequencies

This read-only setting shows a bit field of the frequencies that are available in the modules' region of operation. Each bit corresponds to a physical channel. For the RF407, RF412, and RF427, channels are spaced 400 kHz apart. For the RF422, channels are spaced 200 kHz apart.

RF407/RF412/RF427	RF422
Bit 0 – 902.400 MHz	Bit 0 – 863.15 MHz
Bit 1 – 902.800 MHz	Bit 1 – 863.35 MHz
•	•
Bit 31 – 914.800 MHz	Bit 14 – 865.95 MHz
•	•
Bit 63 – 927.600 MHz	Bit 29 – 869.85 MHz

11.3.3 Radio Channel Mask

The **Radio Channel Mask** allows channels to be selectively enabled or disabled. This is useful to avoid using frequencies that experience unacceptable levels of RF interference.

This setting is a bit field. Each bit in the bit field corresponds to a frequency as defined in the **Available Frequencies** setting above. When a bit in the **Radio Channel Mask** and the corresponding bit in the **Available Frequencies** are both set to 1, that physical channel may be chosen by the module as an active channel for communication.

A minimum of 25 channels must be made available for the module to communicate on. The module will choose the 25 lowest enabled frequencies as its active channels if more than 25 are enabled.

All modules in a network must use an identical set of active channels. Separate networks which are in physical range of each other should use different **Network IDs** to avoid receiving data from the other network.

Note that channel 19 (910.000 MHz) is disabled by default. This channel has approximately 2 dBm worse receiver sensitivity than other channels. It is suggested that this channel not be used.

11.3.4 Operating System Version

Device operating system version

11.3.5 Radio Firmware Version

Radio firmware version

11.3.6 Received Signal Strength

Indicates the signal strength of the last packet received by this radio, and the PakBus address that it came from. The units of the RSSI are –dBm. Because the received signal strength can vary due to multipath, interference, or other environmental effects, it may not give a true indication of communication performance or range. However, received signal strength can be useful for activities such as:

- determining the optimal direction to aim a Yagi antenna
- determining the effects of antenna height and location
- trying alternate (reflective) paths
- seeing the effect of vegetation and weather over time

Accessing the Received Signal Strength

• Direct connection –

Using a direct connection from the PC to the RF407-series **USB** port, *DevConfig* can be used to view the **Received Signal Strength**. Once a connection is established using *DevConfig*, the **Received Signal Strength** can be located under the **Advanced** tab.

• Datalogger query -

The RF407 series must be configured as a PakBus node using *DevConfig*. Under the **Main** tab, set the **Protocol** to **PakBus Node**. This setting makes the RF407 an independent device in the network. The RF407 series must also be given a unique **PakBus Address** under the **PakBus** tab. This will prevent communication errors with other devices in the network and provide an address for a datalogger to query. The datalogger uses the **GetVariables()** instruction in the program to request the RSSI information, which includes the PakBus address of the device the RF407 series last received communication from any RF407-series node in the network as long as there is a known communication route. Once the datalogger has received the RSSI, it can be displayed in the **Public** table or stored to a data table.

```
CRBasic Example 11-1. Retrieving RSSI Information
'Example Program
                      'Set PakBus address of the RF407-series Node
Const RFPBA = 401
Const Neigh = -1
                      'Set neighbor address, -1 = Auto Discover, or 0 = No neighbor
Public Result, RFstatus(2)
Alias RFstatus(1) = RSSI
                            'Received signal strength indicator
                            'Address of the last received communication
Alias RFstatus(2) = PBA
BeginProg
  Scan (5, Sec, 0, 0)
    GetVariables(Result,ComSDC7,Neigh,RFPBA,0000,0,"Public","RFSignalLevel",RFstatus(),2)
  NextScan
EndProg
```

• PakBus Graph –

The RF407 series must be configured as a PakBus node using *DevConfig*. Under the **Main** tab, set the **Protocol** to **PakBus Node**. This setting makes the RF407 an independent device in the network. The RF407 series must also be given a unique **PakBus Address** under the **PakBus** tab. The RSSI and radio settings can be remotely accessed for any RF407 node displayed in *PakBus Graph*. Right-click on a device and a floating menu will be presented. Click on the **Edit Settings** option to display a list of settings. The RSSI is located under the **Advanced** tab in the **Received Signal Strength** field. The RSSI and the PakBus address of the device the RF407 last received communication from will both be displayed in the same field.

11.3.7 Battery Voltage

Specifies the battery voltage in volts at the radio.

11.3.8 ME Baud Rate

Specifies the baud rate that will be used on the CS I/O port when configured for ME Master.

11.3.9 RS-232 Parity

Specifies the parity that will be used on the RS-232 port.

11.3.10 RS-232 Stop Bits

Specifies the number of stop bits used on the RS-232 port.

11.3.11 RS-232 Character Length

Specifies the length in bits of character frames on the RS-232 port.

11.3.12 RS-232 Auto Power Down

Specifies whether to always power the RS-232 device or that the RS-232 TX automatically powers down when there is no activity for 30 seconds.

12. Attributions

PakBus is a registered trademark of Campbell Scientific, Inc.

PolyPhaser is a registered trademark of Transtector Systems, Inc.

Windows is a registered trademark of Microsoft.

Appendix A. Part 15 FCC Compliance Warning

Changes or modifications to the RF407-series radio systems not expressly approved by Campbell Scientific, Inc. could void the user's authority to operate this product.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Appendix B. Distance vs. Antenna Gain, Terrain, and Other Factors

B.1 Introduction

The communication distance you can expect to obtain using the RF407 series depends on a number of factors that are unique to every installation. These unique factors are the path of propagation, relative antenna elevations, and the link budget.

PATH OF PROPAGATION

Signal loss associated with the path of propagation (path loss) is often the single, largest factor determining system performance. The reflection, diffraction, or attenuation of the propagating RF wavefront due to terrain or man-made obstacles in the path of propagation can significantly reduce the level of signal reaching the receiver. For optimal performance, one should make every effort to achieve an unobstructed line-of-sight path between radios. For an in-depth discussion on the effects of obstructions in the path of propagation as well as methods for predicting the induced signal loss, refer to the Campbell Scientific application note *Line of Sight Obstruction*.

ANTENNA ELEVATIONS

The relative elevation of the transmitting and receiving antennas—to the surrounding terrain as well as to each other—plays a critical role in determining the maximum link distance. Greater antenna elevations not only provide greater obstacle clearance, but also increase the maximum unobstructed line-of-sight distances over apparently flat terrain. For example, given 10-foot antenna elevations for both ends of a link and flat, level terrain, the maximum allowable distance between the antennas before the curvature of the earth begins to obstruct the RF line of sight is approximately 9 miles. Increasing the elevation of one or both antennas will increase the maximum line-of-sight distance.

LINK BUDGET

A link budget is the summation of the systems gains and losses and provides a means of estimating the signal level arriving at the receiver. By comparing the signal level reaching the receiver with the signal level required by the receiver to produce a minimal level of performance, one can estimate the link's fade margin. The fade margin—received signal level in excess of the receiver's sensitivity—provides a measure of the link's operational viability. The greater the fade margin, the greater the potential long-term reliability. A minimally acceptable fade margin is 10 dB. For optimal system performance and reliability, it is generally recommended that one should design for a fade margin of 20-30 dB. For detailed information on calculating a link budget and fade margin, see the Campbell Scientific application note *The Link Budget and Fade Margin*.

B.2 How Far Can You Go?

Estimating Distance for Spread Spectrum Radios

B.2.1 Overview

Because the factors affecting communication distance are different for every system, a generalized estimate of distance cannot be stated with any practical degree of accuracy. Reasonable estimates of distance can only be achieved by means of a case-by-case analysis and accounting of these factors. The link budget is a simple and convenient tool for this purpose.

Also of interest are the effects of cable length, antenna gain, and terrain. Some of these items are easy to quantify (cable loss, for instance); others are difficult to quantify (such as the effect of ground reflections). They are all important, though, and affect how well the RF system performs.

B.2.2 Link Budget

In any RF system, there are gains and losses. Gains most commonly derive from the relative gain of the transmitting and receiving antennas. In some cases, an in-line RF amplifier may be used to provide additional system gain, but this is rare and not typical of Campbell Scientific installations. Losses derive from the attenuation of the RF signal as it propagates through the transmission lines (coaxial cables, surge suppressor, etc.) connecting the transmitter and receiver to their respective antennas, and more importantly, as it traverses the path of propagation between the antennas (path loss).

Here is a block diagram of the various components of gain/loss:



Where:

- Ptx = transmitter output power, in dBm (24 dBm in the case of the RF407 series at maximum transmitter power)
- Ltx = cable loss between transmitter and antenna in dB (see Appendix B.2.4, *Cable Loss (p. B-3)*
- Gtx = transmit antenna gain in dBi (dBi = dBd + 2.15)
- Lpath = path loss between antennas in dB (see TABLE B-5, TABLE B-6)
- Grx = receive antenna gain in dBi
- Lrx = cable loss between antenna and receiver in dB
- Prx = signal power at the radio receiver in dBm

Most of these values can be readily obtained from data sheets or direct measurements. The notable exception is path loss. Path loss is very difficult to derive analytically. Probably the best approach is to do a site survey that considers the topography, elevation, and location of the antennas, any potential obstructions to the line of sight, and make some assumptions about the path losses (see the Campbell Scientific application note *Line of Sight Obstruction*).

NOTE If losses due to obstructions in the line-of-sight path of propagation are anticipated and a highly reliable link is required, it is strongly recommended that a professional path study be conducted before proceeding with the installation.

By algebraically summing the transmitters output power with the links gains and losses, the signal power at the receiver's input (Prx) can be estimated. If Prx is greater than the receiver's sensitivity (-101 dBm for the RF407), a connection is possible. The amount by which Prx exceeds the receiver's sensitivity is the fade margin. A minimum fade margin of 10 dB is recommended for a reliable link.

B.2.3 Transmitter Power

Transmitter output power is often expressed in dBm, which is a decibel power rating relative to 1 mW. The conversion formula between transmitter power in mW (Pt) and transmitter power in dBm (Ptx) is:

TABLE B-1. Transmitter Power		
Transmitter Power (Pt) (milliWatts)	Ptx dBm	
1	0	
5 (RF407 series minimum)	7	
10	10	
50	17	
100	20	
250 (RF407 series maximum)	24	
1000	30	
5000	37	

$1 \text{ (m a D m)} = 10 \log(1 \text{ (r) with 1 t expressed m m})$	Ptx	(in dBm) =	10 log (Pt)	with Pt expressed	in mW
--	-----	------------	-------------	-------------------	-------

B.2.4 Cable Loss

Cable loss is a function of cable type, length, and frequency and is usually specified as attenuation (dB) per 100 ft. of cable at a given frequency. Using a low loss cable becomes more important as the cable run distances increase. Here are some typical cable types and their properties:

TABLE B-2. Cable Loss									
Cable Type	Outside Diameter	Loss (dB/100 ft) @ 900 MHz							
RG-58A/U	0.195 in	21.1							
COAX RPSMA-L	0.195 in	11.1							
RG-8	0.405 in	6.9							
COAX NTN-L	0.405 in	4.5							
LMR-400 0.405 in 3.9									
*CSI stocked antenna cables are shaded.									

Campbell Scientific's COAX RPSMA-L uses LMR-195 antenna cable. Cable loss is proportional to length as the following table illustrates.

TABLE B-3. LMR-195 Cable Loss vs. Length @ 900 MHz								
Length (ft)	Loss (dB)							
100	11.1							
50	5.6							
25	2.8							
10	1.1							
6	0.7							

B.2.5 Antenna Gain

Increasing antenna gains improves signal strength and, potentially, distance. For example, in the context of free space path loss and all other factors being equal, an increase of 6dB in antenna gain theoretically extends the attainable distance by a factor of 2. An antenna's gain is a function of directivity. For highly directive antennas such as the Yagi, the narrower beam width makes antenna alignment and orientation more critical.

Antenna gain is specified either in dBi (decibels of gain relative to an isotropic radiator) or in dBd (decibels of gain relative to a dipole). The relationship is:

$$dBi = dBd + 2.15$$

	TABLE B-4. Antenna Gain of Recommended Antennas									
Mfg.	Antenna Type	Band	Model	CSI Part Number	dBd Gain	dBi Gain	Size			
Astron	Omni (1/2 wave)	900 MHz	AXH900 RP SMA R	14204	0	2.15	6.75 in			
Antenex	Collinear	900 MHz	FG9023	14221	3	5.15	24 in			
MaxRad	Yagi	900 MHz	BMOY8905	14201	9	11.15	21.4 in			

Some antennas that are FCC approved for use with the RF407 series are:

B.2.6 Receiver Sensitivity

Receiver sensitivity is usually specified in dBm for a specific bit error rate (BER). The transceiver module used in the RF407 series is specified at -101 dBm at $\sim 10^{-4}$ raw BER.

If the received signal strength is greater than the receiver sensitivity, a link can be established. Any excess signal strength above the receiver sensitivity is fade margin, and is a very good thing; a minimum of 10 dB of fade margin should be sought.

B.2.7 Path Loss

A starting point is the free space path loss. Here are two equations for this:

 $\begin{array}{ll} Lp\ (dB) = 32.4 + 20\ x\ log(\ f\) + 20\ x\ log(\ d\) & dB \\ Lp\ (dB) = 36.6 + 20\ x\ log(\ f\) + 20\ x\ log(\ d\) & dB \end{array} (f\ in\ MHz,\ d\ in\ km) \\ (f\ in\ MHz,\ d\ in\ miles) \end{array}$

Here is a table showing the free space path loss (in dB). Note the effect of frequency.

	TABLE B-5. Free Space Path Loss									
Frequency		Distance								
	1 mi.	2 mi.	4 mi.	8 mi.	10 mi.	16 mi.	22 mi.	26 mi.	30 mi.	
400 MHz	89	95	101	107	109	113	115	117	118	
915 MHz	96	102	108	114	116	120	123	124	125	
2.4 GHz	104	110	116	122	124	128	131	133	134	

Notice, also, the relationship between path loss and distance: each time you double the distance; you lose 6 dB of signal under free space conditions. Or, put another way, if you add 6 dB of gain (for example with 6 dB of additional antenna gain, or 6 dB *less* cable loss), you can double the distance for free space conditions.

As mentioned before, free space conditions are the ideal, but seldom actually seen. The greater the antenna elevations relative to the terrain in the line-of-sight path, the closer to free space conditions. Antenna height is everything!

B.3 Real World Distance Estimates

It is clear from the above discussion that free space path loss should seldom be used as the basis for estimating real world distance.

Ground Reflections

As discussed in Section 5 of the Campbell Scientific application note *The Link Budget and Fade Margin*, ground reflections will almost always be a factor in terrestrial RF telemetry links. These are caused by the RF signal being reflected from the ground (or water), and undergoing a phase shift so that it destructively or constructively interferes with the line-of-sight signal. The conditions that cause this the most are propagation over water, or over a lowlying fogbank. The reflected signal suffers little attenuation, gets out of phase, and interferes with the main signal. This phenomenon gives rise to the 2-Ray Multipath Propagation Model for estimating real world distances.

The path geometry defined by the relative elevations of the antennas and the distance between the antennas is a significant factor in determining the degree of interference from the reflected wave. The terrain along the path of propagation is always assumed to be relatively flat and smooth.

The equation for estimating path loss using the 2-Ray propagation model is:

Lpath (2-Ray) = $120 - 20\log(h_{tx} \cdot h_{rx}) + 40Log(d)$ (h in meters, d in km)

TABLE B-6 compares path loss (Lpath) calculations for the free space and 2-Ray propagation models. The antenna elevations used for the 2-Ray path loss are 9 m (30 ft) and 3 m (10 ft) respectively.

TABI	TABLE B-6. 915 MHz Distance vs. Path Loss (Lpath in dB) per Two Propagation Models*									
Path Type	2 mi.	4 mi.	6 mi.	8 mi.	10 mi.	14 mi.	18 mi.	22 mi.	26 mi.	30 mi.
Free Space	102	108	111	114	116	119	121	123	124	125
2-Ray	112	124	131	136	140	145	150	153	156	159
*(30 ft and 10	*(30 ft and 10 ft antenna elevations)									

Often the maximum path distance may be constrained more by the antenna elevations than the path loss. This is because the maximum unobstructed line of sight distance in kilometres over a flat earth is defined by the following equation:

 $LOS_{MAX} = (4.124\sqrt{h_1}) + (4.12\sqrt{h_2})$

(h is in meters)

For the preceding antenna elevations, the maximum unobstructed line-of-sight distance is 19.5 km (12 miles).

TABLE B-7 helps select a Path Type in TABLE B-6 to best fit your situation.

TABLE B-7. Path Type vs. Path Characteristics Selector							
Path Type	Path Characteristics						
Free Space	Mountaintop to mountaintop or Tall antenna towers Line of sight						
2-Ray	At water's edge (very reflective) Across field of grain (reflective) Lots of Trees (absorptive)						

B.4 Examples

Some examples will help illustrate the trade-offs in a link analysis. These examples will all use the RF407-series 900 MHz radio at maximum transmitter power, 24 dBm, and will use -101 dBm as the required power level at the radio receiver.

Here's the equation we will use, from Appendix B.2.2, *Link Budget (p. B-2)*:

Ptx - Ltx + Gtx - Lpath + Grx - Lrx = Prx

As previously stated, the amount by which Prx exceeds the receiver's sensitivity is the fade margin. Therefore, in this example:

Fade margin = Prx - (-101 dBm)

Example #1

Antenex FG9023 antennas on each end, 20 ft of LMR195 cable on one end, 10 ft of LMR195 on the other end, antennas at 10 ft height, fairly open terrain with a few trees. How far can I go?

 $\begin{aligned} & Ptx = 24 \text{ dBm} \\ & Ltx = 20 \text{ ft} \bullet (11.1 \text{ dB}/100 \text{ ft}) = 2.22 \text{ dB} \\ & Gtx = Grx = 3 \text{ dBd} = 5.15 \text{ dBi} \\ & Lrx = 10 \text{ ft} \bullet (11.1 \text{ dB}/100 \text{ ft}) = 1.11 \text{ dB} \end{aligned}$

From Appendix B.3, Real World Distance Estimates (p. B-5), we know:

Lpath (2-Ray) = $120 - 20\log(h_{tx} \cdot h_{rx}) + 40Log(d)$ (h in meters, d in km)

Lpath $(2-Ray) = 120 - 20\log(3.05 \cdot 3.05) + 40\log(1.609 \cdot d \text{ in mi})$

Lpath $(2-Ray) = 120 - 19.37 + 40Log (1.609 \cdot d in mi)$

Lpath $(2-Ray) = 100.36 + 40Log (1.609 \cdot d in mi)$

Using the above equation to calculate Lpath at different distances, gives:

TABLE B-8. Lpath vs. Distance for 2-Ray Propagation Model in Example #1										
Distance	2 mi.	4 mi.	6 mi.	8 mi.	10 mi.	14 mi.	18 mi.	22 mi.	26 mi.	30 mi.
Lpath	121	133	140	145	149	155	159	162	165	168

Now we will calculate the fade margin for each distance:

Fade margin = Prx - (-101 dBm)

Fade margin = Ptx - Ltx + Gtx - Lpath + Grx - Lrx + 101 dBM

Fade margin = 24 - 2.22 + 5.15 - Lpath + 5.15 - 1.11 + 101

Fade margin = 132 - Lpath

ТАВ	LE B-9.	Fade Ma	argin (dB	8) vs. Dist	tance for 2	2-Ray Proj	pagation N	Model in E	Example #1	l
Path Type	2 mi.	4 mi.	6 mi.	8 mi.	10 mi.	14 mi.	18 mi.	22 mi.	26 mi.	30 mi.
2-Ray	11	-1	-8	-13	-17	-23	-27	-30	-33	-36

Using the Lpath values from TABLE B-8, gives:

From TABLE B-9 we see that this link should be very reliable up to a distance of 2 miles. LOS_{MAX} for this link is approximately 9 miles, so it would be possible to increase distance by substituting higher gain antennas.

Example #2

Base has MaxRad BMOY8905 Yagi, with 50 ft of LMR195 cable on a 30 ft tower, also a surge suppressor (lightning protection device) with a 0.34 dB loss; remote also has a MaxRad BMOY8905 Yagi with 5 ft of LMR195 cable on a 4 ft pole. Terrain is mostly flat, with sagebrush. How far can I go?

Pt = 24 dBm $Lt = 50 \text{ ft} \cdot (11.1 \text{ dB}/100 \text{ ft}) = 5.55 \text{ dB}$ Gt = 9 dBd = 11.15 dBi $Lr = 5 \text{ ft} \cdot (11.1 \text{ dB}/100 \text{ ft}) = 0.55 \text{ dB}$ Gr = 9 dBd = 11.15 dBi

Need to include an additional loss from the surge suppressor:

Lss = 0.34 dB loss.

From Appendix B.3, Real World Distance Estimates (p. B-5), we know:

Lpath (2-Ray) = $120 - 20\log(h_{tx} \cdot h_{rx}) + 40Log(d)$ (h in meters, d in km)

Lpath $(2-Ray) = 120 - 20\log(9.14 \cdot 1.22) + 40\log(1.609 \cdot d \text{ in mi})$

Lpath $(2-Ray) = 120 - 20.95 + 40Log (1.609 \cdot d in mi)$

Lpath $(2-Ray) = 99.05 + 40Log (1.609 \cdot d in mi)$

Using the above equation to calculate Lpath at different distances, gives:

TABLE B-10. Lpath vs. Distance for 2-Ray Propagation Model in Example #2										
Distance	2 mi.	4 mi.	6 mi.	8 mi.	10 mi.	14 mi.	18 mi.	22 mi.	26 mi.	30 mi.
Lpath	119	131	138	143	147	153	157	161	164	166

Now we will calculate the fade margin for each distance:

Fade margin = Prx - (-101 dBm)

Fade margin = Ptx - Ltx + Gtx - Lpath + Grx - Lrx - Lss+ 101 dBM

Fade margin = 24 - 5.55 + 11.15 - Lpath + 11.15 - 0.55 - 0.34 + 101

Fade margin = 141 - Lpath

Using the Lpath values from TABLE B-10, gives:

TABI	TABLE B-11. Fade Margin (dB) vs. Distance for 2-Ray Propagation Model in Example #2									
Path Type	2 mi.	4 mi.	6 mi.	8 mi.	10 mi.	14 mi.	18 mi.	22 mi.	26 mi.	30 mi.
2-Ray	22	10	3	-2	-6	-12	-16	-20	-23	-25

From TABLE B-11 we see that this link should be very reliable up to a distance of 4 miles and somewhat reliable at a distance of 6 miles. LOS_{MAX} for this link is approximately 10.5 miles, so it could be possible to increase distance by substituting higher gain antennas. Also, increasing antenna elevation at one or both ends of the link could be beneficial.

Example #3

You need to run 125 ft of cable for the tra	nsmitter:
How much loss if I use LMR195 cable?	$125 \text{ ft} \cdot (11.1 \text{ dB}/100 \text{ ft}) = 13.9 \text{ dB}$
How much loss if I use LMR400 cable?	$125 \text{ ft} \cdot (3.9 \text{ dB}/100 \text{ ft}) = 4.9 \text{ dB}$

If I am using path loss from the 2-Ray model, and operating fine at 8 miles with LMR195 cable, how much more fade margin could I expect if I use LMR400 cable (assuming similar terrain and antenna elevations)?

 $13.9 \text{ dB} - 4.9 \text{ dB} \Longrightarrow 9 \text{ dB}$ more fade margin

Campbell Scientific Companies

Campbell Scientific, Inc. 815 West 1800 North Logan, Utah 84321 UNITED STATES www.campbellsci.com • info@campbellsci.com

Campbell Scientific Africa Pty. Ltd. PO Box 2450 Somerset West 7129 SOUTH AFRICA www.campbellsci.co.za • cleroux@csafrica.co.za

Campbell Scientific Southeast Asia Co., Ltd. 877/22 Nirvana@Work, Rama 9 Road Suan Luang Subdistrict, Suan Luang District Bangkok 10250 THAILAND www.campbellsci.asia • info@campbellsci.asia

Campbell Scientific Australia Pty. Ltd. PO Box 8108 Garbutt Post Shop QLD 4814 AUSTRALIA www.campbellsci.com.au • info@campbellsci.com.au

Campbell Scientific (Beijing) Co., Ltd. 8B16, Floor 8 Tower B, Hanwei Plaza 7 Guanghua Road Chaoyang, Beijing 100004 P.R. CHINA www.campbellsci.com • info@campbellsci.com.cn

Campbell Scientific do Brasil Ltda. Rua Apinagés, nbr. 2018 — Perdizes CEP: 01258-00 — São Paulo — SP BRASIL www.campbellsci.com.br • vendas@campbellsci.com.br Campbell Scientific Canada Corp. 14532 – 131 Avenue NW Edmonton AB T5L 4X4 CANADA

www.campbellsci.ca • dataloggers@campbellsci.ca

Campbell Scientific Centro Caribe S.A.

300 N Cementerio, Edificio Breller Santo Domingo, Heredia 40305 COSTA RICA www.campbellsci.cc • info@campbellsci.cc

Campbell Scientific Ltd. Campbell Park 80 Hathern Road Shepshed, Loughborough LE12 9GX UNITED KINGDOM www.campbellsci.co.uk • sales@campbellsci.co.uk

> **Campbell Scientific Ltd.** 3 Avenue de la Division Leclerc

92160 ANTONY FRANCE www.campbellsci.fr • info@campbellsci.fr

Campbell Scientific Ltd. Fahrenheitstraße 13 28359 Bremen

GERMANY www.campbellsci.de • info@campbellsci.de

Campbell Scientific Spain, S. L. Avda. Pompeu Fabra 7-9, local 1 08024 Barcelona SPAIN www.campbellsci.es • info@campbellsci.es

Please visit www.campbellsci.com to obtain contact information for your local US or international representative.