


# KH20

---

## Krypton Hygrometer



# Guarantee

---

This equipment is guaranteed against defects in materials and workmanship. We will repair or replace products which prove to be defective during the guarantee period as detailed on your invoice, provided they are returned to us prepaid. The guarantee will not apply to:

- Equipment which has been modified or altered in any way without the written permission of Campbell Scientific
- Batteries
- Any product which has been subjected to misuse, neglect, acts of God or damage in transit.

Campbell Scientific will return guaranteed equipment by surface carrier prepaid. Campbell Scientific will not reimburse the claimant for costs incurred in removing and/or reinstalling equipment. This guarantee and the Company's obligation thereunder is in lieu of all other guarantees, expressed or implied, including those of suitability and fitness for a particular purpose. Campbell Scientific is not liable for consequential damage.

Please inform us before returning equipment and obtain a Repair Reference Number whether the repair is under guarantee or not. Please state the faults as clearly as possible, and if the product is out of the guarantee period it should be accompanied by a purchase order. Quotations for repairs can be given on request. It is the policy of Campbell Scientific to protect the health of its employees and provide a safe working environment, in support of this policy a "Declaration of Hazardous Material and Decontamination" form will be issued for completion.

When returning equipment, the Repair Reference Number must be clearly marked on the outside of the package. Complete the "Declaration of Hazardous Material and Decontamination" form and ensure a completed copy is returned with your goods. Please note your Repair may not be processed if you do not include a copy of this form and Campbell Scientific Ltd reserves the right to return goods at the customers' expense.

Note that goods sent air freight are subject to Customs clearance fees which Campbell Scientific will charge to customers. In many cases, these charges are greater than the cost of the repair.



Campbell Scientific Ltd,  
80 Hathern Road,  
Shepshed, Loughborough, LE12 9GX, UK  
Tel: +44 (0) 1509 601141  
Fax: +44 (0) 1509 270924  
Email: [support@campbellsci.co.uk](mailto:support@campbellsci.co.uk)  
[www.campbellsci.co.uk](http://www.campbellsci.co.uk)

# About this manual

---

Please note that this manual was originally produced by Campbell Scientific Inc. primarily for the North American market. Some spellings, weights and measures may reflect this origin.

Some useful conversion factors:

**Area:** 1 in<sup>2</sup> (square inch) = 645 mm<sup>2</sup>

**Length:** 1 in. (inch) = 25.4 mm  
1 ft (foot) = 304.8 mm  
1 yard = 0.914 m  
1 mile = 1.609 km

**Mass:** 1 oz. (ounce) = 28.35 g  
1 lb (pound weight) = 0.454 kg

**Pressure:** 1 psi (lb/in<sup>2</sup>) = 68.95 mb

**Volume:** 1 UK pint = 568.3 ml  
1 UK gallon = 4.546 litres  
1 US gallon = 3.785 litres

In addition, while most of the information in the manual is correct for all countries, certain information is specific to the North American market and so may not be applicable to European users.

Differences include the U.S standard external power supply details where some information (for example the AC transformer input voltage) will not be applicable for British/European use. *Please note, however, that when a power supply adapter is ordered it will be suitable for use in your country.*

Reference to some radio transmitters, digital cell phones and aerials may also not be applicable according to your locality.

Some brackets, shields and enclosure options, including wiring, are not sold as standard items in the European market; in some cases alternatives are offered. Details of the alternatives will be covered in separate manuals.

Part numbers prefixed with a “#” symbol are special order parts for use with non-EU variants or for special installations. Please quote the full part number with the # when ordering.

## Recycling information



At the end of this product's life it should not be put in commercial or domestic refuse but sent for recycling. Any batteries contained within the product or used during the products life should be removed from the product and also be sent to an appropriate recycling facility.

Campbell Scientific Ltd can advise on the recycling of the equipment and in some cases arrange collection and the correct disposal of it, although charges may apply for some items or territories.

For further advice or support, please contact Campbell Scientific Ltd, or your local agent.



Campbell Scientific Ltd, 80 Hathern Road, Shepshed, Loughborough, LE12 9GX,  
UK Tel: +44 (0) 1509 601141 Fax: +44 (0) 1509 270924  
Email: [support@campbellsci.co.uk](mailto:support@campbellsci.co.uk)  
[www.campbellsci.co.uk](http://www.campbellsci.co.uk)

# Safety

---

**DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.** FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at [www.campbellsci.eu](http://www.campbellsci.eu) or by telephoning +44(0) 1509 828 888 (UK). You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified engineer. If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

## General

- Prior to performing site or installation work, obtain required approvals and permits. Comply with all governing structure-height regulations, such as those of the FAA in the USA.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a **hardhat** and **eye protection**, and take **other appropriate safety precautions** while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

## Utility and Electrical

- **You can be killed** or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in **contact with overhead or underground utility lines**.
- Maintain a distance of at least one-and-one-half times structure height, or 20 feet, or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.

## Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

## Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CUSTOMER ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.

# Table of Contents

---

*PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.*

<b>1. Introduction.....</b>	<b>1</b>
<b>2. Precautions.....</b>	<b>1</b>
<b>3. Initial Inspection .....</b>	<b>1</b>
3.1 Components .....	1
<b>4. Overview .....</b>	<b>1</b>
<b>5. Specifications .....</b>	<b>2</b>
5.1 Measurements .....	2
5.2 Electrical .....	2
5.3 Physical .....	2
<b>6. Installation .....</b>	<b>3</b>
6.1 Siting .....	3
6.2 Mounting.....	3
6.2.1 Parts and Tools Needed for Mounting .....	3
6.2.2 Mounting the KH20 Sensor .....	3
6.2.3 Mounting the Electronics Box .....	4
6.3 Wiring .....	6
6.4 Data Logger Programming.....	7
6.4.1 Coefficient Determination.....	7
<b>7. Maintenance.....</b>	<b>7</b>
7.1 Visual Inspection.....	8
7.2 Testing the Source Tube.....	8
7.3 Testing the Detector Tube.....	8
7.4 Managing the Scaling of KH20.....	8
7.5 Coefficient Adjustments.....	9

## **Appendices**

<b>A. Coefficient Calculations .....</b>	<b>A-1</b>
A.1 Basic Measurement Theory.....	A-1
A.2 Calculation Coefficients for the KH20.....	A-1
<b>B. Example Program .....</b>	<b>B-1</b>

## **C. Equations and Algorithms of Water Vapour Density and Water Flux in KH20 Eddy-Covariance Systems ..... C-1**

C.1	Fundamental Equation .....	C-1
C.2	Working Equation .....	C-2
C.3	Eddy-Covariance Water Flux .....	C-2
C.4	Frequency Response of KH20 .....	C-3
C.5	References .....	C-4

## **Figures**

6-1.	Mounting KH20 to a tripod .....	4
6-2.	Attaching cables to the electronics box .....	5
6-3.	Electronics box with front cover .....	5
6-4.	KH20, CSAT3B, and electronic box mounted on a mast .....	6
A-1.	KH20 ln(mV) vs. Vapour Density .....	A-2

## **Tables**

6-1.	Wire Colour, Function, and Data Logger Connection .....	6
6-2.	KH20 Ranges .....	7
A-1.	Linear Regression Results for KH20 ln(mV) vs. Vapour Density ..	A-2
A-2.	Final Values for KH20 .....	A-3

## **CRBasic Example**

B-1.	CR3000 Program to Measure Water Vapour Fluctuations .....	B-1
------	-----------------------------------------------------------	-----

# ***KH20 Krypton Hygrometer***

---

## **1. Introduction**

The KH20 is a highly sensitive hygrometer designed for measurement of rapid fluctuations in atmospheric water vapour, not absolute concentrations. It is typically used together with a CSAT3B in eddy-covariance systems.

## **2. Precautions**

- READ AND UNDERSTAND the [Safety](#) section at the front of this manual.
- Although the KH20 is rugged, it should be handled as precision scientific instrument.

## **3. Initial Inspection**

- Upon receipt of the KH20, inspect the packaging and contents for damage. File damage claims with the shipping company.
- The model number and cable length are printed on a label at the connection end of the cable. Check this information against the shipping documents to ensure the correct product and cable length are received (see Section [3.1](#), *Components* (p. 1)).

### **3.1 Components**

The KH20 sensor consist of a sensor head with 2 m (6 ft) cables and an electronics box. The following are also shipped with the KH20:

- KH20CBL-L25 Power/Signal cable with 8 m (25 ft) length. If a longer cable is desired, order a KH20CBL-L replacement cable and specify the desired length after -L (for example KH20CBL-L50).
- 1/2 Unit Desiccant Bag
- Rain Shield
- Horizontal Mounting Boom (51 cm 20 mm DN (20-inch 3/4 IPS) threaded aluminium pipe)
- 3/4 x 3/4 in. Nu-Rail Crossover Fitting
- 4 mm (5/32 in) Allen Wrench

## **4. Overview**

The KH20 is a krypton hygrometer for measuring water vapour fluctuations in the air. The name KH20 (KH-twenty) was derived from KH<sub>2</sub>O (K-H<sub>2</sub>O), and the sensor has been known with this name since 1985. It is typically used with

the CSAT3B 3-D sonic anemometer for measuring latent heat flux (LE), using eddy-covariance technique.

The KH20 sensor uses a krypton lamp that emits two absorption lines: major line at 123.58 nm and minor line at 116.49 nm. Both lines are absorbed by water vapour, and a small amount of the minor line is absorbed by oxygen. The KH20 is not suitable for absolute water vapour concentration measurements due to its signal offset drift.

The KH20 heads are sealed and will not suffer damage should they get wet. In addition, the electronics box and the connectors are housed inside a rain shield that protects them from moisture. The KH20 is suitable for long-term continuous outdoor applications.

The KH20 sensor is comprised of two main parts: the sensor head and the electronics box. The sensor head comes with cables that connect the sensor to the electronics, a power/signal cable, and mounting hardware.

#### NOTE

Discussion on the principles and theory of measurement is included in Appendix A, *Coefficient Calculations (p. A-1)*.

#### Features:

- High frequency response suitable for eddy-covariance applications
- Well-suited for long-term, unattended applications
- Compatible with Campbell Scientific CRBasic data loggers: CR6, CR3000, CR1000X, CR800 Series, CR1000, CR5000, and CR9000(X)

## 5. Specifications

### 5.1 Measurements

<b>Range:</b>	1.7 to 19.5 g/m <sup>3</sup> (nominal)
<b>Frequency Response:</b>	100 Hz
<b>Operating Temperature Range:</b>	–30 to 50 °C

### 5.2 Electrical

<b>Supply Voltage:</b>	10 V to 16 VDC
<b>Current Consumption:</b>	20 mA max at 12 VDC
<b>Power Consumption:</b>	0.24 Watts
<b>Output Signal Range:</b>	0 to 5 VDC

### 5.3 Physical

#### Dimensions

<b>Sensor Head:</b>	29 x 23 x 3 cm (11.5 x 9 x 1.25 in)
<b>Electronics Box:</b>	19 x 13 x 5 cm (7.5 x 5 x 2 in)
<b>Rain Shield with Mount:</b>	29 x 18 x 6.5 cm (11.5 x 7 x 2.5 in)
<b>Mounting Pipe:</b>	50 cm (20 in)
<b>Carrying Case:</b>	64 x 38 x 18 cm (25 x 15 x 7 in)



**Weight**

<b>Sensor Head:</b>	1.61 kg (3.55 lb)
<b>Electronics Box:</b>	0.6 kg (1.4 lb)
<b>Rain Shield with Mount:</b>	2.2 kg (4.75 lb)
<b>Mounting Pipe with Nu-rail:</b>	0.45 kg (1.0 lb)
<b>Carrying Case:</b>	4.3 kg (9.45 lb)
<b>Shipping:</b>	9.2 kg (20.15 lb)

## 6. Installation

### 6.1 Siting

When installing the KH20 sensor for latent heat flux measurement in an eddy-covariance application, proper siting, sensor height, sensor orientation and fetch are important.

### 6.2 Mounting

#### 6.2.1 Parts and Tools Needed for Mounting

The following user-supplied hardware is required to mount the KH20 sensor:

1. Tripod (CM115 standard) or tower
2. Campbell Scientific crossarm (CM204 standard)
3. 3/4-inch IPS Aluminium Pipe, 12 inches long
4. 3/4-inch-by-1-inch Nu-Rail Crossover Fitting
5. Small Phillips and flat-head screwdrivers
6. 1/2-inch wrench

#### 6.2.2 Mounting the KH20 Sensor

Mount the KH20 sensor head as follows:

1. Attach the 51 cm (20 in) mounting boom to the KH20.
2. Mount a crossarm to a tripod or tower.
3. Mount the 12-inch-long pipe to a crossarm via 1-inch-by-3/4-inch Nu-Rail Crossover Fitting.
4. Mount the KH20 onto the 30 cm (12 in) pipe using a 3/4-inch-by-3/4-inch Nu-Rail Crossover Fitting. Mount the KH20 such that the source tube, the longer of the two tubes, is positioned on top, as shown in [FIGURE 6-1](#). Use cable ties to secure loose cables to the tripod or tower mast.



FIGURE 6-1. Mounting KH20 to a tripod

### 6.2.3 Mounting the Electronics Box

Mount the electronics box as follows:

1. Remove the front cover of the rain shield by loosening the two pan-head screws on the bottom front of the rain shield, and then pushing the cover all the way up, and sliding it out.

---

**NOTE**

It will be difficult to mount the rain shield to a mast with the front cover on, since the 1/2-inch nut holding the bottom U-bolt is located inside the rain shield.

---

2. Before mounting the rain shield to a tripod, first mount the electronics box inside the rain shield. Remove the four pan-head screws from the back panel of the rain shield. Align the electronics box and use the four pan-head screws to secure the electronics box onto the back panel. Make sure the electronics box is pushed all the way up, and the screws are positioned at the bottom of the mounting slot on the electronics box. This will provide enough room to attach the connectors to the bottom of the electronics box later.

---

**NOTE**

If the electronics box is not pushed all the way up during mounting, you will not have enough room to attach the connectors to the bottom of the electronics box, as the U-bolt for the rain shield will block the position of the connectors.

---

3. Mount the rain shield onto the tripod or tower mast using the U-bolt provided. Make sure that the distance between the KH20 sensor head and the rain shield is within 5 feet so that the cables from the sensor head will be within reach of the electronics box. Also make sure that the rain shield is mounted vertically with an opening pointing downward so that the rain will effectively run down the rain shield and not penetrate inside.

4. Connect the three cables to the bottom of the electronics box around the U-bolt on the rain shield (see FIGURE 6-2). If there is not enough room for the connectors around the U-bolt, make sure the electronics box is mounted at a highest possible position (see step 2).



*FIGURE 6-2. Attaching cables to the electronics box*

5. Place the front cover back on the rain shield and tighten the two pan-head screws to secure it in place.



*FIGURE 6-3. Electronics box with front cover*

6. Gather any loose cables and tie them up, using cable ties, onto the tripod or tower mast.



FIGURE 6-4. KH20, CSAT3B, and electronic box mounted on a mast

## 6.3 Wiring

TABLE 6-1. Wire Colour, Function, and Data Logger Connection

Wire	Wire Label	Data Logger Connection Terminal
White	Signal	U configured for differential input <sup>1</sup> , <b>DIFF H</b> (differential high, analog-voltage input)
Black (from white/black set)	Signal Reference	U configured for differential input <sup>1, 2</sup> , <b>DIFF L</b> (differential low, analog-voltage input) <sup>2</sup>
Red	Power 12V	<b>12V</b>
Black (from red/black set)	Power Ground	<b>G</b>
Clear	Shield	⏏ (analogue ground)
<sup>1</sup> U terminals are automatically configured by the measurement instruction.		
<sup>2</sup> Jumper to ⏏ with a user-supplied wire.		

## 6.4 Data Logger Programming

The KH20 sensor outputs 0 to 5 VDC analogue signal. These signals can be measured using the VoltDiff instruction on the CRBasic data loggers.

Programming basics for CRBasic data loggers are in the following sections. Complete program examples for select CRBasic data loggers can be found in Appendix B, *Example Program (p. B-1)*.

### 6.4.1 Coefficient Determination

Each KH20 reports data over a vapour range of approximately 2 to 19 g/m<sup>3</sup>. Calculations are performed under the following conditions: window clean and scaled. The water vapour absorption coefficient for three different vapour ranges are calculated from the report data: full range, dry range, and wet range. TABLE 6-2 shows a sample of the KH20 vapour ranges over which three different water vapour absorption coefficients are calculated. See Appendix A, *Coefficient Calculations (p. A-1)*, for more information.

TABLE 6-2. KH20 Ranges	
Ranges	Vapour Density (g/m <sup>3</sup> )
Full Vapour Range	2 – 19
Dry Vapour Range	2 – 9.5
Wet Vapour Range	8.25 – 19

Before the water vapour absorption coefficient,  $k_w$ , is entered into the data logger program for the KH20, the following decisions must be made:

- Will the windows be allowed to scale?
- What vapour range is appropriate for the site?

Once the decision is made, the appropriate  $k_w$  can be chosen from the data report. The data report also contains the path length,  $x$ , for a specific KH20. Using the water vapour absorption coefficient for either the dry or the wet vapour range will produce more accurate measurements than using that for the full range. If the vapour range of the site is unknown, or if the vapour range is on the border line between the dry and the wet vapour ranges, the full range should be used.

## 7. Maintenance

The KH20 sensor is designed for continuous field application and requires little maintenance. The tube ends for the KH20 have been sealed with silicone elastomer using an injection-mould method. Therefore, the tubes are protected from water damage, and the KH20 continues to make measurements under rainy or wet conditions. If the water tends to pool up on the tube window and blocks the signal, turn the sensor head at an angle so as to shed the water off the tube window. The rain shield protects the electronics box and the connectors from moisture.

## 7.1 Visual Inspection

- Make sure the optical windows are clean.
- Inspect the cables and connectors for any damage or corrosion. If you see a discolouration on the white co-axial cable, you may suspect that the cable has water damage.

## 7.2 Testing the Source Tube

The source tube is the longer of the two tubes. Check to see if the source tube is working properly by performing the following test.

First, make sure the UV light is emitted from the source tube. To do this, you may look into the source tube (the longer of the two tubes), and you should see a bright blue light emitted from it.

---

**NOTE**

Avoid looking into the source tube for an extended period of time when the KH20 is powered on to minimize the prolonged exposure to the UV light.

---

If you see a faint or flickering blue light, perform the following test.

Check the current drain on the KH20

Typical current drain for the KH20 during normal operation should be 15 ~ 20 mA. The current drain of around 5 mA or less indicates the problem on the source tube. Obtain an RMA from Campbell Scientific and send the unit in for repair.

Check the voltage signal output from the KH20

If the voltage output reading is below 50 mV, you may have problems with either the source tube or the detector tube (Section 7.3, *Testing the Detector Tube* (p. 8)).

## 7.3 Testing the Detector Tube

If the source tube tests fine but the output from KH20 is still in question, perform the following test. Prepare a piece of paper and insert it between the source tube and the detector tube to completely block the optical path. You should see an immediate decrease in the voltage reading, and it should go close to zero. No noticeable change in the voltage output, when the optical path is completely blocked, indicates a problem in the detector tube. If the decrease in the voltage reading takes place but the reading remains below 50 mV, when the paper is removed from the optical path, the source tube may be at fault. Obtain an RMA from Campbell Scientific and send the unit in for repair.

## 7.4 Managing the Scaling of KH20

The KH20 cannot be used to measure an absolute concentration of water vapour, because of scaling on the source tube windows caused by disassociation of atmospheric constituents by the ultra violet photons (Campbell and Tanner,

1985 and Buck, 1976). The rate of scaling is a function of the atmospheric humidity. In a high humidity environment, scaling can occur within a few hours. That scaling attenuates the signal and can cause shifts in the coefficient curve. However, the scaling over a typical flux averaging period is small. Thus, water vapour fluctuation measurements can still be made with the hygrometer.

To see if the source tube window has been scaled, get a clean, dry cotton swab and slide it across the source tube window. The scale is not visible to the naked eye, but if the window is scaled, you will feel a slight but noticeable resistance while you slide the swab across the window. There will be little resistance if the window is not scaled. If you determine the window is scaled, you can clean it with a wet cotton swab.

Use distilled water and a clean cotton swab to clean the scaled window. After cleaning the window, slide a clean, dry swab across the window to confirm the scale has been removed.

---

**NOTE**

You can use the water vapour absorption coefficient for scaled window from the data report if the window will be allowed to scale during measurements.

---

## 7.5 Coefficient Adjustments

For quality assurance of the measured data, Campbell Scientific recommends the coefficient calculations to be adjusted every two years. A returned material authorization (RMA) and completion of the “Declaration of Hazardous Material and Decontamination” form is required. Refer to the [About this manual](#) page at the front of this manual for more information.

For more information, refer to Appendix [A](#), *Coefficient Calculations* (p. A-1).

# Appendix A. Coefficient Calculations

---

## A.1 Basic Measurement Theory

The KH20 uses an empirical relationship between the absorption of the light and the material through which the light travels. This relationship is known as the Beer's law, the Beer-Lambert law, or the Lambert-Beer law. According to the Beer's law, the log of the transmissivity is anti-proportional to the product of the absorption coefficient of the material,  $k$ , the distance the light travels,  $x$ , and the density of the absorbing material,  $\rho$ . The KH20 sensor uses the UV light emitted by the krypton lamp: major line at 123.58 nm and the minor line at 116.49. As the light travels through the air, both the major line and the minor line are absorbed by the water vapour present in the light path. This relationship can be rewritten as follows, where  $k_w$  is the absorption coefficient for water vapour,  $x$  is the path length for the KH20 sensor, and  $\rho_w$  is the water vapour density.

$$T = e^{-k_w x \rho_w} \quad \text{A-1}$$

If we express the transmissivity,  $T$ , in terms of the light intensity before and after passing through the material as measured by the KH20 sensor,  $V$  and  $V_0$ , respectively, we obtain the following equation.

$$\frac{V}{V_0} = e^{-k_w x \rho_w} \quad \text{A-2}$$

Taking the natural log of both sides, and solving for the density,  $\rho_w$ , yields the following equation.

$$\rho_w = \frac{1}{-k_w x} (\ln V - \ln V_0) \quad \text{A-3}$$

If the path length,  $x$ , and the absorption coefficient for water,  $k_w$  are known, it becomes possible to measure the water vapour density  $\rho_w$ , by measuring the signal output,  $V$ , from KH20.

## A.2 Calculation Coefficients for the KH20

To calculate the absorption coefficient of water vapour,  $k_w$ , we rewrite the equation A-3, and solve for  $\ln(V)$ .

$$\ln V = -k_w x \rho_w + \ln V_0 \quad \text{A-4}$$

Equation A-4 shows a linear relationship between the natural log of the KH20 measurement output,  $\ln V$ , and the water vapour density,  $\rho_w$ . [FIGURE A-1](#) shows the plot of the equation A-4 after we ran a KH20 over a full vapour range.






FIGURE A-1. KH20  $\ln(\text{mV})$  vs. Vapour Density

We can perform the linear regression on the plot to obtain the slope for the relationship between the  $\ln(\text{mV})$  and the vapour density. The slope for the graph is the coefficient,  $k_w x$ . TABLE A-1 shows the result of linear regression analysis. The slope is the product of the absorption coefficient of water vapour,  $k_w$ , and the KH20 path length,  $x$ .

TABLE A-1. Linear Regression Results for KH20 $\ln(\text{mV})$ vs. Vapour Density	
Description	Values
Slope ( $xk_w$ )	−0.205
Y Intercept ( $\ln(V_0)$ )	8.033

If we substitute these values, along with the measured  $\ln V$  into equation A-3, we can obtain the water vapour density,  $\rho_w$ . Campbell Scientific performs the calculations twice for each KH20: once with the window cleaned and again with the window scaled. We then break up the vapour density range into dry and wet ranges, and compute the  $k_w$  values for each sub range, as well as for the full range. If you know the vapour density range for your site, it is recommended that you select the coefficient,  $k_w$ , that is appropriate for your site, the dry range or the wet range. If the vapour range for the site is unknown, or if the vapour range is on the border line between the dry and the wet ranges, use the value for the full range. TABLE A-2 shows the final values the KH20 data report contains. The data shown in TABLE A-2 is from an actual KH20.

TABLE A-2. Final Values for KH20

	Vapour Range (g/m <sup>3</sup> )	Slope (xk <sub>w</sub> )	Y Intercept ln (V <sub>0</sub> )	Coefficient (k <sub>w</sub> )
Full Range	1.74 ~ 19.25	-0.205	3087	-0.144
Dry Range	1.74 ~ 9.20	-0.216	3259	-0.151
Wet Range	7.95 ~ 19.25	-0.201	2899	-0.141

# Appendix B. Example Program

The following example program measures the KH20 at 10Hz, and stores the average values into a data table called 'stats', as well as the raw data into a data table called 'ts\_data'.

## NOTE

The KH20 does not monitor absolute water vapour concentration.

### CRBasic Example B-1. CR3000 Program to Measure Water Vapour Fluctuations

```
'CR3000 Series Data Logger

'This data logger program measures KH20 Krypton Hygrometer.

'The station operator must enter the constant and the coefficient for the KH20.
'Search for the text string "unique" to find the locations of these constants
'and enter the appropriate values found from the data report of the KH20.

*** Unit Definitions ***

'Units      Description
'ln_mV      ln(mV)    (natural log of the KH20 millivolts)
'mV         millivolts
'rho_w      g/m^3

*** Wiring ***

'ANALOG INPUT
'1H         KH20 signal+ (white)
'1L         KH20 signal- (black)
'gnd        KH20 shield (clear)

'EXTERNAL POWER SUPPLY
'POS         KH20 power+ (red)
'            data logger POWER IN 12 (red)
'NEG         KH20 power- (black)
'            KH20 power shield (clear)
'            data logger POWER IN G (black)

PipeLineMode

*** Constants ***

'Measurement Rate      '10 Hz
Const SCAN_INTERVAL = 100 '100 mSec

'Output period
Const OUTPUT_INTERVAL = 30 'Online flux data output interval in minutes.
Const x = 1               'Unique path length of the KH20 [cm].
Const kw = -0.150         'Unique water vapour absorption coefficient [m^3 / (g cm)].
Const xkw = x*kw          'Path length times water vapour absorption coefficient [m^3 / g].

*** Variables ***
Public panel_temp
Public batt_volt
Public kh(2)
Public rho_w
Alias kh(1) = kh_mV
Alias kh (2) = ln_kh
Units panel_temp = deg_C
Units batt_volt = volts
Units kh_mV = mV
```

```

Units ln_kh = ln_mV
Units rho_w = g/m^3

'*** Data Output Tables ***
'Processed data
DataTable (stats,True,-1)
  DataInterval (0,OUTPUT_INTERVAL,Min,10)
  Minimum (1,batt_volt,FP2,False,False)
  Average (1,panel_temp,FP2,False)
  Average (2,kh(1),IEEE4,False)
EndTable

'Raw time-series data.
DataTable (ts_data,True,-1)
  DataInterval (0,SCAN_INTERVAL,mSec,100)
  Sample (1,kh_mV,IEEE4)
EndTable

'*** Program ***

BeginProg

  Scan (SCAN_INTERVAL,mSec,3,0)

    'data logger panel temperature.
    PanelTemp (panel_temp,250)

    'Measure battery voltage.
    Battery (batt_volt)

    'Measure KH2O.
    VoltDiff (kh_mV,1,mV5000,1,TRUE,200,250,1,0)
    ln_kh = LOG(kh_mV)
    rho_w = ln_kh/xkw

    CallTable stats
    CallTable ts_data

  NextScan
EndProg

```

# Appendix C. Equations and Algorithms of Water Vapour Density and Water Flux in KH20 Eddy-Covariance Systems

---

## C.1 Fundamental Equation

A krypton hygrometer (KH20, Campbell Scientific) is a fast-response water vapour analyzer to measure the high-frequency fluctuations of water vapour density in the atmosphere. When the three-dimensional wind speeds are measured nearby using a fast-response sonic anemometer, the fluctuations are used for the eddy-covariance methodology to estimate the water flux (latent heat flux) between ecosystems and the atmosphere.

KH20 has a cylindrical path for measurements (FIGURE 6-1). In the lower end of the path, a krypton lamp emits a major light at 123.58-nm wavelength (wavelength 1) along with a minor light at 116.49-nm wavelength (wavelength 2). The lights penetrate the air along the path length of  $x$ , in cm, and are received by the detector in the upper end of the path that outputs voltage ( $V$  in mV). The lights in both wavelengths are absorbed by two air components: water vapour and oxygen. Without both components along the path, the sensor outputs voltage  $V_{01}$  from wavelength 1 and voltage  $V_{02}$  from wavelength 2, both of which sum up one voltage output as  $V_0$  ( $V_0 = V_{01} + V_{02}$ ) from the sensor for air free of water vapour and oxygen. Given water vapour density ( $\rho_w$  in gH<sub>2</sub>O m<sup>-3</sup>) and oxygen density ( $\rho_o$  in gO<sub>2</sub> m<sup>-3</sup>), based on the Beer–Lambert Law (Wallace and Hobbs. 2006), KH20 output  $V$  can be theoretically expressed as:

$$V = V_{01} \exp(-xk_{w1}\rho_w - xk_{o1}\rho_o) + V_{02} \exp(-xk_{w2}\rho_w - xk_{o2}\rho_o) \quad (1)$$

where, on wavelengths 1 and 2,  $k_{w1}$  and  $k_{w2}$  with subscript  $w$  indicating water are the absorption coefficients of water vapour and  $k_{o1}$  and  $k_{o2}$  with subscript  $o$  indicating oxygen are the absorption coefficients of oxygen. Water vapour has similar absorption at both wavelengths (Campbell Scientific Inc. 2010), thus

$k_{w1} \approx k_{w2}$  and absorption coefficients of water vapour on both wavelengths could be represented by the same value denoted by  $k_w$  in ln(mV) m<sup>3</sup> gH<sub>2</sub>O<sup>-1</sup> cm<sup>-1</sup>. Similarly, one coefficient also is used by Tanner et al. (1993) and van Dijk et al. (2003) for the absorption by oxygen at both wavelengths. Thus, the absorption coefficients for oxygen on both wavelengths ( $k_{o1}$  and  $k_{o2}$ ) can be represented by the same value denoted by  $k_o$  in ln(mV) m<sup>3</sup> gO<sub>2</sub><sup>-1</sup> cm<sup>-1</sup>. Further, equation (1) can be solved for  $\rho_w$  as:

$$\rho_w = -\frac{1}{xk_w} \ln V + \frac{1}{xk_w} (\ln V_0 - xk_o \rho_o) \quad (2)$$

This is the fundamental equation for KH20 measurements.

## C.2 Working Equation

In the field, KH20 measurements output  $V$  values. To acquire  $\rho_w$  from fundamental equation (2), other constants ( $x$  and  $V_0$ ), parameters ( $k_w$  and  $k_o$ ), and variable ( $\rho_o$ ) in this equation are needed. In manufacture process,  $x$  is measured in precision and others are statistically estimated in the coefficient calculation process under the background oxygen density ( $\rho_{oc}$  in  $\text{gO}_2 \text{ m}^{-3}$ ). Through the process, the working equation is given

$$\rho_w = -\frac{1}{xk_w} \ln V + \frac{1}{xk_w} \left[ C_I + xk_o \left( \rho_{oc} - \frac{C_o M_o P}{R^* T} \right) \right] \quad (3)$$

In this equation,  $V$ ,  $P$  (high-frequency atmospheric pressure in Pa), and  $T$  (high-frequency air temperature in K) are variables measured/derived in KH20 eddy-covariance water flux systems;  $k_w$ ,  $C_I$  [termed as “Constant” in  $\ln(\text{mV})$ ],  $x$ , and  $\rho_{oc}$  are parameters and constants from the coefficient calculation, given in KH20 data report;  $k_o$  is  $0.00345 \ln(\text{mV}) \text{ m}^3 \text{ g}^{-1} \text{ cm}^{-1}$  determined by van Dijk et al (2003) following Tanner et al. (1993), considered as universal for all KH20 sensors with  $x$  around 1.3 cm;  $C_o$  is the mole fraction of oxygen that is considered as a constant of 0.2095 in ecosystems (Tanner et al. 1993);  $M_o$  is the molar mass of oxygen ( $32 \text{ g mole}^{-1}$ ); and  $R^*$  is universal gas constant ( $8.3143 \text{ J K}^{-1} \text{ mol}^{-1}$ ).

## C.3 Eddy-Covariance Water Flux

Water flux is computed from  $\overline{w\rho_w}$  (Webb et al. 1980) where  $w$  is vertical wind speed and overbar averages the data over an averaging interval. In practice, it is computed from

$$\overline{w\rho_w} = \overline{w'\rho'_w} + \overline{w\rho_w} \quad (4)$$

where prime indicates the fluctuation of a given variable away from its mean. In the right side of this equation, the first term is the eddy-covariance term which is the covariance of vertical wind speed with water vapour density and the second term is the WPL term (Webb et al. 1980) which reflects the water flux caused by changes in air density.

Eddy-covariance term is derived from equation (3) as

$$\overline{w'\rho'_w} = -\frac{1}{xk_w} \overline{w'(\ln V)'} + \frac{k_o}{k_w} \frac{C_o M_o \bar{P}}{R^* \bar{T}^2} \overline{w'T'} \quad (5)$$

The second term on the right side of this equation is the oxygen correction term.  $\overline{w'T'}$  is temperature flux. It can be directly measured if a fine wiring thermocouple is available; otherwise, it is derived from  $\overline{w'T'_s}$  through SND corrections (van Dijk 2002).

The WPL term is given by Webb et al. (1980):

$$\overline{w'\rho_w'} = \mu\sigma\overline{w'\rho_w'} + (1 + \mu\sigma)\frac{\overline{\rho_w'}}{\overline{T}}\overline{w'T'} \quad (6)$$

where  $\mu$  (1.60802) is the ratio of dry air molecular weight (28.97 kg kmol<sup>-1</sup>) to water molecular weight [18.016 kg kmol<sup>-1</sup>, page 466 in Wallace and Hobbs (2006)],  $\sigma$  is mean water vapour mass mixing ratio (ratio of mean water vapour to mean dry air density computed in the data processing).

As usual in eddy-covariance measurements, the covariance variables:

$w'(\ln V)'$  and  $\overline{w'T'}$  need coordinate rotation and frequency corrections. The general algorithm and procedure for coordinate rotation and frequency corrections are addressed in Campbell Scientific Inc (2020), but the equation for frequency response of a KH20 to water vapour density ( $\ln V$ ) cannot be found in previous documents from Campbell Scientific.

## C.4 Frequency Response of KH20

KH20 measures the water vapour density averaged over a cylindrical light path that has a diameter of 9.5 mm and length of 11 to 15 mm. Andreas (1981) derived the power spectra transfer function for volume averaging [Equation (18) in Andreas (1981)]. His equation includes the first order Bessel function of the first kind that makes the integration of the transfer function over the frequency domain in need of more computation time. Moene (2003) used a simple function to approximate equation (18) of Andreas (1981). Moene's (2003) approximation was developed only for a Krypton Hygrometer with a diameter-ratio of 0.5. Because the cylindrical light path of KH20 for measurements has a fixed diameter, but changeable length, Moene's (2003) approximation only uses the length as a sensor parameter. In his original equation, the approximation curve matches the curve for a diameter-length ratio between 0.5 and 1.0 when the ratio of Kolmogorov microscale (1 mm in the atmosphere) to the path length is 0.014 [Fig. 2 in Andreas (1981)]. Based on the diameter fixed and length range of KH20 cylindrical light path, its diameter-length ratio is about 0.63 to 0.86 within the applicable range of Moene's (2003) approximation for 0.5 to 1.0 as a diameter-length ratio (see page 650). This approximation is given by:

$$T_{\rho_w'^2 VA}(f, x, u) = \exp\left[-2\left(\frac{fx/100}{\bar{u}}\right)^2\right] \quad (7)$$

where  $f$  is natural frequency,  $u$  is wind speed in the stream-wise direction, and 100 is used to convert  $x$  in cm to m. Its application is the same as the power spectral transfer function for line averaging in other Campbell Scientific open-path eddy-covariance systems for the EC155 or IRGASON infrared gas analyzer (Campbell Scientific Inc. 2020)

## **C.5 References**

- Andreas, E.L. 1981. The effects of volume averaging on spectra measured with Lyman-Alpha hygrometer. *Journal of Applied Meteorology* 20: 467-475.
- Campbell Scientific Inc. 2010. KH20 Krypton Hygrometer, Logan, UT, US. pp. 10.
- Campbell Scientific Inc. 2020. EasyFlux-DL, Logan, UT, US. pp. 10.
- Moene, A.F. 2003. Effects of water vapour on the structure parameter of the refractive index for near-infrared radiation. *Boundary-Layer Meteorology* 107: 635-653.
- Tanner, B.D., E. Swiatek, J.P. Greene. 1993. Density fluctuations and use of the krypton Hygrometer in surface flux measurement. *Management of Irrigation and Drainage Systems Sponsored by the Irrigation and Drainage Division/ASCE*, Park City, Utah.
- van Dijk, A. 2002. *The Principle of Surface Flux Physics*. Research Group of the Royal Netherlands Meteorological Institute and Department of Meteorology and Air Quality with Agricultural University Wageningen. 65p.
- van Dijk, A, W. Kohsiek, H.A.R. de Bruin. 2003. Oxygen sensitivity of krypton and Lyman- $\alpha$  hygrometers. *Journal of Atmospheric and Oceanic Technology* 20: 143-151.
- Wallace, J.M., P.V. Hobbs. 2006. *Atmospheric Science: An Introductory Survey*, 2<sup>nd</sup> edition. Elsevier, Amsterdam. pp: 483.
- Webb, E.K., G.I. Pearman, R. Leuning. 1980. Correction of flux measurements for density effects due to heat and water transfer. *Quart. J. Met. Soc.* 106: 85-100.





## Global Sales & Support Network

*A worldwide network to help meet your needs*



### Campbell Scientific regional offices

#### Australia

**Location:** Garbutt, QLD Australia  
**Phone:** 61.7.4401.7700  
**Email:** [info@campbellsci.com.au](mailto:info@campbellsci.com.au)  
**Website:** [www.campbellsci.com.au](http://www.campbellsci.com.au)

#### Brazil

**Location:** São Paulo, SP Brazil  
**Phone:** 11.3732.3399  
**Email:** [vendas@campbellsci.com.br](mailto:vendas@campbellsci.com.br)  
**Website:** [www.campbellsci.com.br](http://www.campbellsci.com.br)

#### Canada

**Location:** Edmonton, AB Canada  
**Phone:** 780.454.2505  
**Email:** [dataloggers@campbellsci.ca](mailto:dataloggers@campbellsci.ca)  
**Website:** [www.campbellsci.ca](http://www.campbellsci.ca)

#### China

**Location:** Beijing, P. R. China  
**Phone:** 86.10.6561.0080  
**Email:** [info@campbellsci.com.cn](mailto:info@campbellsci.com.cn)  
**Website:** [www.campbellsci.com.cn](http://www.campbellsci.com.cn)

#### Costa Rica

**Location:** San Pedro, Costa Rica  
**Phone:** 506.2280.1564  
**Email:** [info@campbellsci.cc](mailto:info@campbellsci.cc)  
**Website:** [www.campbellsci.cc](http://www.campbellsci.cc)

#### France

**Location:** Vincennes, France  
**Phone:** 0033.0.1.56.45.15.20  
**Email:** [info@campbellsci.fr](mailto:info@campbellsci.fr)  
**Website:** [www.campbellsci.fr](http://www.campbellsci.fr)

#### Germany

**Location:** Bremen, Germany  
**Phone:** 49.0.421.460974.0  
**Email:** [info@campbellsci.de](mailto:info@campbellsci.de)  
**Website:** [www.campbellsci.de](http://www.campbellsci.de)

#### India

**Location:** New Delhi, DL India  
**Phone:** 91.11.46500481.482  
**Email:** [info@campbellsci.in](mailto:info@campbellsci.in)  
**Website:** [www.campbellsci.in](http://www.campbellsci.in)

#### South Africa

**Location:** Stellenbosch, South Africa  
**Phone:** 27.21.8809960  
**Email:** [sales@campbellsci.co.za](mailto:sales@campbellsci.co.za)  
**Website:** [www.campbellsci.co.za](http://www.campbellsci.co.za)

#### Spain

**Location:** Barcelona, Spain  
**Phone:** 34.93.2323938  
**Email:** [info@campbellsci.es](mailto:info@campbellsci.es)  
**Website:** [www.campbellsci.es](http://www.campbellsci.es)

#### Thailand

**Location:** Bangkok, Thailand  
**Phone:** 66.2.719.3399  
**Email:** [info@campbellsci.asia](mailto:info@campbellsci.asia)  
**Website:** [www.campbellsci.asia](http://www.campbellsci.asia)

#### UK

**Location:** Shepshed, Loughborough, UK  
**Phone:** 44.0.1509.601141  
**Email:** [sales@campbellsci.co.uk](mailto:sales@campbellsci.co.uk)  
**Website:** [www.campbellsci.co.uk](http://www.campbellsci.co.uk)

#### USA

**Location:** Logan, UT USA  
**Phone:** 435.227.9120  
**Email:** [info@campbellsci.com](mailto:info@campbellsci.com)  
**Website:** [www.campbellsci.com](http://www.campbellsci.com)