



SC32B

Optically Isolated RS-232 Interface



Table of Contents

PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.

1. Function	1
2. Specifications	2
3. Connector Descriptions	2
3.1 RS-232.....	2
3.2 9 Pin	3
4. Operation	3
5. Application.....	3

Figure

1-1. SC32B Optically Isolated RS-232 Interface.....	1
---	---

Table

3-1. SC32B Connector Descriptions.....	2
--	---

SC32B Optically Isolated RS-232 Interface

1. Function



FIGURE 1-1. SC32B Optically Isolated RS-232 Interface

The SC32B interfaces an RS-232 peripheral, commonly a computer or terminal, to the CS I/O port of a Campbell Scientific data logger. Functions include:

1. Converting data logger logic levels to RS-232 logic levels.
2. Optically isolating the data logger and the RS-232 peripheral. Optical isolation separates the SC32B into a data logger section and an RS-232 section. Signals entering from either side are electrically independent, protecting against ground loops, normal static discharge, and noise.
3. Passing data when modem enable pin 5 is high and SDE/printer enable pin 6 is low (normal telecommunications mode).

The SC32B blocks data sent out the data logger CS I/O port when the SDE/print enable pin 6 is high. This prevents data sent to an SDE device (for example, storage module) or printer output from being sent out the RS-232 port.

2. Specifications

Operating Temperature:	–25° to +50°C (typical)
Power:	Powered by data logger; see Section 4, <i>Operation</i>
Ports:	9 pin female RS-232 configured as DCE. 9 pin male CS I/O
Baud Rate:	1200 bps to 115.2 kbps; see Section 4, <i>Operation</i>
Size:	4.1 x 2.3 x 7.6 cm (1.6 x 0.9 x 3 in)
Weight:	45.4 g (1.6 oz)
Compliance Documents:	View at www.campbellsci.com/sc32b



3. Connector Descriptions

RS-232 9 Pin Female Connector			CS I/O 9 Pin Male Connector		
Pin #	I/O	Description	Pin #	I/O	Description
1	Out	DCD	1	In	+5 V
2	Out	RXD	2		Ground
3	In	TXD	3	Out	Ring
4	In	DTR	4	Out	RX
5		Ground	5	In	ME
6	Out	DSR	6	In	PE (SDE)
7	In	RTS	7		No Connection
8	Out	CTS	8		No Connection
9		No Connection	9	In	TX

3.1 RS-232

The DB9 RS-232 port is configured as Data Communications Equipment (DCE) for direct cable connection to Data Terminal Equipment (DTE). Most computers are configured as DTE. For connection to DCE devices such as modems, the SC932A should be used in place of the SC32B.

3.2 9 Pin

The CS I/O port connects to the data logger through the SC12 Two Peripheral Cable supplied with the SC32B. Pin descriptions and direction (Input/Output) are given in TABLE 3-1.

4. Operation

Power for the SC32B data logger section comes from the 5 V supply on pin 1 of the data logger CS I/O. Communication logic levels to and from the data logger are referenced to this voltage, ranging from 0 to slightly less than 5 V.

Power for the RS-232 section is isolated from the data logger 5 V supply via a transformer/isolator. An on-board DC to DC converter supplies the negative voltage required for RS-232 signals.

When the SC32B first receives a character from the RS-232 peripheral (pin 3), 5 V is applied to the data logger Ring line (pin 3) until the data logger Modem Enable (ME) goes high, putting the data logger into the Telecommunications Mode.

The SC32B does not perform baud rate translation. The data speed going out will match the data speed coming in. If you are having trouble communicating, check that the data logger's CS I/O ME baud rate matches that being used by the computer/*LoggerNet*. When other devices are also connected to the data logger's CS I/O port, it may be necessary to lower the baud rate used for the SC32B. If you encounter communication issues, consider starting at 9600. If communication is successful, you can increase the baud rate until communication problems return.

5. Application

The SC32B provides a direct interface between the CS I/O port on a Campbell Scientific data logger and the RS-232 port on a computer. Some Campbell Scientific data loggers have a built-in RS-232 port in addition to the CS I/O port. With these data loggers, the SC32B is only necessary if you wish to connect to the CS I/O port instead of the RS-232 port.

The SC32B blocks data sent out the CS I/O port when the data logger sets the printer enable/SDE (pin 6) high. The SC932A (CS I/O to RS-232 DTE interface) can be used to interface to an RS-232 modem.

Limited Warranty

Products manufactured by Campbell Scientific are warranted by Campbell Scientific to be free from defects in materials and workmanship under normal use and service for twelve months from the date of shipment unless otherwise specified on the corresponding product webpage. See Product Details on the Ordering Information pages at www.campbellsci.com. Other manufacturer's products, that are resold by Campbell Scientific, are warranted only to the limits extended by the original manufacturer.

Refer to www.campbellsci.com/terms#warranty for more information.

CAMPBELL SCIENTIFIC EXPRESSLY DISCLAIMS AND EXCLUDES ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Campbell Scientific hereby disclaims, to the fullest extent allowed by applicable law, any and all warranties and conditions with respect to the Products, whether express, implied or statutory, other than those expressly provided herein.

Assistance

Products may not be returned without prior authorization.

Products shipped to Campbell Scientific require a Returned Materials Authorization (RMA) or Repair Reference number and must be clean and uncontaminated by harmful substances, such as hazardous materials, chemicals, insects, and pests. Please complete the required forms prior to shipping equipment.

Campbell Scientific regional offices handle repairs for customers within their territories. Please see the back page for the Global Sales and Support Network or visit www.campbellsci.com/contact to determine which Campbell Scientific office serves your country.

To obtain a Returned Materials Authorization or Repair Reference number, contact your CAMPBELL SCIENTIFIC regional office. Please write the issued number clearly on the outside of the shipping container and ship as directed.

For all returns, the customer must provide a “Statement of Product Cleanliness and Decontamination” or “Declaration of Hazardous Material and Decontamination” form and comply with the requirements specified in it. The form is available from your CAMPBELL SCIENTIFIC regional office. Campbell Scientific is unable to process any returns until we receive this statement. If the statement is not received within three days of product receipt or is incomplete, the product will be returned to the customer at the customer’s expense. Campbell Scientific reserves the right to refuse service on products that were exposed to contaminants that may cause health or safety concerns for our employees.

Safety

DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND **TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.** FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at www.campbellsci.com. You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified engineer. If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

General

- Protect from over-voltage.
- Protect electrical equipment from water.
- Protect from electrostatic discharge (ESD).
- Protect from lightning.
- Prior to performing site or installation work, obtain required approvals and permits. Comply with all governing structure-height regulations.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a **hardhat** and **eye protection**, and take **other appropriate safety precautions** while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

Utility and Electrical

- **You can be killed** or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in **contact with overhead or underground utility lines**.
- Maintain a distance of at least one-and-one-half times structure height, 6 meters (20 feet), or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.
- Only use power sources approved for use in the country of installation to power Campbell Scientific devices.

Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

Internal Battery

- Be aware of fire, explosion, and severe-burn hazards.
- Misuse or improper installation of the internal lithium battery can cause severe injury.
- Do not recharge, disassemble, heat above 100 °C (212 °F), solder directly to the cell, incinerate, or expose contents to water. Dispose of spent batteries properly.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CUSTOMER ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.



Global Sales & Support Network

A worldwide network to help meet your needs



Campbell Scientific Regional Offices

Australia

Location: Garbutt, QLD Australia
Phone: 61.7.4401.7700
Email: info@campbellsci.com.au
Website: www.campbellsci.com.au

Brazil

Location: São Paulo, SP Brazil
Phone: 11.3732.3399
Email: vendas@campbellsci.com.br
Website: www.campbellsci.com.br

Canada

Location: Edmonton, AB Canada
Phone: 780.454.2505
Email: dataloggers@campbellsci.ca
Website: www.campbellsci.ca

China

Location: Beijing, P. R. China
Phone: 86.10.6561.0080
Email: info@campbellsci.com.cn
Website: www.campbellsci.com.cn

Costa Rica

Location: San Pedro, Costa Rica
Phone: 506.2280.1564
Email: info@campbellsci.com
Website: www.campbellsci.com

France

Location: Vincennes, France
Phone: 0033.0.1.56.45.15.20
Email: info@campbellsci.fr
Website: www.campbellsci.fr

Germany

Location: Bremen, Germany
Phone: 49.0.421.460974.0
Email: info@campbellsci.de
Website: www.campbellsci.de

India

Location: New Delhi, DL India
Phone: 91.11.46500481.482
Email: info@campbellsci.in
Website: www.campbellsci.in

South Africa

Location: Stellenbosch, South Africa
Phone: 27.21.8809960
Email: sales@campbellsci.co.za
Website: www.campbellsci.co.za

Spain

Location: Barcelona, Spain
Phone: 34.93.2323938
Email: info@campbellsci.es
Website: www.campbellsci.es

Thailand

Location: Bangkok, Thailand
Phone: 66.2.719.3399
Email: info@campbellsci.asia
Website: www.campbellsci.asia

UK

Location: Shepshed, Loughborough, UK
Phone: 44.0.1509.601141
Email: sales@campbellsci.co.uk
Website: www.campbellsci.co.uk

USA

Location: Logan, UT USA
Phone: 435.227.9120
Email: info@campbellsci.com
Website: www.campbellsci.com