



TS100SS

Aspirated Radiation Shield



Please read first

About this manual

Please note that this manual was produced by Campbell Scientific Inc. primarily for the North American market. Some spellings, weights and measures may reflect this. In addition, while most of the information in the manual is correct for all countries, certain information is specific to the North American market and so may not be applicable to European users. Differences include the U.S. standard external power supply details where some information (for example the AC transformer input voltage) will not be applicable for British/European use. Please note, however, *that when a power supply adapter is ordered from Campbell Scientific it will be suitable for use in your country.*

Reference to some radio transmitters, digital cell phones and aerials (antennas) may also not be applicable according to your locality. Some brackets, shields and enclosure options, including wiring, are not sold as standard items in the European market; in some cases alternatives are offered.

Recycling information for countries subject to WEEE regulations 2012/19/EU



At the end of this product's life it should not be put in commercial or domestic refuse but sent for recycling. Any batteries contained within the product or used during the products life should be removed from the product and also be sent to an appropriate recycling facility, per [The Waste Electrical and Electronic Equipment \(WEEE\) Regulations 2012/19/EU](#). Campbell Scientific can advise on the recycling of the equipment and in some cases arrange collection and the correct disposal of it, although charges may apply for some items or territories. For further support, please contact Campbell Scientific, or your local agent.

Table of contents

1. Introduction	1
2. Precautions	1
3. Initial inspection	1
4. QuickStart	2
5. Overview	5
6. Specifications	6
7. Installation	6
7.1 Wiring	6
7.2 Programming	7
7.3 Siting	7
7.4 Mounting	8
8. Maintenance	10
Appendix A. Importing Short Cut code into CRBasic Editor	12

1. Introduction

The TS100SS, manufactured by Apogee Instruments, Inc., is a fan-aspirated radiation shield that minimizes temperature-measurement errors caused by incident solar radiation. The unique aerodynamic shape and rugged, low-power fan make it the first research-grade fan-aspirated shield that is practical for use on battery- or solar-powered stations. The shield protects the sensor and accommodates various combinations of thermistors, PRTs, and humidity sensors using one of the sensor port adapter plugs.

Typical applications include air temperature and humidity measurements in weather networks, often for weather forecasting, and solar energy sites. Fan-aspirated shields are also important in the precise measurement of air temperature and humidity gradients above the land surface and in climate change monitoring.

2. Precautions

- READ AND UNDERSTAND the [Safety](#) section at the back of this manual.
- Care should be taken when opening the shipping package to not damage or cut the cable jacket. If damage to the cable is suspected, consult with Campbell Scientific.
- The TS100SS is a precision instrument. Please handle it with care.



3. Initial inspection

- Upon receipt of the TS100SS, inspect the packaging and contents for damage. File any damage claims with the shipping company.
- Immediately check package contents against the shipping documentation. Contact Campbell Scientific about any discrepancies.
- The TS100SS is shipped with the cable, cable tie tabs, and two cable ties ([Figure 3-1](#) [p. 2]). A port adapter is ordered as an accessory; ensure that it is the correct adapter for your sensor.



Figure 3-1. Components shipped with the TS100SS

4. QuickStart

A video that describes data logger programming using *Short Cut* is available at: www.campbellsci.com/videos/cr1000x-data-logger-getting-started-program-part-3 . *Short Cut* is an easy way to program your data logger to measure the sensor and assign data logger wiring terminals. *Short Cut* is available as a download on www.campbellsci.com . It is included in installations of *LoggerNet*, *RTDAQ*, and *PC400*.


The following procedure also shows using *Short Cut* to program the TS100SS.

1. Open *Short Cut* and click **Create New Program**.
2. Double-click the data logger model.

NOTE:

If using a solar radiation measurement to control the fan, add the solar sensor to *Short Cut* before adding the TS100SS. The solar radiation output needs to be in W/m^2 . Refer to the solar radiation sensor manual for more information.

3. In the **Available Sensors and Devices** box, type TS100SS or find the device in the **Calculations & Control > Control** folder, and double-click **TS100SS Aspirated Radiation Shield**. If not using a solar radiation measurement, uncheck the **Use reference solar radiation measurement for fan control** box. Otherwise, select the correct variable name for the reference solar radiation measurement.



- Click the **Wiring** tab. Click **OK** after wiring the sensor.

The screenshot shows the 'Wiring' tab of a configuration window for the TS100SS. It features a table mapping sensor wires to CR1000X Series terminals. Below the table is a descriptive text block about the TS100SS and its fan speed units. At the bottom are 'OK', 'Cancel', and 'Help' buttons.

TS100SS	CR1000X Series
Tachometer Power, Blue	12V
Fan Power, Red	12V
Fan Speed Control, Green	C1
Shield, Clear	G
Power Ground, Black	G
Tachometer Signal, White	P1

Click a CR1000X Series terminal name to change a wire's location.

TS100SS Aspirated Radiation Shield
Units for Fan Speed: RPM

The TS100SS is a datalogger controlled fan aspirated solar radiation shield that can use a solar radiation measurement (W/M^2) to set the duty cycle of the fan. By slowing the fan at night, power consumption can be reduced from 80mA to 25mA. The fan duty cycle is controlled using pulse width modulation from the datalogger. The fan speed is also monitored by measuring a high frequency pulse count. Fan speed is useful to determine fan health and may indicate problems that will require a site visit.

OK Cancel Help

- Repeat steps three and four for other sensors you want to measure. Click **Next**.
- In **Output Setup**, type the scan rate, a **Table Name**, and **Data Output Storage Interval**. Click **Next**.

The screenshot shows the 'Output Setup' window. It includes a progress sidebar, a table configuration section with a 'Table Name' field, and a 'Data Output Storage Interval' section. At the bottom, there is a checkbox for 'Advanced Outputs' and a help section with a question mark icon. Navigation buttons 'Previous', 'Next', 'Finish', and 'Help' are at the bottom.

File Program Tools Help Test

Progress

1. New/Open
2. Datalogger
3. Sensors
- 4. Output Setup**
5. Adv. Outputs
6. Output Select
7. Finish

Wiring

- Wiring Diagram
- Wiring Text

How often should the CR300 Series measure its sensor(s)? 10 Seconds

Data is processed by the datalogger and then stored in an output table. Two tables are defined by default; up to 10 tables can be added. Add New Table

1 hourly 2 Daily

Table Name hourly Delete Table


Data Output Storage Interval
Makes 360 measurements per output interval based upon the chosen measurement interval of 10 Seconds. 60 Minutes

☐ Advanced Outputs (all tables)

? Specify how often measurements are to be made and how often outputs are to be stored. Note that multiple output intervals can be specified, one for each output table. By default, an output table is set up to send data to memory based on time. Select the Advanced Output option to send data to memory based on one or more of the following conditions: time, the state of a flag, or the value of a measurement.

Previous Next Finish Help

7. Select the output options.



- Click **Finish** and save the program. Send the program to the data logger if the data logger is connected to the computer.
- If the sensor is connected to the data logger, check the output of the sensor in the data display in *LoggerNet*, *RTDAQ*, or *PC400* to make sure it is making reasonable measurements.

5. Overview

The TS100SS is a fan-aspirated radiation shield that minimizes temperature-measurement errors caused by incident solar radiation. It has a detachable cable and a sensor port that fits several adapters that allow the shield to house different temperature and temperature and relative humidity sensors. Under some environmental conditions such as high wind speed or low solar radiation, accurate measurements can be made without running the fan at full speed. Fan speed and power consumption can be decreased using a pulse width modulation (PWM) signal. The PWM signal should have a frequency of approximately 20 kHz and a duty cycle of 50 to 100%, where a duty cycle of 100% is full power and 50% is low power. Running the fan in a low power mode reduces the current drain from 80 mA to approximately 25 mA. The only way to completely stop the fan is to turn the power off.

The fan also has a tachometer to monitor blade revolutions per minute (RPM). The tachometer outputs a pulse voltage signal. The pulse multiplied by 30 yields fan RPMs. The RPM should be near 4500 in full power mode and 2500 in low power mode. In addition to the tachometer output

wire, there is a pull-up wire (power input). This allows a user-defined maximum output voltage from the tachometer, and facilitates interfacing with multiple measurement devices.

6. Specifications

Difference among individual replicate shields:	< 0.1 °C
Aspiration rate:	6 m/s at full speed; 3 m/s at half speed
Fan input voltage requirement:	10.8 to 13.2 VDC
Fan current draw:	80 mA at full-speed; 25 mA at half-speed
IP rating:	IP55
Height:	22.0 cm (8.7 in)
Diameter:	27.0 cm (10.6 in)
Weight:	840 g (1.9 lb)

7. Installation

If you are programming your data logger with *Short Cut*, skip [Wiring](#) (p. 6) and [Programming](#) (p. 7). *Short Cut* does this work for you. See [QuickStart](#) (p. 2) for a tutorial.

7.1 Wiring

[Table 7-1](#) (p. 6) provides wiring for the TS100SS fan-aspirated radiation shield. The tachometer requires the connection to a power supply.

Table 7-1: Wire color, function, and data logger connection			
Wire color	Wire function	Data logger terminal	Tachometer power supply
Red	12 VDC	12V	N/A
Black	Power ground	G	N/A

Table 7-1: Wire color, function, and data logger connection			
Wire color	Wire function	Data logger terminal	Tachometer power supply
Clear	Shield	⏏ (analog ground)	N/A
Green	Fan speed control	C (control terminal), U configured for pulse width modulation ¹	N/A
Blue	Tachometer power	N/A	VDC +
White	Tachometer output	P, C (control terminal), U configured for high-frequency pulse counting ¹	N/A
¹ U and C terminals are automatically configured by the measurement instruction for Campbell Scientific CR6 data logger.			

7.2 Programming

Accurate measurements can be made at slower fan speeds under conditions such as during the night, high wind speed, and low solar radiation. Running the fan at a lower speed reduces the current drain. The CRBasic program can reduce the fan speed based on these conditions by using the `PWM()` CRBasic instruction. Syntax for this instruction is the following:

```
PWM (Duty_Cycle, Port, Period, Units )
```

A **Duty_Cycle** of 1 operates the fan at full power and a **Duty_Cycle** of 0.5 operates the fan at low power. The period needs to be 50 with the units as microseconds.

The fan has a tachometer to monitor blade revolutions per minute (RPMs) to ensure it is working properly. The tachometer outputs a pulse voltage signal that is measured by the `PulseCount()` instruction, which has the following syntax:

```
PulseCount( Dest, Reps, PChan, PConfig, POption, Mult, Offset )
```

The **Dest** parameter will store the RPMs. Choose high frequency for the **PConfig** parameter and choose frequency in Hertz for the **POption**. The multiplier should be 30 and the offset 0.

Downloadable example programs are available at: www.campbellsci.com/downloads/ts100ss-example-programs.

7.3 Siting

Avoid placing the shield near buildings, paved surfaces, or any other location which may create a micro-environment significantly different than ambient environment. The World Meteorological

Organization (WMO) recommends a mounting height of 1.25 to 2 m above ground. Air temperature typically decreases with increasing height above the ground surface. Ensure that the sensor port (the hole in the side of the shield where the air temperature and/or humidity probe mounts) faces the nearest global pole (north for northern hemisphere, south for southern hemisphere) to maximize shading of the cable wires.

7.4 Mounting

The shield mounts on a crossarm or horizontal pipe (1-1/4 inch to 2 inch IPS).

1. Attach the hat to the pipe with the U-bolt, nuts, and rubber washers ([Figure 7-1](#) [p. 8]).




Figure 7-1. Components of the TS100SS

2. If not already assembled, insert the shorter threaded end of the nylon standoffs into the shield body ([Figure 7-2](#) [p. 9]).




Figure 7-2. Exploded view

3. With the sensor port facing the nearest pole, align the standoffs to the four corresponding holes in the hat and secure with nylon nuts.
4. Insert the sensor port adapter into the sensor port.
5. Slowly insert the sensor into the adapter until the sensor tip is centered in the air stream.
6. If the O-ring binds or comes loose, remove the sensor, fix the O-ring positioning, and reinsert the sensor. Applying petroleum jelly and rotating the sensor while inserting it can ensure the O-ring remains properly positioned.
7. Fasten a cable-tie mount on a flat surface on the underside of the hat. The fan cable comes out the top of the shield under the hat. Secure the cable to the cable-tie mount using a cable tie.
8. Route the cable to the data logger, and secure the cable to the mounting structure using cable ties.

8. Maintenance

NOTE:

All factory repairs and recalibrations require a returned material authorization (RMA) and completion of the “Statement of Product Cleanliness and Decontamination” form. Refer to the [Assistance](#) page at the end of this manual for more information.

Regularly inspect the shield and clean as needed by wiping the surface with a moist rag. Also, check all mounting nuts and tighten if they are loose.

The fan has a tachometer that monitors RPMs (see [Programming](#) [p. 7]). If less than 4500 RPMs at full speed, check for blockage. If there isn't a blockage, replace the fan using the following procedure:

1. Disconnect the TS100SS cable from the fan-cable connector ([Figure 8-1](#) [p. 10]).



Figure 8-1. Top of the TS100SS without hat and standoffs

2. Remove the screws that are holding the fan in the shield body.
3. Lift the old fan from the shield body.

4. Place the new fan (Figure 8-2 [p. 11]) in the shield body and orient the fan so the fan pulls air upwards through the shield towards the hat.




Figure 8-2. Replacement fan

5. Replace and tighten the screws.
6. Connect the TS100SS cable to the fan-cable connector.

Appendix A. Importing *Short Cut* code into *CRBasic Editor*


Short Cut creates a .DEF file that contains wiring information and a program file that can be imported into *CRBasic Editor*. By default, these files reside in the C:\campbellsci\SCWin folder.

Import *Short Cut* program file and wiring information into *CRBasic Editor*:

1. Create the *Short Cut* program, then save it. Click the **Advanced** tab then the **CRBasic Editor** button. Your program file will open in CRBasic with a generic name. Provide a meaningful name and save the CRBasic program. This program can now be edited for additional refinement.

NOTE:

Once the file is edited with *CRBasic Editor*, *Short Cut* can no longer be used to edit the program.

2. To add the *Short Cut* wiring information into the new CRBasic program, open the .DEF file located in the C:\campbellsci\SCWin folder. Copy the wiring information found at the beginning of the .DEF file.
3. Go into the CRBasic program and paste the wiring information at the beginning of the program.
4. In the CRBasic program, highlight the wiring information, right-click, and select **Comment Block**. This adds an apostrophe (') to the beginning of each of the highlighted lines, which instructs the data logger compiler to ignore those lines when compiling. The **Comment Block** feature is demonstrated at about 5:10 in the [CRBasic | Features](#) video .

Limited warranty


Covered equipment is warranted/guaranteed against defects in materials and workmanship under normal use and service for the period listed on your sales invoice or the product order information web page. The covered period begins on the date of shipment unless otherwise specified. For a repair to be covered under warranty, the following criteria must be met:

1. There must be a defect in materials or workmanship that affects form, fit, or function of the device.
2. The defect cannot be the result of misuse.
3. The defect must have occurred within a specified period of time; and
4. The determination must be made by a qualified technician at a Campbell Scientific Service Center/ repair facility.

The following is not covered:

1. Equipment which has been modified or altered in any way without the written permission of Campbell Scientific.
2. Batteries; and
3. Any equipment which has been subjected to misuse, neglect, acts of God or damage in transit.

Campbell Scientific regional offices handle repairs for customers within their territories. Please see the back page of the manual for a list of [regional offices](#) or visit


www.campbellsci.com/contact  to determine which Campbell Scientific office serves your country. For directions on how to return equipment, see [Assistance](#).

Other manufacturer's products, that are resold by Campbell Scientific, are warranted only to the limits extended by the original manufacturer.

CAMPBELL SCIENTIFIC EXPRESSLY DISCLAIMS AND EXCLUDES ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Campbell Scientific hereby disclaims, to the fullest extent allowed by applicable law, any and all warranties and conditions with respect to the products, whether express, implied, or statutory, other than those expressly provided herein.


Campbell Scientific will, as a default, return warranted equipment by surface carrier prepaid. However, the method of return shipment is at Campbell Scientific's sole discretion. Campbell Scientific will not reimburse the claimant for costs incurred in removing and/or reinstalling equipment. This warranty and the Company's obligation thereunder is in lieu of all other

warranties, expressed or implied, including those of suitability and fitness for a particular purpose. Campbell Scientific is not liable for consequential damage.

In the event of any conflict or inconsistency between the provisions of this Warranty and the provisions of Campbell Scientific's Terms, the provisions of Campbell Scientific's Terms shall prevail. Furthermore, Campbell Scientific's Terms are hereby incorporated by reference into this Warranty. To view Terms and conditions that apply to Campbell Scientific, Logan, UT, USA, see [Terms and Conditions](#) . To view terms and conditions that apply to Campbell Scientific offices outside of the United States, contact the [regional office](#) that serves your country.

Assistance

Products may not be returned without prior authorization. Please inform us before returning equipment and obtain a **return material authorization (RMA) number** whether the repair is under warranty/guarantee or not. See [Limited warranty](#) for information on covered equipment.

Campbell Scientific regional offices handle repairs for customers within their territories. Please see the back page of the manual for a list of [regional offices](#) or visit www.campbellsci.com/contact  to determine which Campbell Scientific office serves your country.

When returning equipment, a RMA number must be clearly marked on the outside of the package. Please state the faults as clearly as possible. Quotations for repairs can be given on request.

It is the policy of Campbell Scientific to protect the health of its employees and provide a safe working environment. In support of this policy, when equipment is returned to Campbell Scientific, Logan, UT, USA, it is mandatory that a “[Declaration of Hazardous Material and Decontamination](#)” form be received before the return can be processed. If the form is not received within 5 working days of product receipt or is incomplete, the product will be returned to the customer at the customer’s expense. For details on decontamination standards specific to your country, please reach out to your [regional Campbell Scientific](#) office.

NOTE:

All goods that cross trade boundaries may be subject to some form of fee (customs clearance, duties or import tax). Also, some regional offices require a purchase order upfront if a product is out of the warranty period. Please contact your [regional Campbell Scientific](#) office for details.

Safety

DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC. FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at www.campbellsci.com You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified engineer. If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

General

- Protect from over-voltage.
- Protect electrical equipment from water.
- Protect from electrostatic discharge (ESD).
- Protect from lightning.
- Prior to performing site or installation work, obtain required approvals and permits. Comply with all governing structure-height regulations, such as those of the FAA in the USA.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a hardhat and eye protection, and take other appropriate safety precautions while working on or around tripods and towers.
- Do not climb tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

Utility and Electrical

- You can be killed or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in contact with overhead or underground utility lines.
- Maintain a distance of at least one-and-one-half times structure height, 6 meters (20 feet), or the distance required by applicable law, whichever is greater, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.
- Only use power sources approved for use in the country of installation to power Campbell Scientific devices.

Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

Internal Battery

- Be aware of fire, explosion, and severe-burn hazards.
- Misuse or improper installation of the internal lithium battery can cause severe injury.

- Do not recharge, disassemble, heat above 100 °C (212 °F), solder directly to the cell, incinerate, or expose contents to water. Dispose of spent batteries properly.

Use and disposal of batteries

- Where batteries need to be transported to the installation site, ensure they are packed to prevent the battery terminals shorting which could cause a fire or explosion. Especially in the case of lithium batteries, ensure they are packed and transported in a way that complies with local shipping regulations and the safety requirements of the carriers involved.
- When installing the batteries follow the installation instructions very carefully. This is to avoid risk of damage to the equipment caused by installing the wrong type of battery or reverse connections.
- When disposing of used batteries, it is still important to avoid the risk of shorting. Do not dispose of the batteries in a fire as there is risk of explosion and leakage of harmful chemicals into the environment. Batteries should be disposed of at registered recycling facilities.

Avoiding unnecessary exposure to radio transmitter radiation

- Where the equipment includes a radio transmitter, precautions should be taken to avoid unnecessary exposure to radiation from the antenna. The degree of caution required varies with the power of the transmitter, but as a rule it is best to avoid getting closer to the antenna than 20 cm (8 inches) when the antenna is active. In particular keep your head away from the antenna. For higher power radios (in excess of 1 W ERP) turn the radio off when servicing the system, unless the antenna is installed away from the station, e.g. it is mounted above the system on an arm or pole.

Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CUSTOMER ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.

Global Sales and Support Network

A worldwide network to help meet your needs



Campbell Scientific Regional Offices

Australia

Location: Garbutt, QLD Australia
Phone: 61.7.4401.7700
Email: info@campbellsci.com.au
Website: www.campbellsci.com.au

Brazil

Location: São Paulo, SP Brazil
Phone: 11.3732.3399
Email: vendas@campbellsci.com.br
Website: www.campbellsci.com.br

Canada

Location: Edmonton, AB Canada
Phone: 780.454.2505
Email: dataloggers@campbellsci.ca
Website: www.campbellsci.ca

China

Location: Beijing, P. R. China
Phone: 86.10.6561.0080
Email: info@campbellsci.com.cn
Website: www.campbellsci.com.cn

Costa Rica

Location: San Pedro, Costa Rica
Phone: 506.2280.1564
Email: info@campbellsci.cc
Website: www.campbellsci.cc

France

Location: Montrouge, France
Phone: 0033.0.1.56.45.15.20
Email: info@campbellsci.fr
Website: www.campbellsci.fr

Germany

Location: Bremen, Germany
Phone: 49.0.421.460974.0
Email: info@campbellsci.de
Website: www.campbellsci.de

India

Location: New Delhi, DL India
Phone: 91.11.46500481.482
Email: info@campbellsci.in
Website: www.campbellsci.in

South Africa

Location: Stellenbosch, South Africa
Phone: 27.21.8809960
Email: sales@campbellsci.co.za
Website: www.campbellsci.co.za

Spain

Location: Barcelona, Spain
Phone: 34.93.2323938
Email: info@campbellsci.es
Website: www.campbellsci.es

Thailand

Location: Bangkok, Thailand
Phone: 66.2.719.3399
Email: info@campbellsci.asia
Website: www.campbellsci.asia

UK

Location: Shepshed, Loughborough, UK
Phone: 44.0.1509.601141
Email: sales@campbellsci.co.uk
Website: www.campbellsci.co.uk

USA

Location: Logan, UT USA
Phone: 435.227.9120
Email: info@campbellsci.com
Website: www.campbellsci.com