

INSTRUCTION MANUAL



SC32B Optically Isolated **RS-232 Interface**

Revision: 11/13



Copyright © 1987-2013
Campbell Scientific, Inc.

Warranty

“PRODUCTS MANUFACTURED BY CAMPBELL SCIENTIFIC, INC. are warranted by Campbell Scientific, Inc. (“Campbell”) to be free from defects in materials and workmanship under normal use and service for twelve (12) months from date of shipment unless otherwise specified in the corresponding Campbell pricelist or product manual. Products not manufactured, but that are re-sold by Campbell, are warranted only to the limits extended by the original manufacturer. Batteries, fine-wire thermocouples, desiccant, and other consumables have no warranty. Campbell’s obligation under this warranty is limited to repairing or replacing (at Campbell’s option) defective products, which shall be the sole and exclusive remedy under this warranty. The customer shall assume all costs of removing, reinstalling, and shipping defective products to Campbell. Campbell will return such products by surface carrier prepaid within the continental United States of America. To all other locations, Campbell will return such products best way CIP (Port of Entry) INCOTERM® 2010, prepaid. This warranty shall not apply to any products which have been subjected to modification, misuse, neglect, improper service, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied. The warranty for installation services performed by Campbell such as programming to customer specifications, electrical connections to products manufactured by Campbell, and product specific training, is part of Campbell’s product warranty. CAMPBELL EXPRESSLY DISCLAIMS AND EXCLUDES ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Campbell is not liable for any special, indirect, incidental, and/or consequential damages.”

Assistance

Products may not be returned without prior authorization. The following contact information is for US and international customers residing in countries served by Campbell Scientific, Inc. directly. Affiliate companies handle repairs for customers within their territories. Please visit www.campbellsci.com to determine which Campbell Scientific company serves your country.

To obtain a Returned Materials Authorization (RMA), contact CAMPBELL SCIENTIFIC, INC., phone (435) 227-9000. After an application engineer determines the nature of the problem, an RMA number will be issued. Please write this number clearly on the outside of the shipping container. Campbell Scientific's shipping address is:

CAMPBELL SCIENTIFIC, INC.

RMA# _____
815 West 1800 North
Logan, Utah 84321-1784

For all returns, the customer must fill out a "Statement of Product Cleanliness and Decontamination" form and comply with the requirements specified in it. The form is available from our web site at www.campbellsci.com/repair. A completed form must be either emailed to repair@campbellsci.com or faxed to (435) 227-9106. Campbell Scientific is unable to process any returns until we receive this form. If the form is not received within three days of product receipt or is incomplete, the product will be returned to the customer at the customer's expense. Campbell Scientific reserves the right to refuse service on products that were exposed to contaminants that may cause health or safety concerns for our employees.

Table of Contents

PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.

- 1. Function..... 1
- 2. Specifications2
- 3. Connector Descriptions2
 - 3.1 RS-2322
 - 3.2 9 Pin2
- 4. Operation3
- 5. Application3

Figure

- 1-1. SC32B Optically Isolated RS-232 Interface..... 1

Table

- 3-1. SC32B Connector Descriptions2

SC32B Optically Isolated RS-232 Interface

1. Function



FIGURE 1-1. SC32B Optically Isolated RS-232 Interface

The SC32B interfaces an RS-232 peripheral, commonly a computer or terminal, to the CS I/O port of a Campbell Scientific datalogger. The SC32B has the same functions as the SC32A. Functions include:

1. Converting datalogger logic levels to RS-232 logic levels.
2. Optically isolating the datalogger and the RS-232 peripheral. Optical isolation separates the SC32B into a datalogger section and an RS-232 section. Signals entering from either side are electrically independent, protecting against ground loops, normal static discharge, and noise.
3. Passing data when modem enable pin 5 is high and SDE/printer enable pin 6 is low (normal telecommunications mode).

The SC32B blocks data sent out the datalogger CS I/O port when the SDE/print enable pin 6 is high. This prevents data sent to an SDE device (for example, storage module) or printer output from being sent out the RS-232 port. The SC32B cannot be configured to pass Instruction 96 serial printer or computer data. Contact Campbell Scientific if this capability is required.

2. Specifications

Operating Temperature:	–25° to +50°C (typical)
Power:	Powered by datalogger; see Section 4, <i>Operation</i>
Ports:	9 pin female RS-232 configured as DCE. 9 pin male CS I/O
Baud Rate:	1200 bps to 115.2 kbps; see Section 4, <i>Operation</i>
Size:	4.1 x 2.3 x 7.6 cm (1.6 x 0.9 x 3 in)
Weight:	45.4 g (1.6 oz)

3. Connector Descriptions

TABLE 3-1. SC32B Connector Descriptions					
RS-232 9 Pin Female Connector			CS I/O 9 Pin Male Connector		
Pin #	I/O	Description	Pin #	I/O	Description
1	Out	DCD	1	In	+5 V
2	Out	RXD	2		Ground
3	In	TXD	3	Out	Ring
4	In	DTR	4	Out	RX
5		Ground	5	In	ME
6	Out	DSR	6	In	PE (SDE)
7	In	RTS	7		No Connection
8	Out	CTS	8		No Connection
9		No Connection	9	In	TX

3.1 RS-232

The DB9 RS-232 port is configured as Data Communications Equipment (DCE) for direct cable connection to Data Terminal Equipment (DTE). Most computers are configured as DTE. For connection to DCE devices such as modems, the SC932 or SC932A should be used in place of the SC32B.

3.2 9 Pin

The CS I/O port connects to the datalogger through the SC12 Two Peripheral Cable supplied with the SC32B. Pin descriptions and direction (Input/Output) are given in TABLE 3-1.

4. Operation

Power for the SC32B datalogger section comes from the 5 V supply on pin 1 of the datalogger CS I/O. Communication logic levels to and from the datalogger are referenced to this voltage, ranging from 0 to slightly less than 5 V.

Power for the RS-232 section is isolated from the datalogger 5 V supply via a transformer/isolator. An on-board DC to DC converter supplies the negative voltage required for RS-232 signals.

When the SC32B first receives a character from the RS-232 peripheral (pin 3), 5 V is applied to the datalogger Ring line (pin 3) until the datalogger Modem Enable (ME) goes high, putting the datalogger into the Telecommunications Mode.

The SC32B does not perform baud rate translation. The data speed going out will match the data speed coming in. If you are having trouble communicating, check that the datalogger's CS I/O ME baud rate matches that being used by the computer/*LoggerNet*. When other devices are also connected to the datalogger's CS I/O port, it may be necessary to lower the baud rate used for the SC32B. If you encounter communication issues, consider starting at 9600. If communication is successful, you can increase the baud rate until communication problems return.

5. Application

The SC32B provides a direct interface between the CS I/O port on a Campbell Scientific datalogger and the RS-232 port on a computer. Some Campbell Scientific dataloggers (for example, the CR23X and CR5000) have a built-in RS-232 port in addition to the CS I/O port. With these dataloggers, the SC32B is only necessary if you wish to connect to the CS I/O port instead of the RS-232 port.

The SC32B blocks data sent out the CS I/O port when the datalogger sets the printer enable/SDE (pin 6) high. The SC932 or SC932A (CS I/O to RS-232 DTE interface) can be used to interface to an RS-232 modem.

Campbell Scientific Companies

Campbell Scientific, Inc. (CSI)

815 West 1800 North
Logan, Utah 84321
UNITED STATES

www.campbellsci.com • info@campbellsci.com

Campbell Scientific Africa Pty. Ltd. (CSAf)

PO Box 2450
Somerset West 7129
SOUTH AFRICA

www.csafrica.co.za • cleroux@csafrica.co.za

Campbell Scientific Australia Pty. Ltd. (CSA)

PO Box 8108
Garbutt Post Shop QLD 4814
AUSTRALIA

www.campbellsci.com.au • info@campbellsci.com.au

Campbell Scientific do Brasil Ltda. (CSB)

Rua Apinagés, n.br. 2018 — Perdizes
CEP: 01258-00 — São Paulo — SP
BRASIL

www.campbellsci.com.br • vendas@campbellsci.com.br

Campbell Scientific Canada Corp. (CSC)

14532 — 131 Avenue NW
Edmonton AB T5L 4X4
CANADA

www.campbellsci.ca • dataloggers@campbellsci.ca

Campbell Scientific Centro Caribe S.A. (CSCC)

300 N Cementerio, Edificio Breller
Santo Domingo, Heredia 40305
COSTA RICA

www.campbellsci.cc • info@campbellsci.cc

Campbell Scientific Ltd. (CSL)

Campbell Park
80 Hathern Road
Shepshed, Loughborough LE12 9GX
UNITED KINGDOM

www.campbellsci.co.uk • sales@campbellsci.co.uk

Campbell Scientific Ltd. (CSL France)

3 Avenue de la Division Leclerc
92160 ANTONY
FRANCE

www.campbellsci.fr • info@campbellsci.fr

Campbell Scientific Ltd. (CSL Germany)

Fahrenheitstraße 13
28359 Bremen
GERMANY

www.campbellsci.de • info@campbellsci.de

Campbell Scientific Spain, S. L. (CSL Spain)

Avda. Pompeu Fabra 7-9, local 1
08024 Barcelona
SPAIN

www.campbellsci.es • info@campbellsci.es

Please visit www.campbellsci.com to obtain contact information for your local US or international representative.